



Washing Machine Slot Cleaner

Instruction Manual by ShopyFever.com

Top Load Washing Machine:

1. Dissolve one to two packets of the powder into warm water of around 40~80 degree Celcius.
2. Fill up the washing machine with near full tank water.
3. Pour the solution into the tank. (Alternatively, you can combine the above 2 steps and skip this step, if you can fill the washing machine with warm water. The temperature is suitable to fully dissolve the powder)
4. Put in one to two pieces of cleaning cloth so that the washing machine not running with empty tub.
5. Operate the washing machine for about 10 minutes.
6. Stop the washing machine and let the cleaning solution to work for 3 to 4 hours in still water (but not too long until more than half a day)
7. There might be dirty substances floating on top of the water. Remove them.
8. Continue the washing cycle until it complete. You can use the "tub cleaning" washing cycle if your washing machine support this mode.



Front Load Washing Machine:

1. Pour one to two packets of the powder into the tub and close the door.
2. Put in one to two pieces of cleaning cloth so that the washing machine not running with empty tub.
3. Fill up half the tub with water, preferably warm water.
4. Operate the washing machine for about 10 minutes.
5. Stop the washing machine and let the cleaning solution work for 3 to 4 hours in the water.
6. Continue the washing cycle until it completes.

The steps are different because once the front load washing machine is filled up with water, you can't simply open its door!