


Stopper cylinder ——TWH、TWG、TWQ、TWM Series

TRIMANTEC

Product series

Click to shop online @ www.trimantec.com or call 336-767-1379



Installation and application



- 1. When load changes in the work, the cylinder with abundant output capacity shall be selected.
- 2. Relative cylinder with high temperature resistance or corrosion resistance shall be chosen under the condition of high temperature or corrosion.
- 3. Necessary protection measure shall be taken in the environment with higher humidity, much dust or water drops, oil dust and welding dregs.
- 4. Dirty substances in the pipe must be eliminated before cylinder is connected with pipeline. Impurities must be prevented from entering the cylinder.
- 5. The medium used by cylinder shall be filtered to 40 μ m or below.
- 6. The lateral load of the cylinder shall not exceed the allowable value in operation so as to maintain its normal operation and extend its service life.
- 7. Anti-freezing measure shall be adopted under low temperature environment to prevent the water freezing in cylinder.
- 8. If the cylinder is dismantled and stored for a long time, please conduct anti-rust treatment to the surface. Anti-dust caps shall be added in air inlet and outlet ports.


IVV



TWH, TWM Series



Symbol



Product feature


- 1. JIS standard is implemented.
- 2. Widening the piston rod can effectively improve the impact resistance ability of the cylinder.
- 3. Heavy type stopper cylinder has shock absorber adjustable shock absorber, which can reliably absorb the impact energy.
- 4. Shockless stopper cylinder is equipped with self-lock device, which can prevent the returning of rebound of rocker caused by bar objects.
- 5. Several series and specifications for stopper cylinders can be selected.

Specification

Series			TWH						TWM	
Bore size(mm)	20	25	32	40	50	63	80	50	
Fluid			Air(to be filtered by	40 µ m	filter e	lement)				
Action			Double acting type、	Single	acting-	pull typ	е			
Operating Double acting type 0.15~1.0MPa(23~145psi)										
pressure	Single acting-pull type	Ф 20:0.25~	1.0MPa(35~145psi)	Other	s:0.2~	1.0MPa	a(28~1	(45psi		
Proof pres	sure		1.5MPa	a(215ps	i)					
Temperatu	ire °C		-20~80							
Range of s	stroke tolerance		+	1.0 0						
Cushion ty	rpe	Bumper								
Lubrication	1	Non required								
Mounting t	уре		Fla	ange						
Stopper ty	ре	Shock less stopper(With non adjustable absorber) Shock le					ess stopper(With adjustab absorber)			
Port size	1	M5 × 0.8 1/8					1	1/4"	1/8"	
Sensor's t	hread	M5 × 0.5 M8 × 1.0								

① PT thread, G thread and NPT thread are available. Add) Refer to Page 457~480 for details of sensor switch.


Ordering code



1) When the thread is standard, the code is blank.

Note) The buffer is not adjustable if the bore size is 20 and 25. It is adjustable if the bore is over 32.

Lateral Load and Operation pressure





TWH, TWM Series


How to select

Drawing I Bore size Φ 20. Φ 25. Φ 32. Friction index μ =0.1 60 50 40 Ф32 m(kg) 30 Load: 20 Ф20, 25 10 0


Impact speed $\,\upsilon\,[m/min]$ Load m[kg] Friction index µ

When the speed is the same, the friction index more higher, the Load more lighter. so the rubbing surface is smoother is better.

Drawing II




Impact speed: V(m/min)




Selection way:

When load is 300kg, speed is 15m/min, and friction factor is 0.1, draw a horizontal line in the 300 position of Y axis in Table 3 to join with X axis' $.15m/min \phi 63$ cylinder used in this application will be selected.

Inner structure and material of major parts




N	0.	Item	Material	No.	Item	Material
1		Countersink screw	Carbon steel	17	Rocker	Cast steel\ Nodular Cast iron
2		Body	Aluminum alloy	18	PIN	S45C grinding rod
3		Piston	Aluminum alloy	19	PIN gasket	S45C grinding rod
3 4 5 5		Wear ring	Wear resistant material	20	Obstruct block	Powder metallurgy
5		Piston seal	NBR	21	Countersink screw	Carbon steel
		Magnet washer	Aluminum alloy	22	Leader	S45C grinding rod
7		Front cover	Aluminum alloy	23	Sliding bushing	Wear resistant material
8		O-ring	NBR	24	O-ring	NBR
9		Packing	NBR	25	Bumper	TPU
9 9 10 11 11 12		Silencer	Sintered bronze particle	26	Absorber fix and adjust seat	POM
. 11	1	Piston rod	S45C grinding rod		aujust scat	
12	2	Shock absorber		27	Magnet	Plastic
- 13	3	Fixed seat	Nodular Cast iron	28	Magnet washer	NBR
14	4	PIN	S45C grinding rod	29	Spring	Spring steel
15	5	Clip	Spring steel	30	Cushion	POM
16	6	Torsion spring	Spring steel	31	Back cover	Aluminum alloy



16						
	No.	Item	Material	No.	Item	Material
5	1	Body	Aluminum alloy	15	Rocker	Nodular cast iron
4	2	Piston	Aluminum alloy	16	Roller	Powder metallurgy
	3	Wear ring	Wear resistant material	17	Obstruct black	Powder metallurgy
3 2 1 0	4	Piston seal	NBR	18	Countersink screw	Carbon steel
- 1	5	Magnet washer	Aluminum alloy	19	Leader	S45C grinding rod
7	6	Front cover	Aluminum alloy	20	Cancel cap	Aluminum alloy
	7	O-ring	NBR	21	Sliding bushing	Bronze powder metallurgy
	8	O-ring	NBR	22	Absorber fix and adjust seat	POM
5	9	Gasket	NBR	23	Bumper	TPU
1	10	Piston rod	S45C grinding rod	24	Magnet	Plastic
3	11	Shock absorber		25	Spring	Spring steel
-	12	Mounting seat	Nodular cast iron	26	Bumper	TPU
_	13	PIN	S45C grinding rod	27	Back cover	Aluminum alloy
	14	Torsion spring	Spring steel			

Dimensions





Bore size\Item	Α	AB	AC	AD	AE	AF	В		С	С	Α	СВ
20	129	74	55	60	2.5	8	48		40	1	8	36
25	135.5	78	57.	5 64	2.5	12	58		45	2	0	40
Bore size\Item	D	K	KB	Р	F	PA	R	S		Т		
20	16	4.5	40	M5×0.8	1	12	12	10	3	28	1	
25	16	6.5	47	M5×0.8		16	12	10	2	28		


Note: The type with magnet and the type without magnet have the same dimension. The type with self-lock and the type without selflock have the same dimension.


Adjustable absorber(TWH-K(F),TDH-K(F),TTH-K(F)

Ф32~Ф80










Bore size\Item	Α	AB	AC	1	4D	ΑŁ		Αŀ	В	C	CA
32	152.5	87	65.	5 7	73.5	1.	5	16	67	51.5	23
40	191	112	79	9	92.5	3.	5	16	82	62	26.5
50	211	128	83	-	107.5	2		20	93	72	32
63	245.5	144.5	101		122	3.	5	25	114	87.5	38.5
80	299.5	171.5	128	3 1	145.5	3.	5	25	138	109	49
Bore size\Item	СВ	D	J	K	KB		Р	PA	R	S	Т
32	46	20	11	6.5	53		1/8"	16	12	18.5	28
40	53	25	11	6.5	65		1/8"	16	20	21	26
50	64	32	14	9	73		1/8"	18	20	26	24
63	77	40	18	11	90		1/4"	24	20	30	24

20 13 110 1/4" 30 25 98 50 Note: The type with magnet and the type without magnet have the same dimension. The type with self-lock and the type without selflock have the same dimension.




TWH, TWM Series

Dimensions




Installation and application

1. Function & Operating Manual




- 2. Adjustment of Shock Absorber
- 2.1) The Shock Absorber had been adjusted before the cylinder finished.
- 2.2) The client can adjust it if necessary
- 2.3) The steps are as following.
 - a. Loose the fixed screw.
 - b. Turn the Shock Absorber to adjust the cushion ability.
 - c. Fasten the fixed screw.




3. Multi-working position


Even the flange is fixed, just adjust the mounting position of guide rod will be changed the working direction of the stopper cylinder.




- 4. Working Forbidden
- 4.1) This function is used to cancel the stop action of the cylinder, and make the work piece pass easy.
- 4.2) The steps are as following.
 - a. Screw off the cancel screw from the flange.
 - b. Put the roller seat down.
 - c. Fasten the cancel screw in the screw hole on the fixed seat and the tail of the cancel screw should be inserted in the hole made on the roller seat.



- 5. How to use stopper function
- 5.1) When the shock absorber is impacted deeply, added impact energy must be avoided. The cylinder without shock absorber cann't be impacted by load, otherwise mechanical failure may be caused.
- 5.2) The maximum impact kinetic energy acting on the piston rod cann't exceed the allowable maximum values, otherwise mechanical failure may be caused.



Unusually, when the stopper cylinder is operating, work piece will be rebound as the effect of shocker absorber. In order to keep the work piece steady, we have developed this self-locking device.



Airtad

TWG Series



Symbol



Product feature


- 1. JIS standard is implemented.
- 2. Widening the piston rod can effectively improve the impact resistance ability of the cylinder.
- The installation height is adjustable and several rod end modes can be selected. The cushion effect of the stopper cylinder with shock absorber is better.
- 4. Shockless stopper cylinder is attached with self-lock device, which can prevent the returning of rebound of rocker caused by bar objects.
- 5. Several series and specifications for stopper cylinders can be selected.

Specification


Bore size(mm)	32	40	50							
Fluid		Double acting type Single acting-pull type									
Action		Air(to be filtered by 40 μ m filter element)									
Operating	Double acting type		0.15~1.0MPa(23~145psi)								
pressure	Single acting-pull type		0.2~1.0MPa(28~145psi)								
Proof pres	ssure		1.5MPa(215psi)								
Temperatu	ure °C		-20~80								
Range of	stroke tolerance	+1.0 0									
Cushion ty	/pe		Bumper								
Lubrication	n		Non required								
Mounting	type	Flange	(The mounting high can be c	hanged)							
Stopper ty	pe	Round rod, Flat	Round rod, Flat rod, Roller shock less stopper(with absorber)								
Port size	1	1/8"									


① PT thread, G thread and NPT thread are available. Add) Refer to Page 457~480 for details of sensor switch.

Ordering code



Lateral Load and Operation pressure










TWG Series


Inner structure and material of major parts Dimensions

TTG-K 19 20 21 25

No.	Item	Material
1	Back cover	Aluminum alloy
2	Bumper	TPU
3	Body	Aluminum alloy
4	Wear ring	Wear resistant material
5	Piston	Aluminum alloy
6	Magnet washer	Aluminum alloy
7	Packing	NBR
8	Flange	Aluminum alloy
9	Fixed nut	Carbon steel
10	Countersink screw	Carbon steel
11	Piston rod	Carbon steel with 20 µ m chrome plated
12	Fixed seat	Nodular cast iron
13	Lock pin	Cast steel
14	Rocker	Cast steel
15	Roller	Mild steel
16	Steel ball	Stainless steel
17	Obstruct block	Powder metallurgy
18	Cancel cap	Aluminum alloy
19	Shock absorber	
20	Lock ring	Powder metallurgy
21	Sliding bushing	Wear resistant material
22	Absorber fix and adjust seat	POM
23	Magnet	Plastic
24	Piston seal	NBR
25	Spring	Spring steel
26	O-ring	NBR
27	Silence	Sintered bronze particle



Note: The type with magnet and the type without magnet have the same dimension.




(Thru.hole)

			_	_		B	_		1			
Bore size\Item	Α	AB	F	١C	В		С		D	Ε	G	GA
32	95	38	5	7	7	0	40		20	18.5	50	18
40	100	38	6	2	8	0	47		25	22.5	60	18
50	100	38	6	2	8	0	58		25	22.5	60	18
Bore size\Item	Н	НА	HE	3 K		KB	M			MA	P	PA
32	37	6	15	9		50	N	136	3×1.5	38	1/8"	9
40	44	6	16	9		60	M	4	5×1.5	38	1/8"	12
50	54	6	16	9		60	M	4	5×1.5	38	1/8"	10

Note: The type with magnet and the type without magnet have the same dimension.


Shockless stopper(TWG-K(F), TTG-K(F))




		J							-		Ш	В		-		
Bore size\Item	Α	A	ιB	AC		ΑE		В	С	;	D		G		G	A
32	147.5	9	0.5	57		1	ŀ	70	4	0	20)	50)	18	3
40	172	1	10	62		1.5	- 8	80	4	7	25	5	60)	18	}
50	172	1	10	62		1.5	1	80	5	8	25	5	60)	18	}
Bore size\Item	Н	H	4	НВ	k	(KI	В	М			M	Ą	Р		P
32	37	6		15	9)	50)	М3	6×1	.5	38		1/8	8"	9
40	44	6		16	9)	60)	M4:	5×1	.5	38		1/8	8"	12
50	54	6		16	9)	60)	M4:	5×1	.5	38		1/8	8"	10
Bore size\Item	R		S		Ī	•		U		١	/					
32	15		11.	.5	2	8.		24	1.5	4	1.5		7			
40	20		14		2	24		38	3		14					
50	20		14		2	24		38	3		14		7			

Note: The type with magnet and the type without magnet have the same dimension. The type with self-lock and the type without self-lock have the same dimension.

Roller(TWG-R, TTG-R)





Bore size\Item	Α	AB	AC	AE	В	С	D	Ε	G	GA	Н
32	116	59	57	4	70	40	20	18.5	50	18	37
40	123	61	62	4	80	47	25	22.5	60	18	44
50	123	61	62	4	80	58	25	22.5	60	18	54
Bore size\Item	HA	НВ	K	KB	М		MA	Р	PA	R	RA
32	6	15	9	50	M36	×1.5	38	1/8"	9	20	8
40	6	16	9	60	M45	×1.5	38	1/8"	12	20	8
50	6	16	9	60	M45	.1 E	20	1/8"	10	20	8

Note: The type with magnet and the type without magnet have the same dimension.




AITTAE


Cancel Screw

TWG Series


Installation and application

1. Function & Operating Manual







- 2. Adjustment of Shock Absorber
- 2.1) The Shock Absorber had been adjusted before the cylinder finished.
- 2.2) The client can adjust it if necessary.
- 2.3) The steps are as following.
 - a. Loose the fixed screw.
 - b. Turn the Shock Absorber to adjust the cushion ability.
 - c. Fasten the fixed screw.





- 3. Multi-working position
- 3.1) If the body is fixed, just to adjust the scotch block, the working direction of the cylinder will be changed.
- 3.2) For TWG series, adjusting the position of flange can be changed the working height.



- 4. Working Forbidden(Shock less stopper(K))
- 4.1) This function is used to cancel the stop action of the cylinder, and make the work piece pass easy.
- 4.2) The steps are as following.
 - a. Screw off the cancel screw from the flange.
 - b. Put the roller seat down.
 - c. Fasten the cancel screw in the screw hole on the fixed seat and the tail of the cancel screw should be inserted in the hole made on the roller seat.
- 5. How to use stopper function








6. Self-locking

Unusually, when the stopper cylinder is operating, work piece will be rebound as the effect of shocker absorber. In order to keep the work piece steady, we have developed this self-locking device.





Airtae

TWQ Series



Symbol



Product feature


- 1. JIS standard is implemented.
- 2. Widening the piston rod can effectively improve the impact resistance ability of the cylinder.
- The installation height is adjustable and several rod end modes can be selected. The stopper cylinder with shock absorber has a better cushion effect.
- 4. Shockless stopper cylinder is attached with self-lock device, which can prevent the returning of rebound of rocker caused by bar objects.
- 5. Several series and specifications for stopper cylinders can be selected.

Specification

Bore size	(mm)	20	25	32	40	50				
Fluid		Double acting type Single acting-pull type								
Action			Air(t	o be filtered by	10 μ m filter element)					
Operating	Double acting type			0.15~1.0MP	a(23~145psi)					
pressure	Single acting-pull type	Ф20	: 0.25~1.0M	Pa(35~145psi)	others: 0.2~1.0MPa	(28~145psi)				
Proof pres	ssure	1.5MPa(215psi)								
Temperatu	ure °C	-20~80								
Range of:	stroke tolerance	+1.0 0								
Cushion ty	уре	Bumper								
Lubricatio	n	Non required								
Mounting	type	Thru hole or screw hole								
Stopper ty	/ре	Round rod, F	lat rod/Roller	Round rod, Flat	rod/Roller, Shock less s	topper(with absorber)				
Port size	1	M5×0.8 1/8"								

① PT thread, G thread and NPT thread are available. Add) Refer to Page 457~480 for details of sensor switch.

Ordering code




1) When the thread is standard, the code is blank.





AITTAL

TWQ Series

How to select








Installation and application

Please refer to page 449 for details.


Inner structure and material of major parts





No.	Item	Material
1	Back cover	Aluminum alloy
2	Spring holder	Aluminum alloy
3	Bumper	TPU
4	Body	Aluminum alloy
5	Spring	Spring steel
6	Piston	Aluminum alloy
7	Magnet holder	Aluminum alloy
8	O-ring	NBR
9	Front cover	Aluminum alloy
10	Lock ring	Powder metallurgy
11	Piston rod	Carbon steel with 20 µ m chrome plated
12	Roller	Cast steel
13	Spring pin	Spring steel
14	Countersink screw	Carbon steel
15	Sliding bushing	Bronze powder metallurgy
16	Packing	NBR
17	Countersink screw	Carbon steel
18	Bumper	TPU
19	Magnet	Plastic
20	Piston seal	NBR
21	Silencer	Sintered bronze particle

TTQ-K(Ф 32~Ф 50
--------	-----------




140.	Itelli	Material
1	Body	Aluminum alloy
2	Silencer	Sintered bronze particle
3	Piston	Aluminum alloy
4	Piston seal	NBR
5	Magnet	Plastic
6	Bumper	TPU
7	Countersink screw	Carbon steel
8	Front cover	Aluminum alloy
9	Absorber fix and adjust seat	POM
10	Countersink screw	Carbon steel
11	Piston rod	Carbon steel with 20 µ m chrome plated
12	Mounting seat	Nodular cast iron
13	Lock pin	Cast steel
14	Torsion spring	Spring steel
15	Rocker	Cast steel
16	Roller	Mild steel
17	Steel ball	Free cutting steel
18	Obstruct block	Powder metallurgy
19	Cancel cap	Aluminum alloy
20	Locking cushion	Powder metallurgy
21	Shock absorber	
22	Bushing	Sintered bronze particle
23	O-ring	NBR
24	O-ring	NBR
25	Magnet washer	Aluminum alloy
26	Bumper	Wear resistant material
27	Spring	Spring steel
28	Cushion	POM
29	Back cover	Aluminum alloy



AITTAL

TWQ Series

Dimensions





Bore size\Item	Α	AB	AC	В	С	D		JA
20	67	22	45	36	-	12	9	7
25	68	20	48	40	-	16	9	7
32	68	20	48	45	49.5	20	9	7
40	80.5	28	52.5	53	57	25	9	7
50	82	28	54	64	71	25	11	8


Bore size\item	K	KA	KB	IVI	MA	Р	PA	PR
20	M6×1.0	10	36	24	22	M5×0.8	16.5	9
25	M6×1.0	10	40	30	20	M5×0.8	18	9
32	M6×1.0	10	34	36	20	1/8"	20	10
40	M6×1.0	10	40	44	28	1/8"	20	11
50	M8×1.25	14	50	56	28	1/8"	22	12


Note: The type with magnet and the type without magnet have the same dimension.

Shockless stopper (TWQ-K(F), TTQ-K(F)) φ32, φ40, φ50










			-	U		_						
Bore size\Item	Α	AB	AC	AE	В	С	D		JA	K	KA	KB
32	120.5	72.5	48	1	45	49.5	20	9	7	M6×1.0	10	34
40	152.5	100	52.5	1.5	53	57	25	9	7	M6×1.0	10	40
50	154	100	54	1.5	64	71	25	11	8	M8×1.25	14	50
Bore size\Item	M	MA	Р	PA	ΡВ	R	S	Т	U	V		
32	36	20	1/8"	20	10	15	11.5	28	24	.5 4.5		
40	44	28	1/8"	20	11	20	14	24	38	14		

56 28 1/8" 22 12 20 14 24 38 14

Note: The type with magnet and the type without magnet have the same dimension.


The type with self-lock and the type without self-lock have the same dimension



80.5 2	8	52.	5	53		57		25	22.5	9	7
82 2	8	54		64		71		25	22.5	11	8
K	K	Ά	KE	3	М		MA	P		PA	РВ
M6×1.0	1	0	36		24		22	M	5×0.8	16.5	9
M6×1.0	1	0	40		30		20	M	5×0.8	18	9
M6×1.0	1	0	34		36		20	1/	8"	20	10
M6×1.0	1	0	40		44		28	1/	8"	20	11
M8×1.2	5 1	4	50		56		28	1/	8"	22	12
	82 2 K M6×1.0 M6×1.0 M6×1.0	K K M6×1.0 1 M6×1.0 1 M6×1.0 1 M6×1.0 1 M6×1.0 1	82 28 54 K KA M6×1.0 10 M6×1.0 10 M6×1.0 10 M6×1.0 10	K KA KE M6×1.0 10 36 M6×1.0 10 40 M6×1.0 10 34 M6×1.0 10 40	82 28 54 64 K KA KB M6×1.0 10 36 M6×1.0 10 40 M6×1.0 10 34 M6×1.0 10 40	82 28 54 64 K KA KB M M6×1.0 10 36 24 M6×1.0 10 40 30 M6×1.0 10 34 36 M6×1.0 10 40 44	82 28 54 64 71 K KA KB M M6×1.0 10 36 24 M6×1.0 10 40 30 M6×1.0 10 34 36 M6×1.0 10 40 44	82 28 54 64 71 K KA KB M MA M6×1.0 10 36 24 22 M6×1.0 10 40 30 20 M6×1.0 10 34 36 20 M6×1.0 10 40 44 28	82 28 54 64 71 25 K KA KB M MA P M6×1.0 10 36 24 22 M M6×1.0 10 40 30 20 M M6×1.0 10 34 36 20 1// M6×1.0 10 40 44 28 1//	82 28 54 64 71 25 22.5 K KA KB M MA P M6×1.0 10 36 24 22 M5×0.8 M6×1.0 10 40 30 20 M5×0.8 M6×1.0 10 34 36 20 1/8" M6×1.0 10 40 44 28 1/8"	82 28 54 64 71 25 22.5 11 K KA KB M MA P PA M6×1.0 10 36 24 22 M5×0.8 16.5 M6×1.0 10 40 30 20 M5×0.8 18 M6×1.0 10 34 36 20 1/8" 20 M6×1.0 10 40 44 28 1/8" 20

Note: The type with magnet and the type without magnet have the same dimension.

Roller(TWQ-R, TTQ-R)



Bore size\Item	Α	AB	AC	AE	В	С	D	E	J	JA
20	78	33	45	2	36	-	12	10	9	7
25	81	33	48	2	40	-	16	14	9	7
32	87	39	48	3	45	49.5	20	18.5	9	7
40	103.5	51	52.5	4	53	57	25	22.5	9	7
50	105	51	54	4	64	71	25	22.5	11	8

Bore size\Item	K	KA	KB	M	MA	Р	PA	РВ	R	RA
20	M6×1.0	10	36	24	22	M5×0.8	16.5	9	10	4
25	M6×1.0	10	40	30	20	M5×0.8	18	9	12	6
32	M6×1.0	10	34	36	20	1/8"	20	10	20	8
40	M6×1.0	10	40	44	28	1/8"	20	11	20	8
50	M8×1.25	14	50	56	28	1/8"	22	12	20	8

Note: The type with magnet and the type without magnet have the same dimension.