Heart-Shaped Recorder Manual





Switch has R and P modes:

R: Record Mode P: Playback Mode MIC: Microphone



Squeeze to Record or Playback

Basics:

Battery Type	3PCS AG13/LR44
Recording Duration	20sec

Recording:

Remove the plastic tab before recording. Turn the switch to "R" position and squeeze the heart to record. Hold the heart within 2-10 cm with mic facing sound source for best playback.

The LED light will remain on for the duration of your recording.

Playback:

After recording, flip the switch from "R" to "P" position and squeeze to ensure desired sound was captured.

LED will flash during playback.

Lock the Recording:

Ensure your heart is in the "P" position. Lock your recording by squeezing the heart for 5 seconds until a "beep" is heard. The recording will be locked and a new recording cannot be captured until unlocked.



Unlock:

To unlock your recorder simply squeeze the recorder while on "P" until you hear two beeps.

This recorder is manufactured by Purusha's Picks Inc. for use in My Baby's Heartbeat Bear products only. All rights are reserved. Under no circumstances should this product be used in conjunction with any other brand. Failure to adhere to these guidelines could result in, but is not limited to, termination of your wholesale account, financial penalties and legal actions. Patent Pending.