ПCROSSBEATS







1- OVERVIEW

- 1. Touch control
- 2. Microphone
- 3. Charging case LED
- 4. Pressure relief hole
- 5. Rechargeable touch pad
- 6. Indicator light

2- POWER ON



Take out the earbuds from the charging case, it will automatically power On.

3- POWER OFF



Place the earbuds back in the charging case, the earbuds will power off automatically.

4- FIRST TIME PAIRING



Take out the earbuds from the charging case



The earbuds will auto power ON





Search for 'CB-ATOM' in your phone's BT list





Click to connec t

5- MONO PAIRING





For mono mode, take out either of the earbuds when already paired







The music will automatically play in that particular earbud

6- LED INDICATOR ON CASE



While charging – White light keep blinkingbased on the charge level Low Battery (less than 10%) – The first light will be on for 3 secs Battery full – All 4 lights will be on

Current charge level – Press on the button present at the bottom of the case, to check the battery level of the case.

7- CHARGING



Connect and use the Type-C cable provided in the box for charging Full charge in less than 1.5 hours

8- RESET



- 1. Ensure L&R earbuds are disconnected from all the devices, (turn off the Bluetooth option on the device which was connected before)
- Take out the earbuds from the charging case
- 3. Quickly tap on the earbuds for 5 times, and the white light flashes, indicating that the reset is complete
- Place both earbuds inside the charging case & repeat the pairing process

9- CONTROLS






































IARGING GUIDELINES





- Use only 10W adapters for charging your earbuds Case.
- Caution against using high-power mobile adapters (beyond 10W), as this may lead to charger faults.
- Using adapters with higher power ratings can result in malfunctions and reduce the lifespan of device and your chargers.
- Users can contact customer support for any further assistance or clarification on concerns related to charging and power adapters.

TCROSSBEATS