



CROSSBEATS



LOOP
300

USER MANUAL

OVERVIEW

1. Premium metal body
2. Silicone Eartips
3. Multifunction button
4. Volume/track changing buttons
5. LED indicator
6. Microphone
7. USB Type-C Charging port



POWER ON

Press and hold the MFB to turn ON the neckband.

POWER OFF

Press and hold the MFB to turn OFF the neckband

CHARGING



1. Connect and use the Type-C cable provided in the box for charging
2. Full charge in less than 60mins.

LED INDICATOR

Charging mode: – red light keeps blinking


Fully charged mode: – White light stays on



PAIRING MODE


- 1 After powering on

2



The earbuds will automatically enter pairing mode

3



The indicator lights red and white start to blink alternatively

Note: If the device is already connected, then the earbuds will pair automatically

RESET

1. Ensure L&R earbuds are disconnected from all the devices, (turn off the Bluetooth option on the device which was connected before)
2. Long press '+' and '-' for 3 secs, then the red and white light keeps blinking and the neckband enters the pairing mode.
3. Repeat the pairing process.

CONTROLS

Note:  Tap  Touch and hold

- **Volume decrease:** Press once the '-' button to decrease the volume
- **Volume increase:** Press once the '+' button to increase the volume
- **Play/Pause:** Press the multifunction button once
- **Next track:** Press and hold the '+' button for 2 secs
- **Previous track:** Press and hold the '-' button for 2 secs




NOTE: Available only on devices that are Voice Assistant enabled.

CONTROLS

- **Voice Assistants:** Double press on the multifunction button
- **Answer calls:** Single press on the multifunction button
- **Hang-up calls:** Single press on the multifunction button
- **Reject incoming calls:** Double press on the multifunction button
- **Game mode:** Single press on the 'G' button to enter the Gaming mode



 +91 80500 56565

 +91 80500 56565

 support@crossbeats.com