

 CROSSBEATS

SONIC



USER MANUAL

Product Overview



1. Touch Area
2. Microphone
3. LED light
4. Charging LED light
5. Charging pin
6. Ear tips
7. Charging port



Power On

Open the buds charging case, earbuds automatically Power On.

Power Off

Place the earbuds back in the charging case, the earbuds will power off automatically.

Charging



1. Place the earbuds in the charging case
2. Connect and use the Type-C cable provided in the box for charging
3. Full charge in less than 60 mins.
4. Only charge the Case with 10W adapters not with Ultra or fast charge adapters for the prolonged life of the product

First time pairing

1. Open the Buds charging case.
2. The earbuds will auto Power On and earbuds will enter into the pairing mode
3. Search for 'CB-Sonic' in your Phone's Bluetooth list
4. Click on 'CB-Sonic' to pair.

Mono Pairing

1. For Mono mode, take out either of the earbuds when already paired
2. The music will automatically play in that particular earbud

Reset

1. Place the earbuds in the charging case.
2. Before disconnect from any Device, quick touch the left and Right earbuds 5 times simultaneously, earbuds will blink thrice and the earbuds will reset.
3. Else Go to your phone's Bluetooth list and Unpair the profile CB-Sonic.
4. delete the 'CB-Sonic' profile.
5. Upon unpair earbuds will enter into pairing mode.

Controls

Left Earbud –

- Previous track – Tap X2
- Voice assistant – Tap X 3
- Decrease Volume – Long press for 2 sec



Right Earbud –

- Next track – Tap X2
- Game/Music Mode – Tap X 3
- Increase Volume – Long press for 2 sec



Left/Right –

- Play/Pause – Tap X 1
- Call Answer – Tap X 1
- Call end- Tap X2
- ANC ON/OFF and Pass through modes- Tap X4



Charging case light



Red LED blink
Battery low

>30%



Green LED blink
Charging

99%



LED always ON
Fully charged

100%

Charging Guidelines



- Use only 10W adapters for charging your earbuds Case.
- Caution against using high-power mobile adapters (beyond 10W), as this may lead to charger faults.
- Using adapters with higher power ratings can result in malfunctions and reduce the lifespan of device and your chargers.
- Users can contact customer support for any further assistance or clarification on concerns related to charging and power adapters.



 +91 9611293293

 +91 9611293293

 support@crossbeats.com