

 CROSSBEATS

TORQ 2.0

USER MANUAL



FEATHER TOUCH EARBUDS
WITH IR SENSORS





OVERVIEW



1. LED indicator
2. Touch area
3. IR sensor
4. Charging pin
5. Charging pin
6. Pairing button
7. Case LED indicator
8. USB-C charging port


FIRST TIME PAIRING


Note:  Press & hold

- 

1 Keep earbuds in the charging case
- 

2  x 2 sec
- 

3 The LED on the left earbud will flash Red & Blue lights
- 



4 Search for CB-TORQ (L) on your phone Bluetooth, click & connect
- 

5 Then take out the left earbud followed by right earbud

PAIRING

MONO PAIRING


Note:  Press & hold  Touch and hold






PAIRING


CONNECT WITH THE OTHER DEVICE


Note:  Press & hold

- 

1 Keep earbuds in the charging case
- 

2  x 2 sec
- 

3 The LED on the left earbud will flash Red & Blue lights
- 

4 Search for CB-TORQ (L) on your phone Bluetooth, click & connect
- 

5 Then take out the left earbud followed by right earbud

PAIRING

CONTROLS

Note:  Touch  Touch and hold



CONTROLS


IR SENSORS


- a) While playing music, remove one earbud from ear, the music will pause.
- b) Similarly, put it back on, and the music will play automatically.






RESET


Note:  Press


- 

1 Ensure earbuds are in charging case
- 

2 Red LED will be on
- 

3  x 10 sec
- 

4 Wait until red LED turns Off and then On
- 

5 Now take both earbuds out from charging case
- 

6 Red & Blue LED flashes on left earbud upon Reset complete

RESET

CHARGING



Connect & use TYPE C cable provided with Earbuds.



Charging case White LED status

0-33%



34-66%




67-99%



100%









or




Place the charging case on wireless charging dock/pad.

CHARGING

LED INDICATORS

-  **1**
Pairing
Red & blue LED
Flashes
-  **2**
Standby
LED off
-  **3**
Working
LED off
-  **4**
While Charging
Red LED is on
-  **5**
Fully Charged
LED off
-  **6**
Resetting
Red & blue LED
blink slowly

CHARGING GUIDELINES



- Use only 10W adapters for charging your earbuds Case.
- Caution against using high-power mobile adapters (beyond 10W), as this may lead to charger faults.
- Using adapters with higher power ratings can result in malfunctions and reduce the lifespan of device and your chargers.
- Users can contact customer support for any further assistance or clarification on concerns related to charging and power adapters.



 +91 96112 93293

 +91 96112 93293

 support@crossbeats.com