

TWS Wireless EarBuds



Model: URBAN

User Manual

Overview

Chose eartips





LED Indicator



Medium size Eartips are the best fit for most people. It is also recommended for first-time users.

How to pair



Take out both 2 earbuds then re-insert them back into the case to activate the earphones. Notes: If Earbuds fail to be charged, please charge the case via USB cable (for details, please refer the following step)

How to pair

- 1. Activating the EarBuds.
- 2. Take out the EarBuds from the case, they will auto power on and pair with each other.
- 3. Left EarBud will auto enter into pairing mode while LED light on right EarBud will be turned off.
- 4. Search for "CB-URBAN" on mobile devices and tap to pair it to both EarBuds.

Resetting

Please try the following steps if fail to connect with the mobile device



- 1. Take out the two earbuds, long press it for 3 secs until the LED lights are turned off.
- 2. Press the button for 10s, the LED lights will be on in red and white at the same time, then the lights will
- 3. Put the two earbuds back into the charging case again, then take out from the case, it will auto turn on and pair with each other.
- 4. Search for "CB-URBAN" on the mobile devices and connect it with the earbuds.



Insert the Earbuds into your ears gently with the mic facing towards the front side.

Charging

Charging the Earbuds



Insert the EarBuds into the charging case (pogo pins should be well-connected) LED light will be Red while charging and turns into White (will be last for 60s) once full charged.

(i) Charging the Case



Note: There are 4 LED lights to show the charging case battery status, its means there is 25%, 50%, 75%, 100% battery in sequence.

Functions

U Power-On

Method 1: Take out the EarBuds from the charging case, it will auto power on.



n Power-Off

Method 1: Put the EarBuds back into the charging case, it will auto power off.

Method 2: Tap the multi-function buttons for 3s



Answer/Hang up the call

Tap the multi-function button to answer the call, Tap the button again to hang up.



@ Decline a call

Tap the multi-function button for 1s.



Switch Audio Output

Under the calling status, Tap the multi-function button for 1s to switch audio output between cellphone and Earbuds.



Mute-on/off

Under the calling status, Tap the multi-function button twice to turn on or off the Mute function.



Play/Pause the music

Tap the multi-function button to play pause the music.



Skip to last song

Press the left 2 Times for last song.



Skip to next song

Press the right 2 Times for next song.



Volume increase

Press the right button 3 Times to increase the volume



Volume decrease

Press the left button 3 Times to decrease the volume



Voice Assistant

Under the standby status, tap the multi-function button for 2s to spelling error the voice assistant (eg. Siri).



Re-dial the last calling number

Under the stand by status, tap MFB 4times, it will dial the last calling number.



Model: URBAN

Transmission Distance: 15 meters Bluetooth Vision: V5.0 Charging Time: 1 hour Talking Time: 8 hours Battery type: li-ion Mode: HFP, HSP, H2DP, AVRCP Battery capacity: 50mAh Charging Case capacity: 550mAh Charging case input: DC 5V/400mAh Charging case output: DC 5V /40mAh

- 1. Before using it, please read the user manual carefully and keep it for reference in the future.
- 2. Charge the product fully before the first use.
- 3. If the product has not been used for more than a month, kindly charge it fully before charging it.
- 4. Kindly use the qualified adapter.
- 5. If it can not be found by your mobile devices, please check whether it is in a pairing mode. If not paired with mobile devices for a long time. it will automatically exit pairing mode, in such cases please re-enter the pairing mode. If a procedure error occurs on mobile devices, please reset it, otherwise, try resetting the earbuds.

Warning

- 1. Never disassemble or modify it to avoid causing any damages or dangers.
- 2. Do not store it in extreme temperatures (under 0°C or over 45°C)
- 3. Keep it away from the kids.
- 4. Do not use it during thunderstorms.
- 5. Do not use harsh chemicals or strong detergents to clean it.
- 6. Keep it dry.



🛟 🗵 FC (E RoHS

MADE IN CHINA