



























# ASSEMBLY INSTRUCTION

## TV235



**ADULT ASSEMBLY REQUIRED**

A	 X1	J	 X1
B	 X2	K	 X1
C	 X1	L	 X1
D	 X1	M1	 X1
		M2	 X1
E	 X2	N1	 X1
		N2	 X1
F	 X1	O	 X2
G	 X1	P	 X2
H	 X2	Q	 X2
I	 X2	R1	 X2
		R2	 X2