


























# PART LIST TV322

<b>A</b>	<b>B</b>	<b>C</b>	<b>D</b>	<b>E</b>	<b>F</b>	
 x1	 x1	 x1	 x1	 x1	 x1	
		<b>G</b>	<b>H</b>	<b>I</b>	<b>J</b>	
		 x1	 x1	 x4	 x2	
<b>K</b>	<b>L</b>	<b>M</b>	<b>N</b>	<b>O</b>	<b>P</b>	<b>Q</b>
 x2	 x2	 x2	 x1	 x1	 x1	 x1
<b>R</b>	<b>S</b>	<b>T</b>	<b>U</b>	<b>V</b>	<b>W</b>	<b>X</b>
 x1	 30 mm x12	 66 mm x4	 x4	 22 mm x4	 FF x1	 FE x1


**ADULT ASSEMBLE**

# ASSEMBLY INSTRUCTION TV322


1




2




3




4



5



Complete



**ADULT ASSEMBLE**