

CHICANETH THROTTLE BY WIRE GRIPS

WARNING This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.

CAUTION This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.

ATTENTION This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation. Read completely and understand the instructions prior to starting installation.

NOTE: Ciro products are designed and manufactured under very strict quality control. Ciro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a limited lifetime warranty against LED failure. Ciro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed, unmodified and maintained. Ciro will not be liable for any consequential and incidental damages, including labor, or non-Ciro products. Please visit Ciro3d.com for our complete warranty policy.



Installation Instructions:

1. Park motorcycle on a level surface and ensure engine has time to cool before beginning installation.

Right side install

- 2. Unscrew the top and bottom screws from switch housing and set aside front cover. Fig. 1
- 3. Loosen screws on brake clamp assembly to facilitate removal of the stock grip. Expand assembly enough to clear ridge on grip and pull off handlebar. Fig. 2
- 4. Note the throttle position sensor at the end of the bar, Fig. 3. which will engage with the Chicane™ grip when installed so rotate position of grip to your preference before engaging fully.
- 5. Ridge on the front collar of the grip must be inside switch housing assembly. Replace front plate on switch housing and tighten all screws securely. Fig. 4

ATTENTION Make sure that throttle grip moves freely and springs back to start position without any sticking.

Left Side Install

- 6. Repeat steps 2 and 3 above to remove left grip.
- 7. When installing grip note position of cam locks to secure grip in place and prevent rotation. No glue is required.
- 8. Replace front switch plate cover and tighten all screws securely.

















