

CON-1A and CON-1B Installation Instructions

Below is a drawing of the two cleats that are used to fasten the console to the deck. The screws used here are the largest screws (#14x2") along with washers. The other smaller screws you received (#12x1.5") along with washers are used to fasten the base of the console to the cleats.

