



HOVERBOARD LIGHT INDICATORS

ION HOVERBOARD


A SMARTER HOVERBOARD




The ION hoverboard features 2 indicator lights. On the **LEFT**, is a battery indicator, on the **RIGHT** is a pressure sensor.




BOTH lights will glow **BLUE** if the battery is charged and there is adequate weight/pressure on both sides.




LEFT light will glow **BLUE** with partial pressure, **RIGHT** light will remain unlit.



When the battery needs to be charged the **LEFT** LED will glow **RED** and beep.




The **RIGHT** indicator light will turn **RED** when the board is turned upside down/lifted from the ground.




The **RIGHT** indicator light will blink **ORANGE** while charging if switched on.

ECO HOVERBOARD


SELF-BALANCING HOVERBOARD



The ECO features a pressure sensor on the **LEFT**, and a battery indicator on the **RIGHT** which glows **GREEN** with adequate charge, **RED** when a charge is needed.




The **RIGHT** indicator light will blink **ORANGE** while charging if switched on. The board cannot function while charging.




BOTH indicator lights will glow **GREEN** when equal pressure is applied and hoverboard is powered on.

HOVERFLY XL


ALL-TERRAIN HOVERBOARD




The Hoverfly XL features 2 indicator lights. On the **LEFT**, is a pressure sensor, on the **RIGHT** is a battery indicator.




When the battery needs to be charged the **RIGHT** LED will blink **RED** and beep.




The **RIGHT** indicator light will blink **ORANGE** while charging.



RIGHT light will glow **GREEN** when hoverboard is adequately charged and no weight is on the board.




The **LEFT** indicator light will turn **RED** and start beeping when unequal pressure is detected.




BOTH will glow **GREEN** when equal pressure is applied.

GOTRAX SRX PRO


ALL-TERRAIN HOVERBOARD



The SRX PRO features 2 lights. The **LEFT** is a battery indicator, the **RIGHT** is a pressure sensor. If the **LEFT** light is **BLUE** the board is charged, **RED** indicates it needs a charge, **ORANGE** means the board is charging.




BOTH indicator lights will glow **BLUE** when there is equal weight/pressure on both footpads, and the board has an adequate charge.




The **RIGHT** indicator light will turn **RED** and start beeping when the board is turned on and partial pressure is detected or the board is turned all the way around.

GOTRAX SRX


LED HOVERBOARD WITH SPEAKERS



The SRX features 2 lights. The **LEFT** is a battery indicator, the **RIGHT** is a pressure sensor. If the **LEFT** light is **BLUE** the board is charged, **RED** indicates it needs a charge, **ORANGE** means the board is charging.



BOTH indicator lights will glow **BLUE** when there is equal weight/pressure on both footpads, and the board has an adequate charge.



The **RIGHT** indicator light will turn **RED** and start beeping when the board is turned on and partial pressure is detected or the board is turned all the way around.