



**GOTRAX**

**KART  
USER MANUAL**

# CONGRATULATIONS ON YOUR PURCHASE!


This user manual will help you assemble and operate your new Hoverfly Kart. Be sure to read **ALL OF THE INFORMATION** in this manual before using.

**NOTE TO ALL RIDERS UNDER 18 YEARS OF AGE:** It's very important that you get parental permission before riding your Hoverfly Kart.






## DON'T RIDE UNTIL YOU READ THIS:

 **ALWAYS** wear a helmet when riding your Hoverfly Kart.

 **Always** be aware of local road laws, and follow them.

 **Do not** use the Hoverfly Kart under the influence of drugs or alcohol.

 **Do not** ride under wet conditions. The hoverboard using the kart may slide from under your feet causing injury. Wet conditions may damage the electronics and void the warranty.



# WARNING MESSAGE

- 1. Abuse** - We do not cover physical damage due to negligent care and extreme riding.
- 2. Whenever you use the GOTRAX Hoverfly Kart**, you risk severe injury or even death from loss of control, collisions, and falls. Use caution and ride at your own risk.
- 3. Do not** modify the product from the manufacturers original design.
- 4. Keep** hands and all body parts away from moving parts while operating the hoverfly kart with a hoverboard.
- 5. Never** exceed the 220 lb (100 kg) maximum load rating.
- The Hoverfly Kart should **never** be used by children under the age of 8.



# UNPACK

You should find each of these items in your Hoverfly Kart box:



- ① Allen Key
- ② Hex Wrench
- ③ Fastener
- ④ Gasket 2 pcs
- ⑤ Spring 4pcs
- ⑥ M10 Locknut 2 pcs
- ⑦ M8 Locknut 4pcs
- ⑧ M8\*15 4pcs
- ⑨ Attachment System and Handles
- ⑩ Seat
- ⑪ Wheel Frame
- ⑫ Foot Plate Frame

Remove all packing material, then inspect each item for any accidental damage that may have occurred during shipping.



# ASSEMBLE YOUR HOVERFLY KART

Follow the below step-by-step instructions to properly assemble your HOVERFLY KART.

**WARNING:** Failure to properly attach, tighten, and secure all bolts, locknuts, screws, and fasteners will increase the risk of injury.

## 1. ATTACH THE HANDLEBARS

Attach the two handlebars (11) to the screw rods on either side of the Wheel Frame (11) plate using the Washers (4) and the M10 Locknuts (6).

- Put one large washer (4) on each screw rod.
- Put the handlebars (11) on the screw rods. Both handlebars (11) should point towards the wheel with the arms of the handlebars (11) extending outwards.
- Put one small washer (4) on each screw rod.
- Use the M10 Locknuts (6) on the screw rods and tighten until each handlebar is firmly secured on the screw rods.

## **2. SECURE THE SEAT**

Attach the HOVERFLY KART seat (10) to the Wheel Frame (11) plate using the M8\*15 bolts (8) and M8 Locknuts (7).

- Place the seat (10) in position and insert the bolts (8) so they go through both the seat (10) and the Wheel Frame (11) plate.
- Use the M10 Locknuts (6) on the bolts (8) and tighten with an Allen Key (1) and a Hex Wrench (2) until the seat (10) is firmly secured to the Wheel Frame (11) plate.

## **3. ADJUST THE WHEEL FRAME**

Adjust the length of the Wheel Frame (11) to fit your height.

- Secure with the Gasket (4)
- Tighten the Gasket (4) until it is firmly secured.

## **4. FASTEN THE HOVERFLY KART TO YOUR HOVERBOARD**

Use the velcro fastener straps to attach the HOVERFLY KART to your self-balancing scooter aka hoverboard.

- Make sure the hoverboard is facing the correct direction so that the HOVERFLY KART wheel will be in front.

# BOARDING PROCEDURES

**Before using the hoverboard, you must fully charge the battery.**


- Find a wide-open flat surface that is safe for go-karting.
- Sit in the GOTRAX HOVERFLY KART seat.
- **Check for any loose** or hanging articles of clothing that could interfere with **your ride**.

# RIDING TIPS

**Powering on:**

- While seated in the HOVERFLY KART, press the power button on the back of your hoverboard to turn it on.
- **Firmly hold** onto the handlebars with both hands.





Power Button

## Riding:

- Forward Acceleration: Gently push the handlebars slightly forward to accelerate.
- Speed Control: The **harder** you push, pull, or turn the handlebars, the faster you will go-kart.
- Slow to Stop: Gently pull the handlebars slightly back to slow to a stop.
- Reverse: **Gently** pull the handlebars back to **move backwards**.
- To Turn Right: **gently pull the right handlebar upwards and the left handlebar downwards.**
- To Turn Left: **gently pull the left handlebar upwards and the right handlebar downwards.**

# TROUBLESHOOTING

We frequently update our user manuals at **gotrax.com**, and reserve the rights to update and change manuals online.

**Please contact our customer service team if you are experiencing problems or need more detailed information. They can be reached at [gotrax.com](https://gotrax.com)**

# WARRANTY

This hoverboard is covered by a 90-day manufacturer's warranty that covers defects in workmanship and material. This does not cover misuse, neglect, abuse, accident, or water damage. For warranty claims and details, please visit **gotrax.com**. Always keep your original shipping box in case the hoverboard needs to be returned or repaired.

**GOTRAX**

**WWW.GOTRAX.COM**

**#RIDEGOTRAX**

