

# LOCATING THE SERIAL NUMBER, MODEL NUMBER AND RANGE(S) OF MY CHART RECORDER

To locate the Serial Number or Model Number on your recorder:

1. Gently lift up the lower right portion of your chart.
2. Underneath is a sticker which contains the following:

Serial Number  
Model Number  
Range(s)



Light Status	Solid Green - Recorder O.K. Flashing Green - Low Battery or Power Failure	
Change Chart	Push and Release Button #3, Wait for Pen to Park, Replace Chart, Push and Release Button #3	
Calibration	Push and Hold Button #1 or #2 Depending on Desired Direction	
Range Change	Push Button #3, Wait for Pen to Park, LED will Glow Steadily Push and Hold Button #1 for 6 sec., LED will Begin to Flash Flash Count = Chart Range Setting, Adjust with Button #1 or #2 Then Push and Release Button #3 to Save Your Selection	
Ranges:		
1. - 210 / -110°C	4. -17 / +38°C	SN:19-00136
2. - 100 / +38°C	5. 0 / +60°C	Model No. B6-XXX-CF-00-12Y0
3. - 40 / +60°C	6. 0 / +100°C	
		R18-212-23 Rev. A