Reinstalling & Removing the Potty Seat




Position potty seat (B) at a 45° angle between the lid and the adult seat. While pressing down on the adult seat near the hinge, pull potty seat (B) at an angle to detach.

To Reinstall

Raise the lid of the toilet seat and while holding the potty seat (B) at a 45° angle, push it at an angle onto the hinge until an audible click is heard.

Removing Quick Flip from Toilet



Hold all three seat pieces up at a 90° angle and pull upward until the seat is removed from the mounting pins.

To Reinstall, refer to STEP 6 of installation instructions.

WARNING:

CHOKING HAZARD:

- Keep small parts away from children during assembly and disassembly
- Ensure mounting covers are installed properly and check regularly to ensure they have not loosened.

FALL HAZARD:

- Adult supervision required. DO NOT allow child to use the product unattended.
- Always ensure assembly has not loosened or become damaged before each use.

ENTRAPMENT HAZARD:

- DO NOT allow child to place potty seat on or over their head.
- Store potty seat in a safe place out of the reach of children.

IMPORTANT:

- KEEP INSTRUCTIONS for future use. Adult assembly required.
- Wash and inspect before use. Discard and replace at first sign of weakness or damage.
- To prevent damage, DO NOT USE potty seat for children over 60 lbs (27.2kg). Remove, clean and store away from light and heat. Always inspect before reinstallation.

To Clean: Wipe surfaces with soap and water or mild cleaning detergent.

Maintenance: Check for loosening and tighten fasteners as needed.

Storage: Remove, clean and store away from light and heat. Always inspect before reinstallation.


PTY-2081-LNG

MANUFACTURER:


JOOL PRODUCTS LLC PO Box 1273 LAKEWOOD, NJ 08701 1-888-788-JOOL (5665) MADE IN CHINA




Included Parts:




TOOLS REQUIRED: Phillips screwdriver



Remove your current toilet seat.
Discard or store seat and loose parts.
CAUTION: Keep loose parts
away from children.




Place both screws (G) through slots in mounting discs (C), and through top of the holes on the toilet bowl.




Nuts (F)

Screws G


Insert the mounting grips (D) into the bottom of the mounting discs (C).




The screws (G) should now be protruding on the underside of the toilet. Fasten the nuts (F) onto the screws (G), leaving them a little loose for further adjustment.




Rotate the mounting disc (C) to find the right distance between two pins.




Holding the toilet seat (A) at a 90° angle, line up the holes on the hinge part of the seat with the pins on the mounting disc (C). If necessary, rotate the mounting disc (C) so the two pins are the correct distance apart. Attach the seat by sliding the holes over the pins.



Put the toilet seat and lid down. Do this carefully, as the fittings are still loose.



Adjust the toilet seat by moving it forward or backward to fit the front edge of your toilet bowl.



Tighten the screw (G) with a screwdriver while holding the nut (F) underneath with your other hand. Repeat for the other side.

IMPORTANT: To avoid damage to seat, DO NOT overtighten



Push and slide in the mounting covers (E) on to the bracket parts from the back.