





Insert dowels into frame. Tap in until fully inserted. Position Ladder Rungs onto dowels.







Attach the Brackets to Ladder Upright using guide holes.


















The Important Stuff.

Tighten all bolts after one month of use.

All beds should be checked periodically to ensure fasteners are tight.

In rooms with ceiling fans care must be taken to ensure distance between closest point is at least 2m.

Children should be discouraged from playing on bunks.

Upper bunk not suitable for children under the age of six.

ENJOY!

