BMW New Vehicle/Light Truck Limited Warranty – Emissions (Coverage Information for SULEV/PZEV Vehicles) Effective October 19, 2016

BMW New Vehicle/Light Truck Limited Warranty - Emissions Coverage	1
Federal Emissions Warranties	1
California Emission Control System Limited Warranties	1
California Emission States – SULEV (PZEV) Vehicles	3
California Emission States (DE, OR, PA, WA) – SULEV (PZEV) Specific Coverage	4
Determining California Emission Control System Limited Warranties Coverage	6
2003 BMW SULEV (PZEV) Parts List - M56 Vehicles	7
2004 BMW SULEV (PZEV) Parts List - M56 Vehicles	10
2005 BMW SULEV (PZEV) Parts List - M56 Vehicles	
2006 BMW SULEV (PZEV) Parts List - M56 Vehicles	14
2007 BMW SULEV (PZEV) Parts List - N51 Vehicles	16
2008 BMW SULEV (PZEV) Parts List - N51 Vehicles	
2009 BMW SULEV (PZEV) Parts List - N51 Vehicles	20
2010 BMW SULEV (PZEV) Parts List - N51 Vehicles	22
2011 BMW SULEV (PZEV) Parts List - N51 Vehicles	
2012 BMW SULEV (PZEV) Parts List - N51 Vehicles	
2012 BMW SULEV (PZEV) Parts List - N26 Vehicles	
2012 BMW SULEV (PZEV) Parts List - N51 Vehicles	
2013 BMW SULEV (PZEV) Parts List - N51 Vehicles	
2013 BMW SULEV (PZEV) Parts List - N26 Vehicles	
2014 BMW SULEV (PZEV) Parts List - N26 Vehicles	
2015 BMW SULEV (PZEV) Parts List - N26 Vehicles	
2016 BMW SULEV (PZEV) Parts List - N26 Vehicles	
2016 BMW SULEV (PZEV) Parts List - N26 Vehicles	45
2016 BMW SULEV (PZEV) Parts List - N26 Vehicles	
2016 BMW SULEV (PZEV) Parts List - B46 Vehicles	49
2017 BMW SULEV (PZEV) Parts List - B46 Vehicles	
2017 BMW SULEV (PZEV) Parts List - B46 Vehicles	
2017 BMW SULEV (PZEV) Parts List - B46 Vehicles	
2017 BMW SULEV (PZEV) Parts List - B46 Vehicles	60

BMW New Vehicle/Light Truck Limited Warranty - Emissions Coverage

All emissions-relevant components or systems are covered under the New Vehicle/Light Truck Limited Warranty for defects in materials or workmanship for a period of 4 years or 50,000 miles, whichever occurs first.

Federal Emissions Warranties

Gasoline, Diesel, ActiveHybrid Vehicles, i3 with Range Extender (REx), and the i8 (Plug-in Hybrid)

General

All emissions-relevant components or systems are covered under the Federal Emissions System Defect Warranty for defects in materials or workmanship for a period of 2 years or 24,000 miles, whichever occurs first.

Since the BMW New Vehicle/Light Truck Limited Warranty coverage exceeds the Federal Emissions System Defect Warranty period, all eligible repairs are claimable under the New Vehicle/Light Truck Limited Warranty period.

Specific-Components

Specific emission-related components are covered under the Federal Emissions System Defect Warranty for defects in materials or workmanship for a period of 8 years or 80,000 miles, whichever occurs first.

This coverage is limited to the:

Catalytic Converter(s)*, and the Engine Control Module (DME/DDE, including on-board diagnostic system).

*For diesel engines, this includes the Selective Catalytic Reduction (SCR) catalyst and Diesel Particulate Filter (DPF).

BMW i3 with Range Extender (REx)

The following component and/or system are covered under the Federal Emission Warranty for a period for a period of 15 years or 150,000 miles, whichever occurs first.

Auxiliary Power Unit (APU)

California Emission Control System Limited Warranties

Gasoline, Diesel, ActiveHybrid Vehicles, i3 with Range Extender (REx), and the i8 (Plug-in Hybrid)

Short-Term Emission Warranty Coverage (California Emission Control Warranty)

All emissions-relevant components or systems on all models are covered under the California Emission Control Warranty for defects in materials or workmanship for a period of 3 years or 50,000 miles, whichever occurs first.

Since the BMW New Vehicle/SAV Limited Warranty coverage exceeds the Federal Emissions System Defect Warranty period, all eligible repairs are claimable under the New Vehicle/SAV Limited Warranty period.

California Emission Control System Limited Warranties (Cont.)

2. Long-Term Emission Control Defects Warranty (California Emission Control System Limited Warranty)

Specific emission-related components are covered under the California Emission Control Warranty for defects in materials or workmanship for a period of 7 years or 70,000 miles, whichever occurs first.

Only high cost emission control components are covered by this warranty. The cost threshold is determined by the California Air Resource Board (CARB).

A complete list of the covered components for specific models is located in the specific vehicle's Service and Warranty Booklet or in this section of the manual.

3. Long-Term Emission Control Defects Warranty – Models Certified to Optional Standards (California Emission Control System Limited Warranty)

The California Air Resource Board (CARB), to address "fleet average" emissions, allows manufacturers to pursue an optional additional certification for specific models. This extends the Long-Term Emission Control Defects Warranty.

Specific emission-related components are covered under the optional additional certification for defects in materials or workmanship for a period of 8 years or 100,000 miles, whichever occurs first.

A list of the covered components for specific models is located in the vehicle's Service and Warranty Booklet.

Other States that have fully adopted these California Air Resource Board Statutes: Items #1 through #3

Participating States	Model Year(s)
Arizona	2012 Only
Connecticut	2008 and Newer
Maine	2001 and Newer
Maryland	2011 and Newer
Massachusetts	1995 and Newer
New Jersey	2009 and Newer
New Mexico	2011 Only
Oregon	2009 and Newer
Pennsylvania	2009 and Newer
Rhode Island	2008 and Newer
Vermont	2000 and Newer
Washington	2009 and Newer
New York	2016 and Newer

California Emission States – SULEV (PZEV) Vehicles

4. Super Ultra Low Emission Vehicles (SULEV) classified as Partial Zero Emission Vehicles (PZEV) (Engine Types: M56, N51, N26, B46) (California Emission Control Warranty)

All emissions-relevant components or systems on SULEV (PZEV) vehicles, in applicable states as noted below, are covered under the California Emission Control Warranty against defects in materials or workmanship for a period of 15 years or 150,000 miles, whichever occurs first.

Other States that have fully adopted the SULEV (PZEV) "State of California regulation" by Model Year

Participating States	Model Year(s)
Arizona	2012 Only
California	2003 and Newer
Connecticut	2007 and Newer
Maine	2003 and Newer
Maryland	2011 and Newer
Massachusetts	2003 and Newer
New Jersey	2008 and Newer
New Mexico	2011 Only
New York	2003 and Newer
Pennsylvania	2009 & 2010
Rhode Island	2008 and Newer
Vermont	2003 and Newer

Other States that have partially adopted the SULEV (PZEV) "State of California regulation" by Model Year

Delaware	2014 and Newer
Oregon	2008 and Newer
Pennsylvania	2011 and Newer
Washington	2008 and Newer

Refer to the <u>California Emission States (DE, OR, PA, WA) – SULEV (PZEV)</u> Specific Coverage section of this manual that follows for more information.

California Emission States (DE, OR, PA, WA) – SULEV (PZEV) Specific Coverage

Delaware

2014 Model Year and Newer

- Eligible SULEV (PZEV) cars registered in the state Delaware do not receive the extended SULEV (PZEV) warranty coverage.
- All eligible registered vehicles are covered by the California Emission Control Warranty (3/50, 7/70 or 8/100, if applicable).

Oregon

2008 Model Year

- Only 2008 MY SULEV (PZEV) cars registered in the State of Oregon are covered by the California Emission Control Warranty (3/50 and 7/70), but not the extended SULEV (PZEV) warranty.
- The Federal Emission Warranty applies to all the other 2008 MY non-SULEV (PZEV) models.

2009 Model Year and Newer

- Eligible SULEV (PZEV) cars registered in the State of Oregon are covered by the California Emission Warranty (3/50 and 7/70 or 8/100 if applicable), but not the extended SULEV (PZEV) warranty.
- The California Emission Control Warranty (3/50, 7/70 or 8/100, if applicable) applies to all the other eligible registered non-SULEV models.

Pennsylvania

2009 & 2010 Model Year

All emissions-relevant components or systems on SULEV (PZEV) vehicles are covered under the California Emission Control Warranty against defects in materials or workmanship for a period of 15 years or 150,000 miles, whichever occurs first.

2011 Model Year and Newer

- Eligible SULEV (PZEV) cars registered in the Commonwealth of Pennsylvania <u>do not</u> receive the extended SULEV (PZEV) warranty coverage.
- All eligible registered vehicles are covered by the California Emission Control Warranty (3/50, 7/70 or 8/100, if applicable).

Washington State

2008 Model Year

- SULEV (PZEV) cars registered in the State of Washington are covered by the California Emission Control System Limited Warranty (3/50, 7/70 or 8/100 if applicable), but not the extended SULEV (PZEV) warranty.
- The Federal Emission Warranty applies to all other 2008 MY non-SULEV (PZEV) models.

2009 Model Year and Newer

- SULEV (PZEV) cars registered in the State of Washington are covered by the California Emission Control System Limited Warranty (3/50, 7/70 or 8/100 if applicable), but not the extended SULEV (PZEV) warranty.
- All eligible registered vehicles are covered by the California Emission Control Warranty (3/50, 7/70 or 8/100, if applicable).

Determining California Emission Control System Limited Warranties Coverage

To determine if a vehicle is eligible for the California Emission Control System Limited Warranties coverage, the following three items must be taken into consideration:

- Model year of the vehicle
- Current state where the vehicle is registered
- Original state where vehicle was retailed (only for vehicles prior to 2011 model year)

The California Emission Control System Limited Warranties was originally established in California, hence the name, by the California Air Resource Board (CARB). Over time, several other states have adopted all or some of the California statutes; therefore, eligible vehicles of these other states are entitled to all or some portion of this warranty.

Model Year

Although a vehicle's emission coverage "start time" is based on the retail date, the Model Year is a major factor for determining the specific emission warranty coverage.

When a vehicle is sold, it is sold with the specific warranty coverage as outlined in the Service and Warranty Booklet. The coverage varies, based on the Model Year of the vehicle.

Vehicle Registration and Original Retail State

The California Emission Control System Limited Warranty applies to a vehicle that is registered in a CARB compliant state. BMW vehicles not initially retailed, leased or currently registered in one of these "CARB compliant states" are not eligible for this coverage.

The California Emission Control System Limited Warranty applies to a vehicle that is <u>registered</u> in a CARB compliant state, regardless of the original retail state, <u>when the model year applies</u>.

Emission Coverage - 2011 Model Year and Newer BMW Vehicles

The statement in the Service and Warranty Booklet is:

The California Emission Control System Limited Warranty applies to all [applicable model year] U.S.-specification BMW [models] **registered in** [specific states - list].

Emission Coverage - BMW Vehicles up to and including 2010 Model Year

The statement in the Service and Warranty Booklet is:

The California Emission Control System Limited Warranty applies to all [applicable model year] U.S.-specification BMW vehicles **sold**, **leased**, **and/or registered** in [specific states - list].

2003 BMW SULEV (PZEV) Parts List - M56 Vehicles

2003 BMW Emissions Related Parts List
Model = 328i Sedan, Coupe and Wagon
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY
LIST OF EIVISSIONS PARTS SUBSECT TO PZEV WARRANTT
Part Name
OIL FILLED CAD
OIL FILLER CAP CYLINDER HEAD COVER GASKET
GASKET, CYL. HEAD COVER
CRANKCASE VENT HOSE
SOLENOID VALVE (VANOS UNIT)
VANOS UNIT
DIPSTICK
O-RING, DIPSTICK
THERMOSTAT W/HOUSING
NON-RETURN VALVE (SECONDARY AIR, VACUUM)
GASKET, IDLE CONTROL VALVE
INTAKE RUNNER ADJUSTER UNIT
VACUUM HOSE ASSEMBLY
INTAKE MANIFOLD
INTAKE MANIFOLD GASKET
EXHAUST MANIFOLD GASKET
MASS AIR FLOW SENSOR (SAS)
PRESSURE HOSE ASSEMBLY (SAS)
SUCTION HOSE (SAS)
SECONDARY AIR PUMP
VALVE (SECONDARY AIR PUMP)
VACUUM HOSE
VACUUM PIPE
SOLENOID VALVE (SECONDARY AIR)
HEATED OXYGEN SENSOR, MONITORING
HEATED OXYGEN SENSOR, REGULATING
IGNITION COIL
KNOCK SENSOR
PULSE GENERATOR, CAMSHAFT
PULSE GENERATOR, CRANKSHAFT
O-RING (FOR PULSE GENERATOR)
BASIC DME UNIT, MS45.1

2003 BMW Emissions Related Parts List
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY
Part Name
OIL PRESSURE SWITCH
IDLE REGULATING VALVE
FUEL RAIL
INJECTION VALVE
INTAKE AIR HOSE
PROFILE GASKET
THROTTLE HOUSING ASSEMBLY
ENGINE COOLANT TEMPERATURE SENSOR
TEMPERATURE SENSOR (LUBE OIL)
TEMPERATURE SENSOR, RADIATOR OUTLET
MASS AIR FLOW SENSOR
O-RING (FOR INJECTION VALVE)
PURGE VALVE
FUEL TANK BREATHER LINE
FUEL FILLER CAP
VENT PIPE, DUST FILTER
VENT PIPE
FUEL TANK WITH FILLER NECK
CARBON CANISTER, METAL
VENT PIPE
FUEL FEED LINE
SCAVENGING LINE FRONT
VENT PIPE
LEAK DIAGNOSTIC PUMP
DUST FILTER
SCAVENGING LINE REAR
CONTROL MODULE FOR FUEL PUMP
COOLING UNIT INCL. DOR SYSTEM
EXHAUST PIPE GASKET
CATALYTIC CONVERTER
EXHAUST MANIFOLD WITH CATALYST
TRANSMISSION SPEED SENSOR
TRANSMISSION SOLENOID VALVE
WIRING HARNESS WITH TEMPERATURE SENSOR
TRANSMISSION SPEED SENSOR
TRANSMISSION CONTROL UNIT SET
TORQUE CONVERTER

2003 BMW Emissions Related Parts List
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY
Part Name
CONTROL UNIT, EGS, PROGRAMMED
ACCELERATOR PEDAL MODULE, AUTOMATIC

2004 BMW SULEV (PZEV) Parts List - M56 Vehicles

2004 BMW Emissions Related Parts List	
Model = 328i Sedan, Coupe and Wagon	
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY	
Part Name	
OIL FILLER CAP	
CYLINDER HEAD COVER GASKET	
GASKET, CYL. HEAD COVER	
CRANKCASE VENT HOSE	
SOLENOID VALVE (VANOS UNIT)	
VANOS UNIT	
DIPSTICK	
O-RING, DIPSTICK	
THERMOSTAT W/HOUSING	
NON-RETURN VALVE (SECONDARY AIR, VACUUM)	
GASKET, IDLE CONTROL VALVE	
INTAKE RUNNER ADJUSTER UNIT	
VACUUM HOSE ASSEMBLY	
INTAKE MANIFOLD	
INTAKE MANIFOLD GASKET	
EXHAUST MANIFOLD GASKET	
MASS AIR FLOW SENSOR (SAS)	
PRESSURE HOSE ASSEMBLY (SAS)	
SUCTION HOSE (SAS)	
SECONDARY AIR PUMP	
VALVE (SECONDARY AIR PUMP)	
VACUUMHOSE	
VACUUM PIPE	
SOLENOID VALVE (SECONDARY AIR)	
HEATED OXYGEN SENSOR, MONITORING	
HEATED OXYGEN SENSOR, REGULATING	
IGNITION COIL	
KNOCKSENSOR	
PULSE GENERATOR, CAMSHAFT	
PULSE GENERATOR, CRANKSHAFT	
O-RING (FOR PULSE GENERATOR)	
BASIC DME UNIT, MS45.1	
PROGRAMMED DME UNIT, MS45.1	
BASIC DME UNIT, MS45.1	
OIL PRESSURE SWITCH	
IDLE REGULATING VALVE	
FUEL RAIL	
INJECTION VALVE	
INTAKE AIR HOSE	
PROFILE GASKET	
THROTTLE HOUSING ASSEMBLY	
ENGINE COOLANT TEMPERATURE SENSOR	
TEMPERATURE SENSOR (LUBE OIL)	
TEMPERATURE SENSOR, RADIATOR OUTLET	

2004 BMW Emissions Related Parts List
Model = 328i Sedan, Coupe and Wagon
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY
Part Name
PURGE VALVE
FUEL TANK BREATHER LINE
FUEL FILLER CAP
VENT PIPE, DUST FILTER
VENT PIPE
FUEL TANK WITH FILLER NECK
CARBON CANISTER, METAL
VENT PIPE
FUEL FEED LINE
SCAVENGING LINE FRONT
VENT PIPE
LEAK DIAGNOSTIC PUMP
DUST FILTER
SCAVENGING LINE REAR
CONTROL MODULE FOR FUEL PUMP
COOLING UNIT INCL. DOR SYSTEM
EXHAUST PIPE GASKET
CATALYTIC CONVERTER
EXHAUST MANIFOLD WITH CATALYST
TRANSMISSION SPEED SENSOR
TRANSMISSION SOLENOID VALVE
WIRING HARNESS WITH TEMPERATURE SENSOR
TRANSMISSION SPEED SENSOR
TRANSMISSION CONTROL UNIT SET
TORQUE CONVERTER CONTROL UNIT, EGS, BASIC
CONTROL UNIT, EGS, BASIC CONTROL UNIT, EGS, PROGRAMMED
ACCELERATOR PEDAL MODULE, AUTOMATIC
ACCELERATOR PEDAL MODULE, AUTOMATIC

2005 BMW SULEV (PZEV) Parts List - M56 Vehicles

2005 BMW Emissions Related Parts List
Model = 328i Sedan, Coupe and Wagon
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY
Part Name
OIL FILLER CAP
CYLINDER HEAD COVER GASKET
GASKET, CYL. HEAD COVER
CRANKCASE VENT HOSE
SOLENOID VALVE (VANOS UNIT)
VANOS UNIT DIPSTICK
O-RING, DIPSTICK
THERMOSTAT W/HOUSING
NON-RETURN VALVE (SECONDARY AIR, VACUUM)
GASKET, IDLE CONTROL VALVE
INTAKE RUNNER ADJUSTER UNIT
VACUUM HOSE ASSEMBLY
INTAKEMANIFOLD
INTAKE MANIFOLD GASKET
EXHAUST MANIFOLD GASKET
MASS AIR FLOW SENSOR (SAS)
PRESSURE HOSE ASSEMBLY (SAS)
SUCTION HOSE (SAS)
SECONDARY AIR PUMP
VALVE (SECONDARY AIR PUMP)
VACUUMHOSE
VACUUM PIPE
SOLENOID VALVE (SECONDARY AIR)
HEATED OXYGEN SENSOR, MONITORING
HEATED OXYGEN SENSOR, REGULATING
IGNITION COIL
KNOCK SENSOR
PULSE GENERATOR, CAMSHAFT
PULSE GENERATOR, CRANKSHAFT
O-RING (FOR PULSE GENERATOR)
BASIC DME UNIT, MS45.1
PROGRAMMED DME UNIT, MS45.1

2005 BMW Emissions Related Parts List
Model = 328i Sedan, Coupe and Wagon
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY
Part Name
PROGRAMMED DME UNIT, MS45.1
OIL PRESSURE SWITCH
IDLE REGULATING VALVE
FUEL RAIL
INJECTION VALVE
INTAKE AIR HOSE
PROFILE GASKET
THROTTLE HOUSING ASSEMBLY
ENGINE COOLANT TEMPERATURE SENSOR
TEMPERATURE SENSOR (LUBE OIL)
TEMPERATURE SENSOR, RADIATOR OUTLET
MASS AIR FLOW SENSOR
O-RING (FOR INJECTION VALVE)
PURGEVALVE
FUEL TANK BREATHER LINE
FUEL FILLER CAP
VENT PIPE, DUST FILTER
VENT PIPE
FUEL TANK WITH FILLER NECK
CARBON CANISTER, METAL
VENT PIPE
FUEL FEED LINE
SCAVENGING LINE FRONT
VENT PIPE
LEAK DIAGNOSTIC PUMP
DUST FILTER
SCAVENGING LINE REAR
CONTROL MODULE FOR FUEL PUMP
COOLING UNIT INCL. DOR SYSTEM
EXHAUST PIPE GASKET
CATALYTIC CONVERTER
EXHAUST MANIFOLD WITH CATALYST
TRANSMISSION SPEED SENSOR
TRANSMISSION SOLENOID VALVE
WIRING HARNESS WITH TEMPERATURE SENSOR
TRANSMISSION SPEED SENSOR
TRANSMISSION CONTROL UNIT SET
TORQUE CONVERTER
CONTROL UNIT, EGS, BASIC
CONTROL UNIT, EGS, PROGRAMMED
ACCELERATOR PEDAL MODULE, AUTOMATIC

2006 BMW SULEV (PZEV) Parts List - M56 Vehicles

2006 BMW Emissions Related Parts List
Model = 328i Coupe
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY
Part Name
T distributio
OIL FILLER CAP
CYLINDER HEAD COVER GASKET
GASKET, CYL. HEAD COVER
CRANKCASE VENT HOSE
SOLENOID VALVE (VANOS UNIT)
VANOS UNIT
DIPSTICK
O-RING, DIPSTICK THERMOSTAT W/HOUSING
NON-RETURN VALVE (SECONDARY AIR, VACUUM)
GASKET, IDLE CONTROL VALVE
INTAKE RUNNER ADJUSTER UNIT
VACUUM HOSE ASSEMBLY
INTAKE MANIFOLD
INTAKE MANIFOLD GASKET
EXHAUST MANIFOLD GASKET
MASS AIR FLOW SENSOR (SAS)
PRESSURE HOSE ASSEMBLY (SAS)
SUCTION HOSE (SAS)
SECONDARY AIR PUMP
VALVE (SECONDARY AIR PUMP)
VACUUMHOSE
VACUUM PIPE
SOLENOID VALVE (SECONDARY AIR) HEATED OXYGEN SENSOR, MONITORING
HEATED OXYGEN SENSOR, MONITORING HEATED OXYGEN SENSOR, REGULATING
IGNITION COIL
KNOCKSENSOR
PULSE GENERATOR, CAMSHAFT
PULSE GENERATOR, CRANKSHAFT
O-RING (FOR PULSE GENERATOR)
BASIC DME UNIT, MS45.1
PROGRAMMED DME UNIT, MS45.1
OIL PRESSURE SWITCH
IDLE REGULATING VALVE
FUEL RAIL
INJECTION VALVE
INTAKE AIR HOSE
PROFILE GASKET
THROTTLE HOUSING ASSEMBLY
ENGINE COOLANT TEMPERATURE SENSOR TEMPERATURE SENSOR (LUBE OIL)
I LIVIF LIVA I ONE SENSON (LODE OIL)

2006 BMW Emissions Related Parts List		
Model = 328i Coupe		
·		
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY		
Part Name		
FUEL TANK BREATHER LINE		
FUEL FILLER CAP		
VENT PIPE, DUST FILTER VENT PIPE		
FUEL TANK WITH FILLER NECK		
CARBON CANISTER, METAL		
VENT PIPE		
FUEL FEED LINE		
SCAVENGING LINE FRONT		
VENT PIPE		
LEAK DIAGNOSTIC PUMP		
DUST FILTER		
SCAVENGING LINE REAR		
CONTROL MODULE FOR FUEL PUMP		
COOLING UNIT INCL. DOR SYSTEM		
EXHAUST PIPE GASKET		
CATALYTIC CONVERTER		
EXHAUST MANIFOLD WITH CATALYST		
TRANSMISSION SPEED SENSOR		
TRANSMISSION SOLENOID VALVE		
WIRING HARNESS WITH TEMPERATURE SENSOR		
TRANSMISSION SPEED SENSOR		
TRANSMISSION CONTROL UNIT SET		
TORQUE CONVERTER		
CONTROL UNIT, EGS, BASIC CONTROL UNIT, EGS, PROGRAMMED		
ACCELERATOR PEDAL MODULE, AUTOMATIC		
ACCELLINATORY EDALINODULE, ACTOMATIC		

2007 BMW Emissions Related Parts List
Model = 328i
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY
LIOT OF EMISSIONST ARTOCODOEST TO FZEV WARRANTT
Part Name
GASKET, VALVETRONIC ACTUATOR
OIL FILLER CAP
VALVE COVER GASKET SET
VACUUM PIPE
VENT HOSE
ADJUSTMENT UNIT, INTAKE CAMSHAFT SOLENOID VALVE
ADJUSTMENT UNIT, EXHAUST CAMSHAFT VALVETRONIC SENSOR
VALVETRONIC SENSOR VALVETRONIC ACTUATOR
THERMOSTAT
SET INTAKE MANIFOLD GASKET
INTAKE MANIFOLD
INTAKE MANIFOLD ADJUSTER (REAR)
INTAKE MANIFOLD ADJUSTER (FRONT)
ANGLE CONNECTOR
INTAKE MANIFOLD ADJUSTER (REAR)
SAS VALVE GASKET
SECONDARY AIR PUMP
SUCTION HOSE, SAS
SAS VALVE
PRESSURE HOSE, SAS
HEATED REAR OXYGEN SENSOR
HEATED FRONT OXYGEN SENSOR
IGNITION COIL
O-RING, CAMSHAFT SENSOR
ENGINE CONTROL MODULE
OIL PRESSURE SENSOR
CAP
INJECTION VALVE
FUEL RAIL
THROTTLE BODY GASKET
THROTTLEBODY
ENGINE COOLANT TEMP SENSOR
RADIATOR COOLANT TEMPERATURE SENSOR
DIFFERENTIAL PRESSURE SENSOR O-RING
CAMSHAFT SENSOR
CRANKSHAFT POSITION/RPM SENSOR
DIFFERENTIAL PRESSURE SENSOR
MASS AIR FLOW SENSOR
KNOCK SENSOR
INJECTION VALVE O-RING

2007 BMW Emissions Related Parts List	
Model = 328i	
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY	
Part Name	
REPAIR KIT FOR FLANGE COVER	
REPAIR KIT FOR FUEL TANK @ FILLER FLAP	
REPAIR KIT FOR FUEL TANK FILLER FLAP	
FUEL FILLER NECK	
FUEL FEED LINE	
FUEL LINE (UNDERBODY)	
SEAL, CANISTER-TO-LDP	
DUST FILTER, LDP SCAVENGE LINE	
VENT LINE (FILLER NECK-TO-TANK)	
LEAK DIAGNOSTIC PUMP	
EVAPORATIVE CANISTER	
FUEL PUMP CONTROL UNIT	
DELIVERY UNIT, RIGHT	
FUEL PUMP CONTROL UNIT	
RADIATOR W/DORS (AUTOMATIC TRANS)	
RADIATOR W/DORS (MANUAL TRANS)	
EXHAUST PIPE GASKET	
EXHAUST PIPE WITH CATALYST	
EXHAUST MANIFOLD GASKET	
EXHAUST MANIFOLD WITH CATALYST	
TORQUECONVERTER	
TRANSMISSION CONTROL MODULE, MECHATRONIK	
GAS PEDAL MODULE (AUTOMATIC)	
GAS PEDAL MODULE (MANUAL)	

2008 BMW Emissions Related Parts List	
Model = 128i	Model = 328i
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY	LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY
Part Name	Part Name
GASKET, VALVETRONIC ACTUATOR	GASKET, VALVETRONIC ACTUATOR
OIL FILLER CAP	OIL FILLER CAP
VALVE COVER GASKET SET	VALVE COVER GASKET SET
VACUUM PIPE	VACUUM PIPE
VENT HOSE	VENT HOSE
ADJUSTMENT UNIT, INTAKE CAMSHAFT	ADJUSTMENT UNIT, INTAKE CAMSHAFT
SOLENOID VALVE	SOLENOID VALVE
ADJUSTMENT UNIT, EXHAUST CAMSHAFT	ADJUSTMENT UNIT, EXHAUST CAMSHAFT
SOLENOID VALVE	VALVETRONIC SENSOR
VALVETRONIC SENSOR	VALVETRONIC ACTUATOR
VALVETRONIC ACTUATOR	THERMOSTAT
THERMOSTAT	SET INTAKE MANIFOLD GASKET
SET INTAKE MANIFOLD GASKET	INTAKE MANIFOLD
INTAKE MANIFOLD	INTAKE MANIFOLD ADJUSTER (REAR)
INTAKE MANIFOLD ADJUSTER (REAR)	INTAKE MANIFOLD ADJUSTER (FRONT)
INTAKE MANIFOLD ADJUSTER (FRONT)	ANGLE CONNECTOR
ANGLE CONNECTOR	INTAKE MANIFOLD ADJUSTER (REAR)
INTAKE MANIFOLD ADJUSTER (REAR)	SAS VALVE GASKET
SAS VALVE GASKET	SECONDARY AIR PUMP
SECONDARY AIR PUMP	SUCTION HOSE, SAS
SUCTION HOSE, SAS	SAS VALVE
SAS VALVE	PRESSURE HOSE, SAS
PRESSURE HOSE, SAS	HEATED REAR OXYGEN SENSOR
HEATED REAR OXYGEN SENSOR	HEATED FRONT OXYGEN SENSOR
HEATED FRONT OXYGEN SENSOR	IGNITION COIL
IGNITION COIL	O-RING, CAMSHAFT SENSOR
O-RING, CAMSHAFT SENSOR	ENGINE CONTROL MODULE
ENGINE CONTROL MODULE	OIL PRESSURE SENSOR
OIL PRESSURE SENSOR	CAP
CAP	INJECTION VALVE
FUEL RAIL	FUEL RAIL
INJECTION VALVE	THROTTLE BODY GASKET
THROTTLE BODY GASKET	THROTTLE BODY
THROTTLE BODY	ENGINE COOLANT TEMP SENSOR
ENGINE COOLANT TEMP SENSOR	RADIATOR COOLANT TEMPERATURE SENSOR
RADIATOR COOLANT TEMPERATURE SENSOR	DIFFERENTIAL PRESSURE SENSOR O-RING
DIFFERENTIAL PRESSURE SENSOR O-RING	CAMSHAFT SENSOR
CAMSHAFT SENSOR	CRANKSHAFT POSITION/RPM SENSOR
CRANKSHAFT POSITION/RPM SENSOR	DIFFERENTIAL PRESSURE SENSOR
DIFFERENTIAL PRESSURE SENSOR	MASS AIR FLOW SENSOR

2008 BMW Emissions Related Parts List	
Model = 128i	Model = 328i
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY	LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY
Part Name	Part Name
MASS AIR FLOW SENSOR	KNOCK SENSOR
KNOCK SENSOR	INJECTION VALVE O-RING
INJECTION VALVE O-RING	RUBBER BOOT (INTAKE AIR DUCT)
RUBBER BOOT (INTAKE AIR DUCT)	CONNECTOR (INTAKE AIR DUCT)
CONNECTOR (INTAKE AIR DUCT)	PURGE VALVE
PURGE VALVE	FUEL FILLER CAP
FUEL FILLER CAP	FUEL TANK
SERVICE LID FOR FUEL TANK, RIGHT	SERVICE LID FOR FUEL TANK, RIGHT
FUEL TANK	REPAIR KIT FOR FLANGE COVER
REPAIR KIT FOR FLANGE COVER	REPAIR KIT FOR FUEL TANK @ FILLER FLAP
REPAIR KIT FOR FUEL TANK @ FILLER FLAP	REPAIR KIT FOR FUEL TANK FILLER FLAP
REPAIR KIT FOR FUEL TANK FILLER FLAP	FUEL FILLER NECK
FUEL FILLER NECK	FUEL FEED LINE
FUEL LINE (UNDERBODY)	FUEL LINE (UNDERBODY)
FUEL FEED LINE	SEAL, CANISTER-TO-LDP
SEAL, CANISTER-TO-LDP	DUST FILTER, LDP
DUST FILTER, LDP	SCAVENGE LINE
VENT LINE (FILLER NECK-TO-TANK)	VENT LINE (FILLER NECK-TO-TANK)
VENT PIPE (FILLER NECK-TO-CANISTER)	LEAK DIAGNOSTIC PUMP
LEAK DIAGNOSTIC PUMP	EVAPORATIVE CANISTER
SCAVENGE LINE	FUEL PUMP CONTROL UNIT
EVAPORATIVE CANISTER	DELIVERY UNIT, RIGHT
FUEL PUMP CONTROL UNIT	FUEL PUMP CONTROL UNIT
DELIVERY UNIT, RIGHT	RADIATOR W/DORS (AUTOMATIC TRANS)
FUEL PUMP CONTROL UNIT	RADIATOR W/DORS (MANUAL TRANS)
RADIATOR W/DORS (AUTOMATIC TRANS)	EXHAUST PIPE GASKET
RADIATOR W/DORS (MANUAL TRANS)	EXHAUST PIPE WITH CATALYST
EXHAUST PIPE GASKET	EXHAUST MANIFOLD GASKET
EXHAUST PIPE WITH CATALYST	EXHAUST MANIFOLD WITH CATALYST
EXHAUST MANIFOLD GASKET	TORQUE CONVERTER
EXHAUST MANIFOLD WITH CATALYST	TRANS. CONTROL MODULE, MECHATRONIK
TORQUE CONVERTER	GAS PEDAL MODULE (AUTOMATIC)
TRANSMISSION CONTROL MODULE, MECHATRONIK	GAS PEDAL MODULE (MANUAL)
GAS PEDAL MODULE (AUTOMATIC)	
GAS PEDAL MODULE (MANUAL)	

KNOCK SENSOR

2009 BMW Emissions Related Parts List Model = 128i Model = 328i LIST OF EMISSIONS PARTS SUBJECT TO PZEV LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY WARRANTY **Part Name Part Name** GASKET, VALVETRONIC ACTUATOR GASKET, VALVETRONIC ACTUATOR OIL FILLER CAP OIL FILLER CAP VALVE COVER GASKET SET VALVE COVER GASKET SET **VACUUM PIPE** VACUUM PIPE VENT HOSE VENT HOSE ADJUSTMENT UNIT, INTAKE CAMSHAFT ADJUSTMENT UNIT, INTAKE CAMSHAFT SOLENOID VALVE SOLENOID VALVE ADJUSTMENT UNIT, EXHAUST CAMSHAFT ADJUSTMENT UNIT, EXHAUST CAMSHAFT **SOLENOID VALVE** VALVETRONIC SENSOR VALVETRONIC ACTUATOR VALVETRONIC SENSOR VALVETRONIC ACTUATOR **THERMOSTAT** THERMOSTAT SET INTAKE MANIFOLD GASKET SET INTAKE MANIFOLD GASKET INTAKE MANIFOLD INTAKE MANIFOLD INTAKE MANIFOLD ADJUSTER (REAR) INTAKE MANIFOLD ADJUSTER (REAR) INTAKE MANIFOLD ADJUSTER (FRONT) INTAKE MANIFOLD ADJUSTER (FRONT) ANGLE CONNECTOR ANGLE CONNECTOR INTAKE MANIFOLD ADJUSTER (REAR) INTAKE MANIFOLD ADJUSTER (REAR) SAS VALVE GASKET SECONDARY AIR PUMP SAS VALVE GASKET SECONDARY AIR PUMP SUCTION HOSE, SAS SUCTION HOSE, SAS SAS VALVE SAS VALVE PRESSURE HOSE, SAS PRESSURE HOSE, SAS HEATED REAR OXYGEN SENSOR HEATED REAR OXYGEN SENSOR HEATED FRONT OXYGEN SENSOR HEATED FRONT OXYGEN SENSOR **IGNITION COIL IGNITION COIL** O-RING, CAMSHAFT SENSOR O-RING, CAMSHAFT SENSOR **ENGINE CONTROL MODULE ENGINE CONTROL MODULE** OIL PRESSURE SENSOR OIL PRESSURE SENSOR CAP CAP INJECTION VALVE **FUEL RAIL FUEL RAIL** INJECTION VALVE THROTTLE BODY GASKET THROTTLE BODY GASKET THROTTLE BODY THROTTLE BODY **ENGINE COOLANT TEMP SENSOR** ENGINE COOLANT TEMP SENSOR RADIATOR COOLANT TEMPERATURE SENSOR RADIATOR COOLANT TEMPERATURE SENSOR DIFFERENTIAL PRESSURE SENSOR O-RING DIFFERENTIAL PRESSURE SENSOR O-RING CAMSHAFT SENSOR **CAMSHAFT SENSOR** CRANKSHAFT POSITION/RPM SENSOR CRANKSHAFT POSITION/RPM SENSOR DIFFERENTIAL PRESSURE SENSOR DIFFERENTIAL PRESSURE SENSOR MASS AIR FLOW SENSOR MASS AIR FLOW SENSOR KNOCK SENSOR

INJECTION VALVE O-RING

2009 BMW Emiss	ions Related Parts List
Model = 128i	Model = 328i
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY	LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY
Part Name	Part Name
INJECTION VALVE O-RING	RUBBER BOOT (INTAKE AIR DUCT)
RUBBER BOOT (INTAKE AIR DUCT)	CONNECTOR (INTAKE AIR DUCT)
CONNECTOR (INTAKE AIR DUCT)	PURGE VALVE
PURGE VALVE	FUEL FILLER CAP
FUEL FILLER CAP	FUEL TANK
SERVICE LID FOR FUEL TANK, RIGHT	SERVICE LID FOR FUEL TANK, RIGHT
FUEL TANK	REPAIR KIT FOR FLANGE COVER
REPAIR KIT FOR FLANGE COVER	REPAIR KIT FOR FUEL TANK @ FILLER FLAP
REPAIR KIT FOR FUEL TANK @ FILLER FLAP	REPAIR KIT FOR FUEL TANK FILLER FLAP
REPAIR KIT FOR FUEL TANK FILLER FLAP	FUEL FILLER NECK
FUEL FILLER NECK	FUEL FEED LINE
FUEL LINE (UNDERBODY)	FUEL LINE (UNDERBODY)
FUEL FEED LINE	SEAL, CANISTER-TO-LDP
SEAL, CANISTER-TO-LDP	DUST FILTER, LDP
DUST FILTER, LDP	SCAVENGE LINE
VENT LINE (FILLER NECK-TO-TANK)	VENT LINE (FILLER NECK-TO-TANK)
VENT PIPE (FILLER NECK-TO-CANISTER)	LEAK DIAGNOSTIC PUMP
LEAK DIAGNOSTIC PUMP	EVAPORATIVE CANISTER
SCAVENGE LINE	FUEL PUMP CONTROL UNIT
EVAPORATIVE CANISTER	DELIVERY UNIT, RIGHT
FUEL PUMP CONTROL UNIT	FUEL PUMP CONTROL UNIT
DELIVERY UNIT, RIGHT	RADIATOR W/DORS (AUTOMATIC TRANS)
FUEL PUMP CONTROL UNIT	RADIATOR W/DORS (MANUAL TRANS)
RADIATOR W/DORS (AUTOMATIC TRANS)	EXHAUST PIPE GASKET
RADIATOR W/DORS (MANUAL TRANS)	EXHAUST PIPE WITH CATALYST
EXHAUST PIPE GASKET	EXHAUST MANIFOLD GASKET
EXHAUST PIPE WITH CATALYST	EXHAUST MANIFOLD WITH CATALYST
EXHAUST MANIFOLD GASKET	TORQUE CONVERTER
EXHAUST MANIFOLD WITH CATALYST	TRANS. CONTROL MODULE, MECHATRONIK
TORQUE CONVERTER	GAS PEDAL MODULE (AUTOMATIC)
TRANS. CONTROL MODULE, MECHATRONIK	GAS PEDAL MODULE (MANUAL)
GAS PEDAL MODULE (AUTOMATIC)	
GAS PEDAL MODULE (MANUAL)	

2010 BMW Emissions Related Parts List	
Model = 128i Series	Model = 328i Series
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY	LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY
Part Name	Part Name
GASKET, VALVETRONIC ACTUATOR	GASKET, VALVETRONIC ACTUATOR
OIL FILLER CAP	OIL FILLER CAP
CYLINDER HEAD COVER GASKET	CYLINDER HEAD COVER GASKET
VACUUM PIPE	VACUUM PIPE
VENT HOSE	VENT HOSE
ADJUSTMENT UNIT, INTAKE CAMSHAFT	ADJUSTMENT UNIT, INTAKE CAMSHAFT
SOLENOID VALVE	SOLENOID VALVE
ADJUSTMENT UNIT, EXHAUST CAMSHAFT	ADJUSTMENT UNIT, EXHAUST CAMSHAFT
SOLENOID VALVE	SOLENOID VALVE
VALVETRONIC SENSOR	VALVETRONIC SENSOR
VALVETRONIC ACTUATOR	VALVETRONIC ACTUATOR
THERMOSTAT	THERMOSTAT
O-RING, ANGLE CONNECTOR	O-RING, ANGLE CONNECTOR
SET INTAKE MANIFOLD GASKET	SET INTAKE MANIFOLD GASKET
INTAKE MANIFOLD	INTAKE MANIFOLD
INTAKE MANIFOLD ADJUSTER (REAR)	INTAKE MANIFOLD ADJUSTER (REAR)
INTAKE MANIFOLD ADJUSTER (FRONT)	INTAKE MANIFOLD ADJUSTER (FRONT)
ANGLE CONNECTOR	ANGLE CONNECTOR
SAS VALVE GASKET	SAS VALVE GASKET
SECONDARY AIR PUMP	SECONDARY AIR PUMP
SUCTION HOSE, SAS	SUCTION HOSE, SAS
SAS VALVE	SAS VALVE
PRESSURE HOSE, SAS	PRESSURE HOSE, SAS
HEATED REAR OXYGEN SENSOR	HEATED REAR OXYGEN SENSOR
HEATED FRONT OXYGEN SENSOR	HEATED FRONT OXYGEN SENSOR
IGNITION COIL	IGNITION COIL
O-RING, CAMSHAFT SENSOR	O-RING, CAMSHAFT SENSOR
ENGINE CONTROL MODULE	ENGINE CONTROL MODULE
OIL PRESSURE SENSOR	OIL PRESSURE SENSOR
CAP	CAP
FUEL RAIL	FUEL RAIL
INJECTION VALVE	INJECTION VALVE
THROTTLE BODY GASKET	THROTTLE BODY GASKET
THROTTLE BODY	THROTTLE BODY
ENGINE COOLANT TEMP SENSOR	ENGINE COOLANT TEMP SENSOR
RADIATOR COOLANT TEMPERATURE SENSOR	RADIATOR COOLANT TEMP. SENSOR
DIFFERENTIAL PRESSURE SENSOR O-RING	DIFFERENTIAL PRESSURE SENSOR O-RING
CAMSHAFT SENSOR	CAMSHAFT SENSOR
CRANKSHAFT POSITION/RPM SENSOR	CRANKSHAFT POSITION/RPM SENSOR

GAS PEDAL MODULE (AUTOMATIC)

2010 BMW Emissions Related Parts List	
Model = 128i Series	Model = 328i Series
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY	LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY
Part Name	Part Name
DIFFERENTIAL PRESSURE SENSOR	DIFFERENTIAL PRESSURE SENSOR
MASS AIR FLOW SENSOR	MASS AIR FLOW SENSOR
KNOCK SENSOR	KNOCK SENSOR
DIFFERENTIAL PRESSURE SENSOR	DIFFERENTIAL PRESSURE SENSOR
INJECTION VALVE O-RING	INJECTION VALVE O-RING
RUBBER BOOT (INTAKE AIR DUCT)	RUBBER BOOT (INTAKE AIR DUCT)
CONNECTOR (INTAKE AIR DUCT)	CONNECTOR (INTAKE AIR DUCT)
PURGE VALVE	PURGE VALVE
FUEL FILLER CAP	FUEL FILLER CAP
SERVICE LID FOR FUEL TANK, RIGHT	SERVICE LID FOR FUEL TANK, RIGHT
RETAINER, FUEL TANK UNIT, RIGHT	FUEL TANK
FUEL TANK	REPAIR KIT FOR FLANGE COVER
REPAIR KIT FOR FLANGE COVER	REPAIR KIT FOR FUEL TANK @ FILLER FLAP
REPAIR KIT FOR FUEL TANK @ FILLER FLAP	REPAIR KIT FOR FUEL TANK FILLER FLAP
REPAIR KIT FOR FUEL TANK FILLER FLAP	FUEL FILLER NECK
FUEL FILLER NECK	FUEL LEVEL SENSOR, RIGHT
FUEL LEVEL SENSOR, RIGHT	FUEL LINE (UNDERBODY)
FUEL LINE (UNDERBODY)	FUEL FEED LINE
FUEL FEED LINE	SEAL, CANISTER-TO-LDP
SEAL, CANISTER-TO-LDP	DUST FILTER, LDP
DUST FILTER, LDP	SCAVENGE LINE
VENT LINE (FILLER NECK-TO-TANK)	VENT PIPE (FILLER NECK-TO-CANISTER)
VENT PIPE (FILLER NECK-TO-CANISTER)	VENT PIPE (DUST FILTER-TO-LDP)
SCAVENGE LINE	LEAK DIAGNOSTIC PUMP
VENT PIPE (DUST FILTER-TO-LDP)	EVAPORATIVE CANISTER
LEAK DIAGNOSTIC PUMP	DELIVERY UNIT, RIGHT
EVAPORATIVE CANISTER	FUEL PUMP CONTROL UNIT
DELIVERY UNIT, RIGHT	RADIATOR W/DORS (AUTOMATIC TRANS)
FUEL PUMP CONTROL UNIT	RADIATOR W/DORS (MANUAL TRANS)
RADIATOR W/DORS (AUTOMATIC TRANS)	EXHAUST PIPE GASKET
RADIATOR W/DORS (MANUAL TRANS)	EXHAUST PIPE WITH CATALYST
EXHAUST PIPE GASKET	EXHAUST MANIFOLD GASKET
EXHAUST PIPE WITH CATALYST	EXHAUST MANIFOLD WITH CATALYST
EXHAUST MANIFOLD GASKET	TORQUE CONVERTER
EXHAUST MANIFOLD WITH CATALYST	TRANS. CONTROL MODULE, MECHATRONIK
TORQUE CONVERTER	GAS PEDAL MODULE (AUTOMATIC)
TRANSMISSION CONTROL MODULE, MECHATRONIK	GAS PEDAL MODULE (MANUAL)
GAS PEDAL MODULE (MANUAL)	
CAC DEDAL MODULE (ALITOMATIC)	

2011 BMW Emissi	ons Related Parts List
Model = 128i Series SULEV-PZEV	Model = 328i Series SULEV-PZEV
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY	LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY
Part Name	Part Name
GASKET, VALVETRONIC ACTUATOR	GASKET, VALVETRONIC ACTUATOR
OIL FILLER CAP	OIL FILLER CAP
CYLINDER HEAD COVER GASKET	CYLINDER HEAD COVER GASKET
VACUUM PIPE	VACUUM PIPE
VENT HOSE	VENT HOSE
ADJUSTMENT UNIT, INTAKE CAMSHAFT	ADJUSTMENT UNIT, INTAKE CAMSHAFT
SOLENOID VALVE	SOLENOID VALVE
	ADJUSTMENT UNIT, EXHAUST CAMSHAFT
ADJUSTMENT UNIT, EXHAUST CAMSHAFT ADJUSTMENT UNIT, INTAKE CAMSHAFT	ADJUSTMENT UNIT, EXHAUST CAMSHAFT ADJUSTMENT UNIT, INTAKE CAMSHAFT
SOLENOID VALVE	SOLENOID VALVE
VALVETRONIC SENSOR	VALVETRONIC SENSOR
VALVETRONIC SENSOR VALVETRONIC ACTUATOR	VALVETRONIC SENSOR VALVETRONIC ACTUATOR
THERMOSTAT	THERMOSTAT
O-RING, ANGLE CONNECTOR SET INTAKE MANIFOLD GASKET	O-RING, ANGLE CONNECTOR SET INTAKE MANIFOLD GASKET
INTAKE MANIFOLD GASKET	
	INTAKE MANIFOLD AD HISTED (DEAD)
INTAKE MANIFOLD ADJUSTER (REAR)	INTAKE MANIFOLD AD JUSTER (REAR)
INTAKE MANIFOLD ADJUSTER (FRONT) ANGLE CONNECTOR	INTAKE MANIFOLD ADJUSTER (FRONT)
	ANGLE CONNECTOR INTAKE MANIFOLD ADJUSTER (REAR)
INTAKE MANIFOLD ADJUSTER (REAR) SAS VALVE GASKET	SAS VALVE GASKET
SECONDARY AIR PUMP	SECONDARY AIR PUMP
SUCTION HOSE, SAS	SUCTION HOSE, SAS
SAS VALVE	SAS VALVE
PRESSURE HOSE, SAS	
HEATED REAR OXYGEN SENSOR	PRESSURE HOSE, SAS HEATED REAR OXYGEN SENSOR
HEATED FRONT OXYGEN SENSOR	HEATED FRONT OXYGEN SENSOR
IGNITION COIL	IGNITION COIL
O-RING, CAMSHAFT SENSOR	O-RING, CAMSHAFT SENSOR
ENGINE CONTROL MODULE	ENGINE CONTROL MODULE
OIL PRESSURE SENSOR	OIL PRESSURE SENSOR
CAP	CAP
FUEL RAIL	FUEL RAIL
INJECTION VALVE	INJECTION VALVE
THROTTLE BODY GASKET	THROTTLE BODY GASKET
THROTTLE BODY GASKET	THROTTLE BODY
ENGINE COOLANT TEMP SENSOR	ENGINE COOLANT TEMP SENSOR
RADIATOR COOLANT TEMPERATURE SENSOR	RADIATOR COOLANT TEMP SENSOR
DIFFERENTIAL PRESSURE SENSOR O-RING	DIFFERENTIAL PRESSURE SENSOR O-RING
CAMSHAFT SENSOR	CAMSHAFT SENSOR
UAIVIOHAF I JENJUK	CAIVIONAL I SEINOUK

2011 BMW Emissions Related Parts List	
Model = 128i Series SULEV-PZEV	Model = 328i Series SULEV-PZEV
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY	LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY
Part Name	Part Name
CRANKSHAFT POSITION/RPM SENSOR	CRANKSHAFT POSITION/RPM SENSOR
DIFFERENTIAL PRESSURE SENSOR	DIFFERENTIAL PRESSURE SENSOR
MASS AIR FLOW SENSOR	MASS AIR FLOW SENSOR
KNOCK SENSOR	KNOCK SENSOR
DIFFERENTIAL PRESSURE SENSOR	DIFFERENTIAL PRESSURE SENSOR
INJECTION VALVE O-RING	INJECTION VALVE O-RING
RUBBER BOOT (INTAKE AIR DUCT)	RUBBER BOOT (INTAKE AIR DUCT)
CONNECTOR (INTAKE AIR DUCT)	CONNECTOR (INTAKE AIR DUCT)
PURGE VALVE	PURGE VALVE
FUEL FILLER CAP	FUEL FILLER CAP
SERVICE LID FOR FUEL TANK, RIGHT	SERVICE LID FOR FUEL TANK, RIGHT
RETAINER, FUEL TANK UNIT, RIGHT	FUEL TANK
FUEL TANK	REPAIR KIT FOR FLANGE COVER
REPAIR KIT FOR FLANGE COVER	REPAIR KIT FOR FUEL TANK @ FILLER FLAP
REPAIR KIT FOR FUEL TANK @ FILLER FLAP	REPAIR KIT FOR FUEL TANK FILLER FLAP
REPAIR KIT FOR FUEL TANK FILLER FLAP	FUEL FILLER NECK
FUEL FILLER NECK	FUEL LEVEL SENSOR, RIGHT
FUEL LEVEL SENSOR, RIGHT	FUEL LINE (UNDERBODY)
FUEL LINE (UNDERBODY)	FUEL FEED LINE
FUEL FEED LINE	SEAL, CANISTER-TO-LDP
SEAL, CANISTER-TO-LDP	DUST FILTER, LDP
DUST FILTER, LDP	SCAVENGE LINE
VENT LINE (FILLER NECK-TO-TANK)	VENT PIPE (FILLER NECK-TO-CANISTER)
VENT PIPE (FILLER NECK-TO-CANISTER)	VENT PIPE (DUST FILTER-TO-LDP)
SCAVENGE LINE	LEAK DIAGNOSTIC PUMP
VENT PIPE (DUST FILTER-TO-LDP)	EVAPORATIVE CANISTER
LEAK DIAGNOSTIC PUMP	DELIVERY UNIT, RIGHT
EVAPORATIVE CANISTER	FUEL PUMP CONTROL UNIT
DELIVERY UNIT, RIGHT	RADIATOR W/DORS (AUTOMATIC TRANS)
FUEL PUMP CONTROL UNIT	RADIATOR W/DORS (MANUAL TRANS)
RADIATOR W/DORS (AUTOMATIC TRANS)	EXHAUST PIPE GASKET
RADIATOR W/DORS (MANUAL TRANS)	EXHAUST PIPE WITH CATALYST
EXHAUST PIPE GASKET	EXHAUST MANIFOLD GASKET
EXHAUST PIPE WITH CATALYST	EXHAUST MANIFOLD WITH CATALYST
EXHAUST MANIFOLD GASKET	TORQUE CONVERTER
EXHAUST MANIFOLD WITH CATALYST	TRANS. CONTROL MODULE, MECHATRONIK
TORQUE CONVERTER	GAS PEDAL MODULE (AUTOMATIC)

2011 BMW Emissions Related Parts List		
Model = 128i Series SULEV-PZEV	Model = 328i Series SULEV-PZEV	
LIST OF EMISSIONS PARTS SUBJECT TO PZEV	LIST OF EMISSIONS PARTS SUBJECT TO PZEV	
WARRANTY	WARRANTY	
Dord Mosso	Dest Name	
Part Name	Part Name	
GAS PEDAL MODULE (MANUAL)	GAS PEDAL MODULE (AUTOMATIC)	
, ,	, ,	
GAS PEDAL MODULE (AUTOMATIC)	GASKET, VALVETRONIC ACTUATOR	

2012 BMW Emissions Related Parts List	
Model = 128i Series SULEV-PZEV	Model = 328i Coupe, 328i Convertible, 328xi Coupe SULEV-PZEV
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY	LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY
Part Name	Part Name
GASKET, VALVETRONIC ACTUATOR	GASKET, VALVETRONIC ACTUATOR
OIL FILLER CAP	OIL FILLER CAP
CYLINDER HEAD COVER GASKET	CYLINDER HEAD COVER GASKET
VACUUM PIPE	VACUUM PIPE
VENT HOSE	VENT HOSE
ADJUSTMENT UNIT, INTAKE CAMSHAFT	ADJUSTMENT UNIT, INTAKE CAMSHAFT
SOLENOID VALVE	SOLENOID VALVE
ADJUSTMENT UNIT, INTAKE CAMSHAFT	ADJUSTMENT UNIT, INTAKE CAMSHAFT
ADJUSTMENT UNIT, EXHAUST CAMSHAFT	ADJUSTMENT UNIT, EXHAUST CAMSHAFT
SOLENOID VALVE	SOLENOID VALVE
VALVETRONIC SENSOR	VALVETRONIC SENSOR
VALVETRONIC ACTUATOR	VALVETRONIC ACTUATOR
THERMOSTAT	THERMOSTAT
O-RING, ANGLE CONNECTOR	O-RING, ANGLE CONNECTOR
SET INTAKE MANIFOLD GASKET	SET INTAKE MANIFOLD GASKET
INTAKE MANIFOLD	INTAKE MANIFOLD
INTAKE MANIFOLD ADJUSTER (REAR)	INTAKE MANIFOLD ADJUSTER (REAR)
INTAKE MANIFOLD ADJUSTER (FRONT)	INTAKE MANIFOLD ADJUSTER (FRONT)
ANGLE CONNECTOR	ANGLE CONNECTOR
INTAKE MANIFOLD ADJUSTER (REAR)	INTAKE MANIFOLD ADJUSTER (REAR)
SAS VALVE GASKET	SAS VALVE GASKET
SECONDARY AIR PUMP	SECONDARY AIR PUMP
SUCTION HOSE, SAS	SUCTION HOSE, SAS
SAS VALVE	SAS VALVE
PRESSURE HOSE, SAS	PRESSURE HOSE, SAS
HEATED REAR OXYGEN SENSOR	HEATED REAR OXYGEN SENSOR
HEATED FRONT OXYGEN SENSOR	HEATED FRONT OXYGEN SENSOR
IGNITION COIL	IGNITION COIL
O-RING, CAMSHAFT SENSOR	O-RING, CAMSHAFT SENSOR
ENGINE CONTROL MODULE	OIL PRESSURE SENSOR
OIL PRESSURE SENSOR	CAP
CAP	FUEL RAIL
FUEL RAIL	INJECTION VALVE
INJECTION VALVE	THROTTLE BODY GASKET
THROTTLE BODY GASKET	THROTTLE BODY
THROTTLE BODY	ENGINE COOLANT TEMP SENSOR

sions Related Parts List

2012 BMW Emis
Model = 128i Series SULEV-PZEV
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY
Part Name
DIFFERENTIAL PRESSURE SENSOR O-RING CAMSHAFT SENSOR
CRANKSHAFT POSITION/RPM SENSOR DIFFERENTIAL PRESSURE SENSOR MASS AIR FLOW SENSOR
KNOCK SENSOR DIFFERENTIAL PRESSURE SENSOR
INJECTION VALVE O-RING RUBBER BOOT (INTAKE AIR DUCT) CONNECTOR (INTAKE AIR DUCT)
PURGE VALVE FUEL FILLER CAP
SERVICE LID FOR FUEL TANK, RIGHT RETAINER, FUEL TANK UNIT, RIGHT FUEL TANK
REPAIR KIT FOR FLANGE COVER REPAIR KIT FOR FUEL TANK @ FILLER FLAP
REPAIR KIT FOR FUEL TANK FILLER FLAP FUEL FILLER NECK FUEL LEVEL SENSOR, RIGHT
FUEL LINE (UNDERBODY) FUEL FEED LINE
SEAL, CANISTER-TO-LDP DUST FILTER, LDP VENT LINE (FILLER NECK-TO-TANK)
VENT PIPE (FILLER NECK-TO-CANISTER) SCAVENGE LINE
VENT PIPE (DUST FILTER-TO-LDP) LEAK DIAGNOSTIC PUMP EVAPORATIVE CANISTER
DELIVERY UNIT, RIGHT FUEL PUMP CONTROL UNIT
RADIATOR W/DORS (AUTOMATIC TRANS) RADIATOR W/DORS (MANUAL TRANS) EXHAUST PIPE GASKET
EXHAUST PIPE WITH CATALYST EXHAUST MANIFOLD GASKET

EXHAUST MANIFOLD WITH CATALYST

Model = 328i Coupe, 328i Convertible, 328xi Coupe SULEV-PZEV

LIST OF EMISSIONS PARTS SUBJECT TO PZEV

LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY		
WANTANII		
Part Name		
CAMSHAFT SENSOR		
CRANKSHAFT POSITION/RPM SENSOR		
DIFFERENTIAL PRESSURE SENSOR		
MASS AIR FLOW SENSOR		
KNOCK SENSOR		
DIFFERENTIAL PRESSURE SENSOR		
INJECTION VALVE O-RING		
RUBBER BOOT (INTAKE AIR DUCT)		
CONNECTOR (INTAKE AIR DUCT)		
PURGE VALVE		
FUEL FILLER CAP		
SERVICE LID FOR FUEL TANK, RIGHT		
FUEL TANK		
REPAIR KIT FOR FLANGE COVER		
REPAIR KIT FOR FUEL TANK @ FILLER FLAP		
REPAIR KIT FOR FUEL TANK FILLER FLAP		
FUEL FILLER NECK		
FUEL LEVEL SENSOR, RIGHT		
FUEL LINE (UNDERBODY)		
FUEL FEED LINE		
SEAL, CANISTER-TO-LDP		
DUST FILTER, LDP		
SCAVENGE LINE		
VENT PIPE (FILLER NECK-TO-CANISTER)		
VENT PIPE (DUST FILTER-TO-LDP)		
LEAK DIAGNOSTIC PUMP		
EVAPORATIVE CANISTER		
DELIVERY UNIT, RIGHT		
FUEL PUMP CONTROL UNIT		
RADIATOR W/DORS (AUTOMATIC TRANS)		
RADIATOR W/DORS (MANUAL TRANS)		
EXHAUST PIPE GASKET		
EXHAUST PIPE WITH CATALYST		
EXHAUST MANIFOLD GASKET		
EXHAUST MANIFOLD WITH CATALYST		
TORQUE CONVERTER		
TRANS. CONTROL MODULE, MECHATRONIK		
GAS PEDAL MODULE (AUTOMATIC)		

ZO 12 DIVITO COLLY (1 ZEV)1 di to Liot 110 1 Ve	
2012 BMW Emissi	ions Related Parts List
Model = 128i Series SULEV-PZEV	Model = 328i Coupe, 328i Convertible, 328xi Coupe SULEV-PZEV
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY	LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY
Part Name	Part Name
TORQUE CONVERTER	GAS PEDAL MODULE (MANUAL)
TRANS. CONTROL MODULE, MECHATRONIK	
GAS PEDAL MODULE (MANUAL)	
GAS PEDAL MODULE (AUTOMATIC)	

2012 BMW SULEV (PZEV) Parts List - N26 Vehicles

2012 BMW Emissions Related Parts List Model = 328i (F30) SULEV-PZEV LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY Part Name HIGH PRESSURE FUEL PUMP MOUNTING GASKET VENT HOSE CYLINDER HEAD COVER GASKET SET OIL FILLER CAP ADJUSTMENT UNIT, INTAKE CAMSHAFT ADJUSTMENT UNIT, EXHAUST CAMSHAFT VANOS CENTRAL (SOLENOID) VALVE VANOS ACTUATOR VALVETRONIC ACTUATOR THERMOSTAT SET INTAKE MANIFOLD GASKET INTAKE MANIFOLD O-RING, CHARGE AIR DUCT (THROTTLE SIDE) O-RING, CHARGE AIR DUCT (TURBO SIDE) VACUUM HOSE, TURBO CONTROL COMPRESSOR BYPASS VALVE EXHAUST MANIFOLD GASKET RING TURBOCHARGER VACUUM HOSE, TURBO CONTROL VACUUM PUMP PRESSURE CONVERTER HEATED FRONT OXYGEN SENSOR HEATED REAR OXYGEN SENSOR IGNITION COIL O-RING, CAMSENSOR **ENGINE CONTROL MODULE** ENGINE OIL TEMP SENSOR HIGH PRESSURE FUEL PUMP FUEL HOSE (UNDERBODY LINE-TO-FUEL INLET PIPE) HIGH PRESSURE RAIL FUEL INLET PIPE (TO HIGH PRESSURE PUMP) HIGH PRESSURE PIPE (PUMP-TO-RAIL) INJECTION VALVE O-RING HIGH PRESSURE SENSOR (FUEL) FUEL HOSE (UNDERBODY LINE-TO-FUEL INLET PIPE) THROTTLE BODY GASKET THROTTLE ENGINE COOLANT TEMP SENSOR CAMSHAFT SENSOR CRANKSHAFT POSITION/RPM SENSOR KNOCK SENSOR MAF SENSOR O-RING, MAF SENSOR

Model = 328i (F30) SULEV-PZEV LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY Part Name PRESSURE SENSOR (UPSTREAM OF THROTTLE) INJECTION VALVE AIR DUCT (AIR FILTER TO COMPRESSOR INLET, UPPER PIECE) CHARGE AIR INDUCTION TRACT (COMPRESSOR OUTLET-TO-CAC INLET) GASKET (AIR INTAKE TUBE-TO-COMPRESSOR INLET) CHARGE AIR INDUCTION TRACT (CAC TO THROTTLE HOUSING) AIR INTAKE TUBE (AIR FILTER TO COMPRESSOR INLET, LOWER PIECE) O-RING, CHARGE AIR DUCT (THROTTLE SIDE) FUEL TANK BREATHER LINE PURGE VALVE CLOSURE RING, FUEL TANK UNIT O-RING, FUEL TANK UNIT FUEL FILLER CAP PLASTIC FILLER PIPE PLASTIC FUEL TANK
PRESSURE SENSOR (UPSTREAM OF THROTTLE) INJECTION VALVE AIR DUCT (AIR FILTER TO COMPRESSOR INLET, UPPER PIECE) CHARGE AIR INDUCTION TRACT (COMPRESSOR OUTLET-TO-CAC INLET) GASKET (AIR INTAKE TUBE-TO-COMPRESSOR INLET) CHARGE AIR INDUCTION TRACT (CAC TO THROTTLE HOUSING) AIR INTAKE TUBE (AIR FILTER TO COMPRESSOR INLET, LOWER PIECE) O-RING, CHARGE AIR DUCT (THROTTLE SIDE) FUEL TANK BREATHER LINE PURGE VALVE CLOSURE RING, FUEL TANK UNIT O-RING, FUEL TANK UNIT FUEL FILLER CAP PLASTIC FILLER PIPE
PRESSURE SENSOR (UPSTREAM OF THROTTLE) INJECTION VALVE AIR DUCT (AIR FILTER TO COMPRESSOR INLET, UPPER PIECE) CHARGE AIR INDUCTION TRACT (COMPRESSOR OUTLET-TO-CAC INLET) GASKET (AIR INTAKE TUBE-TO-COMPRESSOR INLET) CHARGE AIR INDUCTION TRACT (CAC TO THROTTLE HOUSING) AIR INTAKE TUBE (AIR FILTER TO COMPRESSOR INLET, LOWER PIECE) O-RING, CHARGE AIR DUCT (THROTTLE SIDE) FUEL TANK BREATHER LINE PURGE VALVE CLOSURE RING, FUEL TANK UNIT O-RING, FUEL TANK UNIT FUEL FILLER CAP PLASTIC FILLER PIPE
PRESSURE SENSOR (UPSTREAM OF THROTTLE) INJECTION VALVE AIR DUCT (AIR FILTER TO COMPRESSOR INLET, UPPER PIECE) CHARGE AIR INDUCTION TRACT (COMPRESSOR OUTLET-TO-CAC INLET) GASKET (AIR INTAKE TUBE-TO-COMPRESSOR INLET) CHARGE AIR INDUCTION TRACT (CAC TO THROTTLE HOUSING) AIR INTAKE TUBE (AIR FILTER TO COMPRESSOR INLET, LOWER PIECE) O-RING, CHARGE AIR DUCT (THROTTLE SIDE) FUEL TANK BREATHER LINE PURGE VALVE CLOSURE RING, FUEL TANK UNIT O-RING, FUEL TANK UNIT FUEL FILLER CAP PLASTIC FILLER PIPE
INJECTION VALVE AIR DUCT (AIR FILTER TO COMPRESSOR INLET, UPPER PIECE) CHARGE AIR INDUCTION TRACT (COMPRESSOR OUTLET-TO-CAC INLET) GASKET (AIR INTAKE TUBE-TO-COMPRESSOR INLET) CHARGE AIR INDUCTION TRACT (CAC TO THROTTLE HOUSING) AIR INTAKE TUBE (AIR FILTER TO COMPRESSOR INLET, LOWER PIECE) O-RING, CHARGE AIR DUCT (THROTTLE SIDE) FUEL TANK BREATHER LINE PURGE VALVE CLOSURE RING, FUEL TANK UNIT O-RING, FUEL TANK UNIT FUEL FILLER CAP PLASTIC FILLER PIPE
INJECTION VALVE AIR DUCT (AIR FILTER TO COMPRESSOR INLET, UPPER PIECE) CHARGE AIR INDUCTION TRACT (COMPRESSOR OUTLET-TO-CAC INLET) GASKET (AIR INTAKE TUBE-TO-COMPRESSOR INLET) CHARGE AIR INDUCTION TRACT (CAC TO THROTTLE HOUSING) AIR INTAKE TUBE (AIR FILTER TO COMPRESSOR INLET, LOWER PIECE) O-RING, CHARGE AIR DUCT (THROTTLE SIDE) FUEL TANK BREATHER LINE PURGE VALVE CLOSURE RING, FUEL TANK UNIT O-RING, FUEL TANK UNIT FUEL FILLER CAP PLASTIC FILLER PIPE
AIR DUCT (AIR FILTER TO COMPRESSOR INLET, UPPER PIECE) CHARGE AIR INDUCTION TRACT (COMPRESSOR OUTLET-TO-CAC INLET) GASKET (AIR INTAKE TUBE-TO-COMPRESSOR INLET) CHARGE AIR INDUCTION TRACT (CAC TO THROTTLE HOUSING) AIR INTAKE TUBE (AIR FILTER TO COMPRESSOR INLET, LOWER PIECE) O-RING, CHARGE AIR DUCT (THROTTLE SIDE) FUEL TANK BREATHER LINE PURGE VALVE CLOSURE RING, FUEL TANK UNIT O-RING, FUEL TANK UNIT FUEL FILLER CAP PLASTIC FILLER PIPE
CHARGE AIR INDUCTION TRACT (COMPRESSOR OUTLET-TO-CAC INLET) GASKET (AIR INTAKE TUBE-TO-COMPRESSOR INLET) CHARGE AIR INDUCTION TRACT (CAC TO THROTTLE HOUSING) AIR INTAKE TUBE (AIR FILTER TO COMPRESSOR INLET, LOWER PIECE) O-RING, CHARGE AIR DUCT (THROTTLE SIDE) FUEL TANK BREATHER LINE PURGE VALVE CLOSURE RING, FUEL TANK UNIT O-RING, FUEL TANK UNIT FUEL FILLER CAP PLASTIC FILLER PIPE
GASKET (AIR INTAKE TUBE-TO-COMPRESSOR INLET) CHARGE AIR INDUCTION TRACT (CAC TO THROTTLE HOUSING) AIR INTAKE TUBE (AIR FILTER TO COMPRESSOR INLET, LOWER PIECE) O-RING, CHARGE AIR DUCT (THROTTLE SIDE) FUEL TANK BREATHER LINE PURGE VALVE CLOSURE RING, FUEL TANK UNIT O-RING, FUEL TANK UNIT FUEL FILLER CAP PLASTIC FILLER PIPE
CHARGE AIR INDUCTION TRACT (CAC TO THROTTLE HOUSING) AIR INTAKE TUBE (AIR FILTER TO COMPRESSOR INLET, LOWER PIECE) O-RING, CHARGE AIR DUCT (THROTTLE SIDE) FUEL TANK BREATHER LINE PURGE VALVE CLOSURE RING, FUEL TANK UNIT O-RING, FUEL TANK UNIT FUEL FILLER CAP PLASTIC FILLER PIPE
AIR INTAKE TUBE (AIR FILTER TO COMPRESSOR INLET, LOWER PIECE) O-RING, CHARGE AIR DUCT (THROTTLE SIDE) FUEL TANK BREATHER LINE PURGE VALVE CLOSURE RING, FUEL TANK UNIT O-RING, FUEL TANK UNIT FUEL FILLER CAP PLASTIC FILLER PIPE
O-RING, CHARGE AIR DUCT (THROTTLE SIDE) FUEL TANK BREATHER LINE PURGE VALVE CLOSURE RING, FUEL TANK UNIT O-RING, FUEL TANK UNIT FUEL FILLER CAP PLASTIC FILLER PIPE
FUEL TANK BREATHER LINE PURGE VALVE CLOSURE RING, FUEL TANK UNIT O-RING, FUEL TANK UNIT FUEL FILLER CAP PLASTIC FILLER PIPE
PURGE VALVE CLOSURE RING, FUEL TANK UNIT O-RING, FUEL TANK UNIT FUEL FILLER CAP PLASTIC FILLER PIPE
CLOSURE RING, FUEL TANK UNIT O-RING, FUEL TANK UNIT FUEL FILLER CAP PLASTIC FILLER PIPE
O-RING, FUEL TANK UNIT FUEL FILLER CAP PLASTIC FILLER PIPE
FUEL FILLER CAP PLASTIC FILLER PIPE
PLASTIC FILLER PIPE
PLASTIC FUEL TANK
FILLER PIPE (SLEEVE BETWEEN FILLER NECK AND TANK)
FUEL LEVEL SENSOR
FUEL TANK SUPPLY MODULE
EVAPORATIVE CANISTER
SCAVENGER AIR LINE
FUEL FEED LINE
SEAL, CANISTER-TO-LDP
VENT PIPE FROM LDP, INCLUDING DUST FILTER
SCAVENGING LINE FRONT
BREATHER LINE FROM EVAPORATIVE CANISTER
LEAK DIAGNOSTIC PUMP
FUEL PUMP CONTROL UNIT
RADIATOR (WITH DOR SYSTEM)
CHARGE AIR COOLER
GASKET, EXHAUST PIPE (BETWEEN CAT & TURBO)
CATALYST (WU-TWC)
REPLACEMENT CATALYST WITH CENTER MUFFLER (UNDERFLOOR CAT)
TORQUE CONVERTER
TRANSMISSION CONTROL MODULE (MECHATRONIK)
GAS PEDAL MODULE (AUTO)

nissions Related Parts List

2012 BMW Emis	sions Related Parts List
Model = 128i Series SULEV-PZEV	Model = 328i Coupe, 328i Convertible 328xi Coupe SULEV-PZEV
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY	LIST OF EMISSIONS PARTS SUBJECT TO PE WARRANTY
D. I.N.	D. (No. 1)
Part Name	Part Name
GASKET, VALVETRONIC ACTUATOR	GASKET, VALVETRONIC ACTUATOR
OIL FILLER CAP	OIL FILLER CAP
CYLINDER HEAD COVER GASKET	CYLINDER HEAD COVER GASKET
VACUUM PIPE	VACUUM PIPE
VENT HOSE	VENT HOSE
ADJUSTMENT UNIT, INTAKE CAMSHAFT	ADJUSTMENT UNIT, INTAKE CAMSHAFT
SOLENOID VALVE	SOLENOID VALVE
ADJUSTMENT UNIT, INTAKE CAMSHAFT	ADJUSTMENT UNIT, INTAKE CAMSHAFT
ADJUSTMENT UNIT, EXHAUST CAMSHAFT	ADJUSTMENT UNIT, EXHAUST CAMSHAFT
SOLENOID VALVE	SOLENOID VALVE
VALVETRONIC SENSOR	VALVETRONIC SENSOR
VALVETRONIC ACTUATOR	VALVETRONIC ACTUATOR
THERMOSTAT	THERMOSTAT
O-RING, ANGLE CONNECTOR	O-RING, ANGLE CONNECTOR
SET INTAKE MANIFOLD GASKET	SET INTAKE MANIFOLD GASKET
INTAKE MANIFOLD AD HISTER (DEAD)	INTAKE MANIFOLD
INTAKE MANIFOLD ADJUSTER (REAR)	INTAKE MANIFOLD ADJUSTER (REAR)
INTAKE MANIFOLD ADJUSTER (FRONT)	INTAKE MANIFOLD ADJUSTER (FRONT)
ANGLE CONNECTOR	ANGLE CONNECTOR
INTAKE MANIFOLD ADJUSTER (REAR)	INTAKE MANIFOLD ADJUSTER (REAR)
SAS VALVE GASKET	SAS VALVE GASKET
SECONDARY AIR PUMP	SECONDARY AIR PUMP
SUCTION HOSE, SAS	SUCTION HOSE, SAS
SAS VALVE	SAS VALVE
PRESSURE HOSE, SAS	PRESSURE HOSE, SAS
HEATED FRONT OXYGEN SENSOR	HEATED FRONT OXYGEN SENSOR
HEATED FRONT OXYGEN SENSOR IGNITION COIL	HEATED FRONT OXYGEN SENSOR
	IGNITION COIL O DINC CAMSHAET SENSOD
O-RING, CAMSHAFT SENSOR	O-RING, CAMSHAFT SENSOR
ENGINE CONTROL MODULE	OIL PRESSURE SENSOR
OIL PRESSURE SENSOR CAP	CAP
FUEL RAIL	FUEL RAIL
INJECTION VALVE	INJECTION VALVE THROTTLE BODY GASKET
THROTTLE BODY GASKET	THROTTLE BODY GASKET THROTTLE BODY
THROTTLE BODY GASKET	ENGINE COOLANT TEMP SENSOR
ENGINE COOLANT TEMP SENSOR	RADIATOR COOLANT TEMP SENSOR
ENGINE COULANT TEIVIP SENSUK	RADIATOR COOLAINT TEIVIPERATURE SENSUR

Model = 328i Coupe, 328i Convertible, 328xi Coupe SULEV-PZEV

ST OF EMISSIONS PARTS SUBJECT TO PZEV

WARRANTY
Part Name
GASKET, VALVETRONIC ACTUATOR
OIL FILLER CAP
CYLINDER HEAD COVER GASKET
VACUUM PIPE
VENT HOSE
ADJUSTMENT UNIT, INTAKE CAMSHAFT
SOLENOID VALVE
ADJUSTMENT UNIT, INTAKE CAMSHAFT
ADJUSTMENT UNIT, EXHAUST CAMSHAFT
SOLENOID VALVE
VALVETRONIC SENSOR
VALVETRONIC ACTUATOR
THERMOSTAT
O-RING, ANGLE CONNECTOR
SET INTAKE MANIFOLD GASKET
INTAKE MANIFOLD
INTAKE MANIFOLD ADJUSTER (REAR)
INTAKE MANIFOLD ADJUSTER (FRONT)
ANGLE CONNECTOR
INTAKE MANIFOLD ADJUSTER (REAR)
SAS VALVE GASKET
SECONDARY AIR PUMP
SUCTION HOSE, SAS
SAS VALVE
PRESSURE HOSE, SAS
HEATED REAR OXYGEN SENSOR
HEATED FRONT OXYGEN SENSOR
IGNITION COIL
O-RING, CAMSHAFT SENSOR
OIL PRESSURE SENSOR
CAP
FUEL RAIL
INJECTION VALVE
THROTTLE BODY GASKET
THROTTLE BODY
ENGINE COOLANT TEMP SENSOR

2012 BMW Emissions Related Parts List		
Model = 128i Series SULEV-PZEV	Model = 328i Coupe, 328i Convertible, 328xi Coupe SULEV-PZEV	
LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY	LIST OF EMISSIONS PARTS SUBJECT TO PZEV WARRANTY	
Part Name	Part Name	
RADIATOR COOLANT TEMPERATURE SENSOR	DIFFERENTIAL PRESSURE SENSOR O-RING	
DIFFERENTIAL PRESSURE SENSOR O-RING	CAMSHAFT SENSOR	
CAMSHAFT SENSOR	CRANKSHAFT POSITION/RPM SENSOR	
CRANKSHAFT POSITION/RPM SENSOR	DIFFERENTIAL PRESSURE SENSOR	
DIFFERENTIAL PRESSURE SENSOR	MASS AIR FLOW SENSOR	
MASS AIR FLOW SENSOR	KNOCK SENSOR	
KNOCK SENSOR	DIFFERENTIAL PRESSURE SENSOR	
DIFFERENTIAL PRESSURE SENSOR	INJECTION VALVE O-RING	
INJECTION VALVE O-RING	RUBBER BOOT (INTAKE AIR DUCT)	
RUBBER BOOT (INTAKE AIR DUCT)	CONNECTOR (INTAKE AIR DUCT)	
CONNECTOR (INTAKE AIR DUCT)	PURGE VALVE	
PURGE VALVE	FUEL FILLER CAP	
FUEL FILLER CAP	SERVICE LID FOR FUEL TANK, RIGHT	
SERVICE LID FOR FUEL TANK, RIGHT	FUEL TANK	
RETAINER, FUEL TANK UNIT, RIGHT	REPAIR KIT FOR FLANGE COVER	
FUEL TANK	REPAIR KIT FOR FUEL TANK @ FILLER FLAP	
REPAIR KIT FOR FLANGE COVER	REPAIR KIT FOR FUEL TANK FILLER FLAP	
REPAIR KIT FOR FUEL TANK @ FILLER FLAP	FUEL FILLER NECK	
REPAIR KIT FOR FUEL TANK FILLER FLAP	FUEL LEVEL SENSOR, RIGHT	
FUEL FILLER NECK	FUEL LINE (UNDERBODY)	
FUEL LEVEL SENSOR, RIGHT	FUEL FEED LINE	
FUEL LINE (UNDERBODY)	SEAL, CANISTER-TO-LDP	
FUEL FEED LINE	DUST FILTER, LDP	
SEAL, CANISTER-TO-LDP	SCAVENGE LINE	
DUST FILTER, LDP	VENT PIPE (FILLER NECK-TO-CANISTER)	
VENT LINE (FILLER NECK-TO-TANK)	VENT PIPE (DUST FILTER-TO-LDP)	
VENT PIPE (FILLER NECK-TO-CANISTER)	LEAK DIAGNOSTIC PUMP	
SCAVENGE LINE	EVAPORATIVE CANISTER	
VENT PIPE (DUST FILTER-TO-LDP)	DELIVERY UNIT, RIGHT	
LEAK DIAGNOSTIC PUMP	FUEL PUMP CONTROL UNIT	
EVAPORATIVE CANISTER	RADIATOR W/DORS (AUTOMATIC TRANS)	
DELIVERY UNIT, RIGHT	RADIATOR W/DORS (MANUAL TRANS)	
FUEL PUMP CONTROL UNIT	EXHAUST PIPE GASKET	
RADIATOR W/DORS (AUTOMATIC TRANS)	EXHAUST PIPE WITH CATALYST	
RADIATOR W/DORS (MANUAL TRANS)	EXHAUST MANIFOLD GASKET	
EXHAUST PIPE GASKET	EXHAUST MANIFOLD WITH CATALYST	
EXHAUST PIPE WITH CATALYST	TORQUE CONVERTER	
EXHAUST MANIFOLD GASKET	TRANSMISSION CONTROL MODULE, MECHATRONIK	
EXHAUST MANIFOLD WITH CATALYST	GAS PEDAL MODULE (AUTOMATIC)	
TORQUE CONVERTER	GAS PEDAL MODULE (MANUAL)	

2012 BMW Emissions Related Parts List		
Model = 128i Series SULEV-PZEV		
LIST OF EMISSIONS PARTS SUBJECT TO PZEV		
WARRANTY		
Part Name		
TRANS. CONTROL MODULE, MECHATRONIK		
GAS PEDAL MODULE (MANUAL)		
GAS PEDAL MODULE (AUTOMATIC)		

2013 BMW Emissions Related Parts List

Model = 328i Coupe, 328i Convertible, 328xi Coupe SULEV-PZEV	Model = 128i Coupe/Convertible SULEV-PZEV
Part Name	Part Name
GASKET, VALVETRONIC ACTUATOR	GASKET, VALVETRONIC ACTUATOR
OIL FILLER CAP	OIL FILLER CAP
CYLINDER HEAD COVER GASKET	CYLINDER HEAD COVER GASKET
VACUUM PIPE	VACUUM PIPE
VENT HOSE	VENT HOSE
ADJUSTMENT UNIT, INTAKE CAMSHAFT	ADJUSTMENT UNIT, INTAKE CAMSHAFT
ADJUSTMENT UNIT, EXHAUST CAMSHAFT	ADJUSTMENT UNIT, EXHAUST CAMSHAFT
SOLENOID VALVE	SOLENOID VALVE
VALVETRONIC SENSOR	VALVETRONIC SENSOR
VALVETRONIC ACTUATOR	VALVETRONIC ACTUATOR
THERMOSTAT	THERMOSTAT
O-RING, ANGLE CONNECTOR	O-RING, ANGLE CONNECTOR
SET INTAKE MANIFOLD GASKET	SET INTAKE MANIFOLD GASKET
INTAKE MANIFOLD	INTAKE MANIFOLD
INTAKE MANIFOLD ADJUSTER (FRONT)	INTAKE MANIFOLD ADJUSTER (FRONT)
ANGLE CONNECTOR	ANGLE CONNECTOR
INTAKE MANIFOLD ADJUSTER (REAR)	INTAKE MANIFOLD ADJUSTER (REAR)
SAS VALVE GASKET	SAS VALVE GASKET
SECONDARY AIR PUMP	SECONDARY AIR PUMP
SUCTION HOSE, SAS	SUCTION HOSE, SAS
SAS VALVE	SAS VALVE
PRESSURE HOSE, SAS	PRESSURE HOSE, SAS
HEATED REAR OXYGEN SENSOR (cyl 1-3)	HEATED REAR OXYGEN SENSOR
HEATED FRONT OXYGEN SENSOR (cyl 4-6)	HEATED FRONT OXYGEN SENSOR
IGNITION COIL	IGNITION COIL
O-RING, CAMSHAFT SENSOR	O-RING, CAMSHAFT SENSOR
ENGINE CONTROL MODULE	ENGINE CONTROL MODULE
OIL PRESSURE SENSOR	OIL PRESSURE SENSOR
CAP	CAP
FUEL RAIL	FUEL RAIL
INJECTION VALVE	INJECTION VALVE
THROTTLE BODY	THROTTLE BODY GASKET
THROTTLE BODY GASKET	THROTTLE BODY
ENGINE COOLANT TEMP SENSOR	ENGINE COOLANT TEMP SENSOR
RADIATOR COOLANT TEMPERATURE SENSOR	RADIATOR COOLANT TEMPERATURE SENSOR
DIFFERENTIAL PRESSURE SENSOR O-RING	DIFFERENTIAL PRESSURE SENSOR O-RING
CAMSHAFT SENSOR	CAMSHAFT SENSOR
CRANKSHAFT POSITION/RPM SENSOR	CRANKSHAFT POSITION/RPM SENSOR
O-RING MASS AIR FLOW SENSOR	DIFFERENTIAL PRESSURE SENSOR
MASS AIR FLOW SENSOR	MASS AIR FLOW SENSOR
KNOCK SENSOR	KNOCK SENSOR
DIFFERENTIAL PRESSURE SENSOR	DIFFERENTIAL PRESSURE SENSOR
INJECTION VALVE O-RING	INJECTION VALVE O-RING
RUBBER BOOT (INTAKE AIR DUCT)	RUBBER BOOT (INTAKE AIR DUCT)

Model = 328i Coupe, 328i Convertible, 328xi Coupe SULEV-PZEV Part Name **CONNECTOR (INTAKE AIR DUCT) PURGE VALVE FUEL TANK** RETAINER, FUEL TANK UNIT, RIGHT REPAIR KIT FOR FLANGE COVER REPAIR KIT FOR FUEL TANK @ FILLER FLAP FUEL FILLER NECK **FUEL FILLER CAP** FUEL LEVEL SENSOR, RIGHT SERVICE LID FOR FUEL TANK, RIGHT **FUEL FEED LINE** SEAL, CANISTER-TO-LDP VENT PIPE (DUST FILTER-TO-LDP) DUST FILTER, LDP SCAVENGE LINE VENT PIPE (FILLER NECK-TO-CANISTER) LEAK DIAGNOSTIC PUMP **EVAPORATIVE CANISTER DELIVERY UNIT, RIGHT** FUEL PUMP CONTROL UNIT RADIATOR W/DORS (AUTOMATIC TRANS) RADIATOR W/DORS (MANUAL TRANS) EXHAUST PIPE GASKET EXHAUST PIPE WITH CATALYST (cyl 4-6) EXHAUST PIPE WITH CATALYST (cyl 1-3) **EXHAUST MANIFOLD GASKET** EXHAUST MANIFOLD WITH CATALYST (cyl 1-3) EXHAUST MANIFOLD WITH CATALYST (cyl 4-6) TORQUE CONVERTER

TRANS. CONTROL MODULE, MECHATRONIK

GAS PEDAL MODULE (MANUAL)

GAS PEDAL MODULE (AUTOMATIC)

Model = 128i Coupe/Convertible SULEV-PZEV
Part Name
CONNECTOR (INTAKE AIR DUCT)
PURGE VALVE
FUEL FILLER CAP
SERVICE LID FOR FUEL TANK, RIGHT
RETAINER, FUEL TANK UNIT, RIGHT
FUEL TANK
REPAIR KIT FOR FLANGE COVER
REPAIR KIT FOR FUEL TANK @ FILLER FLAP
REPAIR KIT FOR FUEL TANK FILLER FLAP
FUEL FILLER NECK
FUEL LEVEL SENSOR, RIGHT
FUEL LINE (UNDERBODY)
FUEL FEED LINE
SEAL, CANISTER-TO-LDP
DUST FILTER, LDP
VENT LINE (FILLER NECK-TO-TANK)
VENT PIPE (FILLER NECK-TO-CANISTER)
SCAVENGE LINE
VENT PIPE (DUST FILTER-TO-LDP)
LEAK DIAGNOSTIC PUMP
EVAPORATIVE CANISTER
DELIVERY UNIT, RIGHT
FUEL PUMP CONTROL UNIT
RADIATOR W/DORS (AUTOMATIC TRANS)
RADIATOR W/DORS (MANUAL TRANS)
EXHAUST PIPE GASKET
EXHAUST PIPE WITH CATALYST
EXHAUST MANIFOLD GASKET
EXHAUST MANIFOLD WITH CATALYST
TORQUE CONVERTER
TRANS. CONTROL MODULE, MECHATRONIK

GAS PEDAL MODULE (MANUAL)
GAS PEDAL MODULE (AUTOMATIC)

2013 BMW Emissions Related Parts List Model = 328i, 328xi Sedan SULEV-PZEV **Part Name** HIGH PRESSURE FUEL PUMP MOUNTING GASKET **VENT HOSE** CYLINDER HEAD COVER GASKET SET OIL FILLER CAP ADJUSTMENT UNIT, INTAKE CAMSHAFT ADJUSTMENT UNIT, EXHAUST CAMSHAFT VANOS CENTRAL (SOLENOID) VALVE **VANOS ACTUATOR** VALVETRONIC ACTUATOR THERMOSTAT SET INTAKE MANIFOLD GASKET INTAKE MANIFOLD O-RING, CHARGE AIR DUCT (THROTTLE SIDE) O-RING, CHARGE AIR DUCT (TURBO SIDE) VACUUM HOSE, TURBO CONTROL COMPRESSOR BYPASS VALVE EXHAUST MANIFOLD GASKET RING TURBOCHARGER VACUUM HOSE, TURBO CONTROL **VACUUM PUMP** PRESSURE CONVERTER HEATED FRONT OXYGEN SENSOR HEATED REAR OXYGEN SENSOR **IGNITION COIL** O-RING, CAMSENSOR **ENGINE CONTROL MODULE ENGINE OIL TEMP SENSOR** HIGH PRESSURE FUEL PUMP FUEL HOSE (UNDERBODY LINE-TO-FUEL INLET PIPE) HIGH PRESSURE RAIL FUEL INLET PIPE (TO HIGH PRESSURE PUMP) HIGH PRESSURE PIPE (PUMP-TO-RAIL) INJECTION VALVE O-RING HIGH PRESSURE SENSOR (FUEL) FUEL HOSE (UNDERBODY LINE-TO-FUEL INLET PIPE) THROTTLE BODY GASKET THROTTLE ENGINE COOLANT TEMP SENSOR **CAMSHAFT SENSOR** CRANKSHAFT POSITION/RPM SENSOR KNOCK SENSOR MAF SENSOR

O-RING, MAF SENSOR

INJECTION VALVE

PRESSURE SENSOR (UPSTREAM OF THROTTLE)

2013 BMW Emissions Related Parts List
Model = 328i, 328xi Sedan SULEV-PZEV
,
Part Name
AIR DUCT (AIR FILTER TO COMPRESSOR INLET, UPPER PIECE)
CHARGE AIR INDUCTION TRACT (COMPRESSOR OUTLET-TO-CAC INLET)
GASKET (AIR INTAKE TUBE-TO-COMPRESSOR INLET)
CHARGE AIR INDUCTION TRACT (CAC TO THROTTLE HOUSING)
AIR INTAKE TUBE (AIR FILTER TO COMPRESSOR INLET, LOWER PIECE)
O-RING, CHARGE AIR DUCT (THROTTLE SIDE)
FUEL TANK BREATHER LINE
PURGE VALVE
CLOSURE RING, FUEL TANK UNIT
O-RING, FUEL TANK UNIT
FUEL FILLER CAP
PLASTIC FILLER PIPE
PLASTIC FUEL TANK
FILLER PIPE (SLEEVE BETWEEN FILLER NECK AND TANK)
FUEL LEVEL SENSOR
FUEL TANK SUPPLY MODULE
EVAPORATIVE CANISTER
SCAVENGER AIR LINE
FUEL FEED LINE
SEAL, CANISTER-TO-LDP
VENT PIPE FROM LDP, INCLUDING DUST FILTER
SCAVENGING LINE FRONT
BREATHER LINE FROM EVAPORATIVE CANISTER
LEAK DIAGNOSTIC PUMP
FUEL PUMP CONTROL UNIT
RADIATOR (WITH DOR SYSTEM)
CHARGE AIR COOLER
GASKET, EXHAUST PIPE (BETWEEN CAT & TURBO)
CATALYST (WU-TWC)
REPLACEMENT CATALYST WITH CENTER MUFFLER (UNDERFLOOR CAT)
TORQUE CONVERTER
TRANSMISSION CONTROL MODULE (MECHATRONIK)
GAS PEDAL MODULE (AUTO)

Model = 328i, 328xi Sedan SULEV-PZEV; 428i Coupe SULEV-PZEV
Part Name
HIGH PRESSURE FUEL PUMP MOUNTING GASKET
VENT HOSE
CYLINDER HEAD COVER GASKET SET
OIL FILLER CAP
ADJUSTMENT UNIT, INTAKE CAMSHAFT
ADJUSTMENT UNIT, EXHAUST CAMSHAFT
VANOS CENTRAL (SOLENOID) VALVE
VANOS ACTUATOR
VALVETRONIC ACTUATOR
THERMOSTAT
SET INTAKE MANIFOLD GASKET
INTAKE MANIFOLD
O-RING, CHARGE AIR DUCT (THROTTLE SIDE)
O-RING, CHARGE AIR DUCT (TURBO SIDE)
VACUUM HOSE, TURBO CONTROL
COMPRESSOR BYPASS VALVE
EXHAUST MANIFOLD GASKET RING
TURBOCHARGER
VACUUM HOSE, TURBO CONTROL
VACUUM PUMP
PRESSURE CONVERTER
HEATED FRONT OXYGEN SENSOR
HEATED REAR OXYGEN SENSOR
IGNITION COIL
O-RING, CAMSENSOR
ENGINE CONTROL MODULE
ENGINE OIL TEMP SENSOR
HIGH PRESSURE FUEL PUMP
FUEL HOSE (UNDERBODY LINE-TO-FUEL INLET PIPE)
HIGH PRESSURE RAIL
FUEL INLET PIPE (TO HIGH PRESSURE PUMP)
HIGH PRESSURE PIPE (PUMP-TO-RAIL)
INJECTION VALVE O-RING
FUEL FEED LINE
HIGH PRESSURE SENSOR (FUEL)
FUEL HOSE (UNDERBODY LINE-TO-FUEL INLET PIPE)
THROTTLE BODY GASKET
THROTTLE
ENGINE COOLANT TEMP SENSOR

2014 BMW Emissions Related Parts List

Model = 328i, 328xi Sedan SULEV-PZEV; 428i Coupe SULEV-PZEV

P	art	N	а	m	e

CAMSHAFT SENSOR

CRANKSHAFT POSITION/RPM SENSOR

KNOCK SENSOR

PRESSURE SENSOR (INTAKE MANIFOLD)

MAF SENSOR

O-RING, MAF SENSOR

PRESSURE SENSOR (UPSTREAM OF THROTTLE)

INJECTION VALVE

CHARGE AIR INDUCTION TRACT (COMPRESSOR OUTLET-TO-CAC INLET)

GASKET (AIR INTAKE TUBE-TO-COMPRESSOR INLET)

INTAKE MUFFLER (MAF FITS INTO THIS)

CHARGE AIR INDUCTION TRACT (CAC TO THROTTLE HOUSING)

AIR INTAKE TUBE (AIR FILTER TO COMPRESSOR INLET, LOWER PIECE)

O-RING, CHARGE AIR DUCT (THROTTLE SIDE)

FUEL TANK PURGE VALVE W/ PIPE

FUEL TANK BREATHER LINE

CLOSURE RING, FUEL TANK UNIT

O-RING, FUEL TANK UNIT

FUEL FILLER CAP

PLASTIC FILLER PIPE

PLASTIC FUEL TANK

FILLER PIPE (SLEEVE BETWEEN FILLER NECK AND TANK)

FUEL LEVEL SENSOR

FUEL TANK SUPPLY MODULE

EVAPORATIVE CANISTER

SCAVENGER AIR LINE

FUEL FEED LINE

SEAL, CANISTER-TO-LDP

VENT PIPE FROM LDP, INCLUDING DUST FILTER

SCAVENGING LINE FRONT

BREATHER LINE FROM EVAPORATIVE CANISTER

LEAK DIAGNOSTIC PUMP

FUEL PUMP CONTROL UNIT

RADIATOR (WITH DOR SYSTEM)

CHARGE AIR COOLER

GASKET, EXHAUST PIPE (BETWEEN CAT & TURBO)

CATALYST (WU-TWC)

REPLACEMENT CATALYST WITH CENTER MUFFLER (UNDERFLOOR CAT)

TRANSMISSION CONTROL MODULE (MECHATRONIK)

TORQUE CONVERTER

GAS PEDAL MODULE (AUTO)

Part Name Cover Lid O-ring O-RING, CAMSHAFT POSITION SENSOR O-ring, vent hose Filler cap Sealing grommet Pre-formed seal Temperature sensor water/oil Preformed seal Gasket Filler cap Throttle gasket Ignition Coil Vent pipe Closure ring Closure ring Filler cap VANOS actuator Free formed seal Fuel hose Gasket Ignition Coil Camshaft sensor Vent pipe Closure ring Fuel hose Filler tank breather line Filler pressure fuel pump gasket Vent hose Vent pipe Vent pipe Vent pipe Frestressure sensor, intake manifold Fressure sensor, intake manifold Fressure sensor Fuel tank ventilation valve with pipe VANOS actuator Figh-pressure fuel pipe Sealing grommet Temperature sensor water/oil Vent pipe Fuel tank breather line Camshaft sensor Vent pipe Vent hose Vent pipe Vent hose Vent pipe Frestressure sensor Fuel tank ventilation valve with pipe Fressure sensor Fuel tank ventilation valve with pipe Fuel tank ventilation valve with pipe VANOS central valve Vanus hose Fuel fipip pressure sensor Fuel feed line Vaccelerator Pedal module, auto Vaccelerator pedal module, automatic gearbox Leak diagnosis module Control unit for fuel pipe Leak diagnosis module Alr INTAKE TUBE Control unit for fuel gaskets, intake manifold Fressure sensor Fuel or pressure fuel rail Fressure converter Fressure sensor Fuel read ince Vaccourant or pedal module, automatic gearbox Fuel Figh-pressure fuel rail Filler-pressure fuel rail	Model = 328i/ix, 328i/ix GT, 428i/ix Coupé/Convt, 428i/ix GC	Model = 228i/ix Coupé, 228i/ix Convertible		
Cover Lid O-ring O-ring O-ring O-RING, CAMSHAFT POSITION SENSOR Filler cap Sealing grommet Pre-formed seal Temperature sensor water/oil Preformed seal Filler cap Pre-formed seal Filler cap Preformed seal Filler cap Preformed seal Filler cap VANOS actuator Filigh-pressure fuel pipe Five particle sensor water/oil Vent pipe Five particle sensor water/oil Filler passet Filler passer Fil				
O-ring O-RING, CAMSHAFT POSITION SENSOR O-RING, vent hose Filler cap Sealing grommet Pre-formed seal Temperature sensor water/oil Temperature sensor, coolant Pre-formed seal Pre-formed seal Filler cap O-ring Preformed seal Filler cap O-ring Fuel hose Gasket Ignition coil Vacuum pipe Closure ring Vent pipe Pressure fuel pump gasket Vent hose Vent pipe Filler pipe Filler cap VANOS actuator Filler cap VANOS actuator Filler cap VANOS central valve Vant pipe Filler cap VantoS actuator Vent pipe Filler cap VantoS actuator Vent pipe Filler cap VantoS actuator Vent hose Filler cap VantoS actuator Vent pipe Filler cap VantoS actuator Vacuum hose Caseerator Pedal module, manual Accelerator Pedal module, auto Vacuum hose Leak diagnosis module Closure ring Casket ring O-ring Intake manifold gasket set Knock sensor Intake manifold gasket set Knock sensor Filler pipe Cntrol unit for fuel pump VantoS actuator Vacuum fore Valuer intake manifold gasket set VantoS central valve Filler cap VantoS actuator Vacuum fore Vacuum for				
O-RING, CAMSHAFT POSITION SENSOR O-ring, vent hose Sealing grommet Pre-formed seal Gasket Ignition Coil Vancuum pipe Closure ring Englier oil pressure fuel pump gasket Vent hose, cylinder head cover High-pressure fuel pump Breather sensor, intake manifold Pressure sensor, intake manifold Pressure sensor, intake manifold Pressure sensor Fuel tank ventilation valve with pipe Vancy Scavenge air line Camsh, high-pressure Fuel tank Breather Line Accelerator pedal module, automatic gearbox Leak diagnosis module Cantrol unit for fuel pump Closure ring Closure ring Vancy Scavenge air line Closure ring Closure ring Vancy Scavenge air line Closure ring Vancy Scavenge air line Closure ring Closure ring Vancy Scavenge air line Closure ring Closure ring Closure ring Vancy Scavenge air line Closure ring Closu		<u> </u>		
O-ring, vent hose Filler cap Sealing grommet Pre-formed seal Temperature sensor water/oil Temperature sensor, coolant Preformed seal Gasket Pre-formed seal Gasket Ignition Coil Vacuum pipe Closure ring Rubber boot Vent pipe O-ring Rubber boot Vent bose, cylinder head cover High-pressure sensor, intake manifold Pressure sensor, intake manifold Pressure sensor Fuel tank ventilation valve with pipe Rubber boot Vent pipe O-ring Rubber boot Vent pipe Rubber				
Filler cap Sealing grommet Pre-formed seal Temperature sensor water/oil Temperature sensor, coolant Preformed seal Pre-formed seal Gasket Pre-formed seal Ignition Coil Vent pipe Closure ring Engine oil pressure/temperature sensor Went hose, cylinder head cover High pressure sensor Fuel tank ventilation valve with pipe Pressure sensor Fuel tank ventilation valve Fuel feed line VANOS central valve Filler pipe Accelerator Pedal module, manual Sensor, high-pressure Fuel Tank Breather Line Closure ring Closure ring Closure ring Closure ring Closure ring Casket ring Casket ring Casket ring Casket ring Co-ring Closure ring Closure ring Casket ring Co-ring Closure ring Closure ring Closure ring Closure ring Casket ring Co-ring Closure ring Clo	·			
Sealing grommet Pre-formed seal Temperature sensor water/oil Temperature sensor, coolant Preformed seal Gasket Gasket Ignition coil Ignition c				
Temperature sensor water/oil Temperature sensor water/oil Vent pipe O-ring	•	9 1		
Temperature sensor water/oil Temperature sensor, coolant Preformed seal Gasket Pre-formed seal Gasket Pre-formed seal Gasket Ignition Coil Gasket Ignition Coil Gasket Ignition Coil Fuel tank breather line Camshaft sensor High-pressure fuel pump gasket Vent hose Went pipe Pressure pipe Uent pipe Pressure sensor, intake manifold Pressure sensor Fuel tank ventilation valve with pipe Pulse generator Scavenge air line Filler pipe Accelerator Pedal module, manual Accelerator Pedal module, auto Vacuum hose Leak diagnosis module Closure ring Gasket ring O-ring Intake manifold gasket set Knock sensor High-pressure fuel rail Pressure converter				
Temperature sensor, coolant Preformed seal Gasket Throttle gasket Ignition coil Gasket Ignition coil Gasket Ignition coil Fuel tank breather line Camshaft sensor Vacuum pipe Closure ring Vent hose Engine oil pressure/temperature sensor Rubber boot Vent hose, cylinder head cover High-pressure sensor Rubber sensor Vent pipe Breather line O-ring Vant wentilation valve with pipe Intake manifold pressure sensor Fuel feed line VANOS central valve Filler pipe VANOS Actuator Season, high-pressure Filler pipe Camshaft sensor Filler pipe Fuel tank ventilation valve with pipe Filler pipe CAMSHAFT POSITION SENSOR Accelerator pedal module, manual gearbox Fuel tank beather Line Cansel module, automatic gearbox Leak diagnosis module VANOS central valve Filler pipe Casket ring Casket Igniton coil Fuel tank breather line Intake manifold pressure sensor Fuel tank ventilation valve with pipe VANOS Actuator Scavenge air line Filler pipe Cacelerator pedal module, manual gearbox Leak diagnosis module Casket ring Casket ring Control unit for fuel pump Pressure converter	Pre-formed seal	Temperature sensor water/oil		
Preformed seal Gasket Pre-formed seal Gasket Pre-formed seal Gasket Ignition coil Ignition Coil Vacuum pipe Closure ring Rubber boot Vent hose, cylinder head cover High pressure pipe O-ring Pressure sensor, intake manifold Pressure sensor Fuel tank ventilation valve with pipe Pressure sensor Fuel fank pressure pipe O-ring Accelerator pedal module, manual gearbox Fuel Tank Breather Line Closure ring Accelerator pedal module, automatic gearbox Leak diagnosis module Control unit for fuel pump Pressure converter Pressure converter Pressure converter	Temperature sensor water/oil	Vent pipe		
Gasket Pre-formed seal Gasket Ignition coil Gasket Vacuum pipe Closure ring Engine oil pressure/temperature sensor Went hose, cylinder head cover High-pressure pipe O-ring Vent pipe Pressure sensor, intake manifold Pressure sensor Fuel tank ventilation valve with pipe VaNOS central valve Accelerator Pedal module, manual gearbox Eugh rose, rose Racelerator pedal module, automatic gearbox Leak diagnosis module Control unit for fuel pump Teuel tank linghteressure fine Ignition coil Fuel tank breather line Ignition coil Fuel tank ventile pump gasket Vent hose Vent pipe Themostat Vent pipe Breather line Intake manifold pressure sensor Fuel feed line VANOS central valve Fuel high pressure sensor Fuel tank ventilation valve with pipe VANOS central valve Fuel high pressure sensor Fuel tank ventilation valve with pipe Pulse generator Scavenge air line Filler pipe Accelerator Pedal module, manual Accelerator Pedal module, auto Vacuum hose Leak diagnosis module Closure ring Gasket ring O-ring Intake manifold gasket set Knock sensor High-pressure fuel rail Pressure converter	Temperature sensor, coolant	O-ring		
Pre-formed seal Gasket Ignition Coil Gasket Ignition Coil Gasket Ignition Coil Fuel tank breather line Camshaft sensor High-pressure fuel pump gasket Vent hose Engine oil pressure/temperature sensor Rubber boot Vent hose, cylinder head cover High pressure pipe O-ring O-ring Vent pipe Pressure sensor, intake manifold Pressure sensor, intake manifold Pressure sensor Fuel feed line VANOS central valve Pressure sensor Fuel tank ventilation valve with pipe VANOS Actuator Scavenge air line Filler pipe CAMSHAFT POSITION SENSOR Accelerator Pedal module, manual gearbox Fuel Tank Breather Line Closure ring Casket Ignition coil Fuel tank breather line Fugh-pressure fuel pump gasket Vent hose Vent pipe Vent pipe Thermostat Fuel tank ventilation valve with pipe Wanifold pressure sensor Fuel feed line VANOS central valve Fuel high pressure sensor Fuel high pressure sensor Fuel high pressure sensor Fuel pipe Accelerator Pedal module, manual Accelerator Pedal module, manual Closure ring Casket ring Casket ring Casket ring Casket ring Acrelerator pedal module Arcolerator pedal module Corring Fuel Facel Fuel	Preformed seal	Fuel hose		
Gasket Ignition Coil Camshaft sensor High-pressure fuel pump gasket Vent hose Vent pipe Thermostat Fuel tank ventilation valve with pipe Breather line Intake manifold pressure sensor Fuel tank ventilation valve with pipe Fuel feed line VANOS central valve Fuel tank ventilation valve with pipe Fuel tank ventilation valve with pipe Fuel feed line VANOS central valve Fuel high pressure sensor Fuel high pressure sensor Fuel tank ventilation valve with pipe Pulse generator Scavenge air line Filler pipe Accelerator Pedal module, manual Accelerator Pedal module, auto Vacuum hose Leak diagnosis module Closure ring Gasket ring Closure ring Casket ring Change of the control valve Control unit for fuel pump Pressure fuel rail Pressure fuel rail Pressure fuel rail Pressure converter	Gasket	Throttle gasket		
Camshaft sensor High-pressure fuel pump gasket	Pre-formed seal	Ignition coil		
Vacuum pipe Closure ring Engine oil pressure/temperature sensor Rubber boot Vent hose, cylinder head cover High pressure pipe O-ring Vent pipe Pressure sensor, intake manifold Pressure sensor Fuel tank ventilation valve with pipe Fuel feed line VANOS central valve Fuel high pressure sensor Fuel tank ventilation valve Fuel sensor Fuel tank ventilation valve Fuel fine Filler pipe CAMSHAFT POSITION SENSOR Sensor, high-pressure Fuel Feed Line Accelerator pedal module, manual gearbox Fuel Tank Breather Line Accelerator pedal module, automatic gearbox Leak diagnosis module Scavenge air line Scavenge air line Chancelerator pedal module, automatic gearbox Leak diagnosis module Scavenge air line Intake manifold gasket set VANOS central valve Arnos central valve arn	Gasket	Fuel tank breather line		
Closure ring Engine oil pressure/temperature sensor Rubber boot Vent hose, cylinder head cover High pressure pipe O-ring Vent pipe Pressure sensor, intake manifold Pressure sensor Fuel tank ventilation valve with pipe VANOS central valve Pressure sensor Fuel tank ventilation valve with pipe VANOS Actuator Seasor, high-pressure Filler pipe Accelerator pedal module, manual gearbox Fuel Tank Breather Line Accelerator pedal module, automatic gearbox Leak diagnosis module VANOS central valve Filler pipe Accelerator Pedal module, automatic gearbox Leak diagnosis module Vacuum hose Cosure ring Gasket ring O-ring Intake manifold gasket set Knock sensor AIR INTAKE TUBE Control unit for fuel pump Perssure ventilation valve with pipe VANOS central valve Fuel feed line VANOS central valve Fuel high pressure sensor Fuel high pressure fuel rail Fuel tank ventilation valve with pipe VANOS central valve Fuel feed line Vacuum hose Leak diagnosis module Closure ring Gasket ring O-ring Intake manifold gasket set Knock sensor	Ignition Coil	Camshaft sensor		
Engine oil pressure/temperature sensor Rubber boot Vent hose, cylinder head cover High pressure pipe O-ring Vent pipe Pressure sensor, intake manifold Pressure sensor Fuel tank ventilation valve with pipe Fressure sensor Fuel tank ventilation valve with pipe Pressure sensor Fuel tank ventilation valve with pipe Pressure sensor Fuel high pressure sensor Pulse generator Scavenge air line Filler pipe CAMSHAFT POSITION SENSOR Accelerator Pedal module, manual Sensor, high-pressure Fuel Feed Line Accelerator pedal module, manual gearbox Fuel Tank Breather Line Cake diagnosis module Closure ring Casket ring O-ring Intake manifold gasket set Knock sensor AIR INTAKE TUBE Control unit for fuel pump Vent pipe Thermostat Fuel tank ventilation valve with pipe Breather line Fuel tank ventilation valve with pipe Breather line VANOS central valve Accelerator pedal module, walve Fuel Fassure fuel rail Pressure converter	Vacuum pipe	High-pressure fuel pump gasket		
Rubber boot Vent hose, cylinder head cover High pressure pipe O-ring Pressure sensor, intake manifold Pressure sensor Fuel tank ventilation valve with pipe Pressure sensor, intake manifold Pressure sensor Fuel tank ventilation valve Pressure sensor Fuel tank pressure Fuel pigh pressure sensor Pulse generator Scavenge air line Filler pipe Accelerator Pedal module, manual Sensor, high-pressure Fuel Feed Line Accelerator pedal module, manual gearbox Fuel Tank Breather Line Closure ring Gasket ring O-ring Gasket ring O-ring Intake manifold gasket set Knock sensor Alr INTAKE TUBE Control unit for fuel pump Thermostat Fuel tank ventilation valve with pipe Breather line Intake manifold pressure sensor Fuel feed line VANOS central valve with pipe Fuel feed line VANOS central valve Fuel feed line VANOS central va	Closure ring	Vent hose		
Vent hose, cylinder head cover High pressure pipe O-ring Pressure sensor, intake manifold Pressure sensor Fuel tank ventilation valve with pipe Pressure sensor, intake manifold Pressure sensor Fuel tank ventilation valve Pressure sensor Fuel tank ventilation valve with pipe VANOS actuator VANOS Actuator Scavenge air line Filler pipe CAMSHAFT POSITION SENSOR Sensor, high-pressure Accelerator Pedal module, manual Accelerator Pedal module, auto Vacuum hose Leak diagnosis module Fuel Tank Breather Line Accelerator pedal module, automatic gearbox Leak diagnosis module Scavenge air line VanoS central valve Alr INTAKE TUBE Control unit for fuel pump Fuel tank ventilation valve with pipe Breather line Intake manifold pressure sensor Fuel feed line VANOS central valve with pipe Fuel feed line VanoS central valve with pipe Fuel feed line VanoS central valve with pipe Fuel feed line VanoS central valve Fuel feed line Fuel feed line VanoS central valve Fuel feed line Fuel feed line VanoS central valve with pipe Fuel feed line Fuel feed line VanoS central valve with pipe Fuel feed line VanoS central valve with pipe Fuel feed line Fuel feed line VanoS central valve with pipe Fuel feed line Fuel feed line VanoS central valve with pipe Fuel feed line Fuel feed line VanoS central valve with pipe Fuel feed line Fuel feed line VanoS central valve Fuel feed line Fuel feed line Fuel feed line VanoS central valve Fuel feed line Fuel feed	Engine oil pressure/temperature sensor	Vent pipe		
High pressure pipe O-ring Intake manifold pressure sensor Fuel feed line VANOS central valve Pressure sensor Fuel tank ventilation valve with pipe VANOS Actuator Scavenge air line CAMSHAFT POSITION SENSOR Accelerator Pedal module, manual Sensor, high-pressure Accelerator pedal module, manual gearbox Fuel Tank Breather Line Accelerator pedal module, automatic gearbox Leak diagnosis module Scavenge air line CIosure ring Casket ring C-ring Scavenge air line Intake manifold gasket set VANOS central valve Accelerator Pedal module, auto Fuel Feed Line Accelerator pedal module, auto Closure ring Casket ring C-ring Intake manifold gasket set Knock sensor High-pressure fuel rail Pressure converter	Rubber boot	Thermostat		
O-ring Vent pipe Pressure sensor, intake manifold Pressure sensor Fuel tank ventilation valve with pipe VANOS Actuator VANOS Actuator breather line CAMSHAFT POSITION SENSOR Accelerator Pedal module, manual Sensor, high-pressure Accelerator pedal module, manual gearbox Fuel Tank Breather Line Accelerator pedal module, automatic gearbox Leak diagnosis module Scavenge air line Closure ring Gasket ring O-ring Intake manifold pressure sensor Fuel feed line VANOS central valve Accelerator Closure ring Gasket ring O-ring Intake manifold pressure sensor Fuel feed line VANOS central valve Accelerator Alr INTAKE TUBE Control unit for fuel pump Intake manifold pressure sensor Fuel feed line VANOS central valve Fuel high pressure sensor	Vent hose, cylinder head cover	Fuel tank ventilation valve with pipe		
Vent pipeFuel feed linePressure sensor, intake manifoldVANOS central valvePressure sensorFuel high pressure sensorFuel tank ventilation valve with pipePulse generatorVANOS ActuatorScavenge air linebreather lineFiller pipeCAMSHAFT POSITION SENSORAccelerator Pedal module, manualSensor, high-pressureAccelerator Pedal module, autoFuel Feed LineVacuum hoseAccelerator pedal module, manual gearboxLeak diagnosis moduleFuel Tank Breather LineClosure ringAccelerator pedal module, automatic gearboxGasket ringLeak diagnosis moduleO-ringScavenge air lineIntake manifold gasket setVANOS central valveKnock sensorAIR INTAKE TUBEHigh-pressure fuel railControl unit for fuel pumpPressure converter	High pressure pipe	Breather line		
Pressure sensor, intake manifold Pressure sensor Fuel tank ventilation valve with pipe VANOS Actuator VANOS Actuator Breather line CAMSHAFT POSITION SENSOR Sensor, high-pressure Fuel Feed Line Accelerator pedal module, manual gearbox Fuel Tank Breather Line Accelerator pedal module, automatic gearbox Leak diagnosis module Scavenge air line Vacuum hose Closure ring Gasket ring O-ring Scavenge air line VanoS central valve Knock sensor High-pressure fuel rail Pressure converter	O-ring	Intake manifold pressure sensor		
Fuel high pressure sensor Fuel tank ventilation valve with pipe VANOS Actuator breather line CAMSHAFT POSITION SENSOR Sensor, high-pressure Fuel Feed Line Accelerator pedal module, manual gearbox Fuel Tank Breather Line Accelerator pedal module, automatic gearbox Leak diagnosis module Accelerator pedal module, automatic gearbox Leak diagnosis module Closure ring Gasket ring O-ring Intake manifold gasket set VANOS central valve AIR INTAKE TUBE Control unit for fuel pump Fuel high pressure sensor Pulse generator Scavenge air line Fuller pipe Accelerator Pedal module, manual Vacuum hose Leak diagnosis module Closure ring Gasket ring O-ring Intake manifold gasket set Knock sensor High-pressure fuel rail Pressure converter	Vent pipe	Fuel feed line		
Fuel tank ventilation valve with pipe VANOS Actuator breather line CAMSHAFT POSITION SENSOR Sensor, high-pressure Fuel Feed Line Accelerator pedal module, manual gearbox Fuel Tank Breather Line Accelerator pedal module, automatic gearbox Leak diagnosis module Scavenge air line Vacuum hose Leak diagnosis module Closure ring Gasket ring O-ring Intake manifold gasket set VANOS central valve AIR INTAKE TUBE Control unit for fuel pump Pulse generator Scavenge air line Vacelerator Scavenge air line Vacelerator Pedal module, manual Accelerator Pedal module, auto Vacuum hose Leak diagnosis module Closure ring Gasket ring O-ring Intake manifold gasket set Knock sensor High-pressure fuel rail Pressure converter	Pressure sensor, intake manifold	VANOS central valve		
VANOS Actuator breather line CAMSHAFT POSITION SENSOR Sensor, high-pressure Fuel Feed Line Accelerator pedal module, manual gearbox Fuel Tank Breather Line Accelerator pedal module, automatic gearbox Leak diagnosis module Leak diagnosis module Scavenge air line Vacuum hose Leak diagnosis module Closure ring Gasket ring O-ring Scavenge air line VANOS central valve AIR INTAKE TUBE Control unit for fuel pump Scavenge air line Filler pipe Accelerator Pedal module, manual Accelerator Pedal module, auto Vacuum hose Leak diagnosis module Closure ring Gasket ring O-ring Intake manifold gasket set Knock sensor High-pressure fuel rail Pressure converter	Pressure sensor	Fuel high pressure sensor		
Filler pipe CAMSHAFT POSITION SENSOR Sensor, high-pressure Fuel Feed Line Accelerator pedal module, auto Vacuum hose Leak diagnosis module Closure ring Casket ring Coring Scavenge air line VANOS central valve AIR INTAKE TUBE COntrol unit for fuel pump Filler pipe Accelerator Pedal module, manual Accelerator Pedal module, auto Vacuum hose Leak diagnosis module Closure ring Casket ring O-ring Intake manifold gasket set Knock sensor High-pressure fuel rail Pressure converter	Fuel tank ventilation valve with pipe	Pulse generator		
CAMSHAFT POSITION SENSOR Sensor, high-pressure Fuel Feed Line Accelerator pedal module, manual gearbox Fuel Tank Breather Line Accelerator pedal module, automatic gearbox Leak diagnosis module Closure ring Gasket ring O-ring Scavenge air line VANOS central valve AIR INTAKE TUBE Control unit for fuel pump Accelerator Pedal module, manual Accelerator Pedal module,	VANOS Actuator	Scavenge air line		
Sensor, high-pressure Fuel Feed Line Accelerator pedal module, manual gearbox Fuel Tank Breather Line Accelerator pedal module, automatic gearbox Leak diagnosis module Closure ring Gasket ring O-ring Scavenge air line VANOS central valve AIR INTAKE TUBE Control unit for fuel pump Accelerator Pedal module, automatic Vacuum hose Leak diagnosis module Closure ring Gasket ring O-ring Intake manifold gasket set Knock sensor High-pressure fuel rail Pressure converter	breather line	Filler pipe		
Fuel Feed Line Accelerator pedal module, manual gearbox Fuel Tank Breather Line Accelerator pedal module, automatic gearbox Leak diagnosis module Closure ring Gasket ring O-ring Intake manifold gasket set VANOS central valve AIR INTAKE TUBE Control unit for fuel pump Vacuum hose Leak diagnosis module Closure ring Gasket ring High-pressure fuel rail Pressure converter	CAMSHAFT POSITION SENSOR	Accelerator Pedal module, manual		
Accelerator pedal module, manual gearbox Fuel Tank Breather Line Closure ring Gasket ring Casket ring O-ring Scavenge air line VANOS central valve AIR INTAKE TUBE Control unit for fuel pump Leak diagnosis module Closure ring Gasket ring Intake manifold gasket set Knock sensor High-pressure fuel rail Pressure converter	Sensor, high-pressure	Accelerator Pedal module, auto		
Fuel Tank Breather Line Accelerator pedal module, automatic gearbox Leak diagnosis module Scavenge air line VANOS central valve AIR INTAKE TUBE Closure ring Gasket ring O-ring Intake manifold gasket set Knock sensor High-pressure fuel rail Pressure converter		Vacuum hose		
Fuel Tank Breather Line Accelerator pedal module, automatic gearbox Leak diagnosis module Scavenge air line VANOS central valve AIR INTAKE TUBE Closure ring Gasket ring O-ring Intake manifold gasket set Knock sensor High-pressure fuel rail Pressure converter	Accelerator pedal module, manual gearbox	Leak diagnosis module		
Leak diagnosis moduleO-ringScavenge air lineIntake manifold gasket setVANOS central valveKnock sensorAIR INTAKE TUBEHigh-pressure fuel railControl unit for fuel pumpPressure converter		Closure ring		
Leak diagnosis moduleO-ringScavenge air lineIntake manifold gasket setVANOS central valveKnock sensorAIR INTAKE TUBEHigh-pressure fuel railControl unit for fuel pumpPressure converter	Accelerator pedal module, automatic gearbox	Gasket ring		
Scavenge air line VANOS central valve AIR INTAKE TUBE Control unit for fuel pump Intake manifold gasket set Knock sensor High-pressure fuel rail Pressure converter		3		
VANOS central valve AIR INTAKE TUBE Control unit for fuel pump Knock sensor High-pressure fuel rail Pressure converter				
AIR INTAKE TUBE Control unit for fuel pump High-pressure fuel rail Pressure converter		The state of the s		
Control unit for fuel pump Pressure converter				
		<u> </u>		
	Set of profile gaskets, intake manifold	Fuel pump control unit		

Model = 328i/ix, 328i/ix GT, 428i/ix
Coupé/Convertible, 428i/ix GC
Don't Name
Part Name
Vent pipe
THERMOSTAT
Fuel feed line
Gasket ring
Crankshaft sensor
Charge-air duct, turbo to CAC
Gasket Ring
LAMBDA PROBE, O2 Sensor
Knock Sensor
Charge-air duct, between CAC and turbocharger
Intake silencer
Intake silencer, M Sports Package
High-pressure rail
Hot-film air mass meter
Actuator
Throttle
Delivery module
Gasket set, cylinder head cover
Injector
Activated Charcoal Filter
Charge-air cooler
Radiator
FILLER PIPE
Vacuum pump
Intake manifold system
FILLER PIPE VALVETRONIC ACUTATOR
Blow-off valve
High-pressure pump
Adjustment unit, outlet camshaft
Adjustment unit, inlet camshaft
Plastic fuel tank
Exchange catalyst
Basic control unit DME
Exchange catalyst with center silencer
EXCH-TURBO CHARGER
Repair kit, torque converter
Trans Control Module, Mechatronics
,

Part Name Lambda probe sensor Regulating lambda probe Turbo actuator Gasket ring Hot-film air mass meter Intake silencer Throttle Fuel injector EVAP canister Gasket set, cylinder head cover Delivery module Vacuum pump Exhaust manifold gasket ring Plastic filler pipe Intake manifold system Valvetronic actuator Blow-off valve High-pressure fuel pump Adjustment unit, outlet camshaft Adjustment unit, inlet camshaft Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst Radiator	Model = 228i/ix Coupé, 228i/ix Convertible
Lambda probe sensor Regulating lambda probe Turbo actuator Gasket ring Hot-film air mass meter Intake silencer Throttle Fuel injector EVAP canister Gasket set, cylinder head cover Delivery module Vacuum pump Exhaust manifold gasket ring Plastic filler pipe Intake manifold system Valvetronic actuator Blow-off valve High-pressure fuel pump Adjustment unit, outlet camshaft Adjustment unit, inlet camshaft Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	
Regulating lambda probe Turbo actuator Gasket ring Hot-film air mass meter Intake silencer Throttle Fuel injector EVAP canister Gasket set, cylinder head cover Delivery module Vacuum pump Exhaust manifold gasket ring Plastic filler pipe Intake manifold system Valvetronic actuator Blow-off valve High-pressure fuel pump Adjustment unit, outlet camshaft Adjustment unit, inlet camshaft Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	Part Name
Regulating lambda probe Turbo actuator Gasket ring Hot-film air mass meter Intake silencer Throttle Fuel injector EVAP canister Gasket set, cylinder head cover Delivery module Vacuum pump Exhaust manifold gasket ring Plastic filler pipe Intake manifold system Valvetronic actuator Blow-off valve High-pressure fuel pump Adjustment unit, outlet camshaft Adjustment unit, inlet camshaft Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	
Turbo actuator Gasket ring Hot-film air mass meter Intake silencer Throttle Fuel injector EVAP canister Gasket set, cylinder head cover Delivery module Vacuum pump Exhaust manifold gasket ring Plastic filler pipe Intake manifold system Valvetronic actuator Blow-off valve High-pressure fuel pump Adjustment unit, outlet camshaft Adjustment unit, inlet camshaft Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	·
Gasket ring Hot-film air mass meter Intake silencer Throttle Fuel injector EVAP canister Gasket set, cylinder head cover Delivery module Vacuum pump Exhaust manifold gasket ring Plastic filler pipe Intake manifold system Valvetronic actuator Blow-off valve High-pressure fuel pump Adjustment unit, outlet camshaft Adjustment unit, inlet camshaft Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	<u> </u>
Hot-film air mass meter Intake silencer Throttle Fuel injector EVAP canister Gasket set, cylinder head cover Delivery module Vacuum pump Exhaust manifold gasket ring Plastic filler pipe Intake manifold system Valvetronic actuator Blow-off valve High-pressure fuel pump Adjustment unit, outlet camshaft Adjustment unit, inlet camshaft Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	
Intake silencer Throttle Fuel injector EVAP canister Gasket set, cylinder head cover Delivery module Vacuum pump Exhaust manifold gasket ring Plastic filler pipe Intake manifold system Valvetronic actuator Blow-off valve High-pressure fuel pump Adjustment unit, outlet camshaft Adjustment unit, inlet camshaft Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	<u> </u>
Throttle Fuel injector EVAP canister Gasket set, cylinder head cover Delivery module Vacuum pump Exhaust manifold gasket ring Plastic filler pipe Intake manifold system Valvetronic actuator Blow-off valve High-pressure fuel pump Adjustment unit, outlet camshaft Adjustment unit, inlet camshaft Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	
Fuel injector EVAP canister Gasket set, cylinder head cover Delivery module Vacuum pump Exhaust manifold gasket ring Plastic filler pipe Intake manifold system Valvetronic actuator Blow-off valve High-pressure fuel pump Adjustment unit, outlet camshaft Adjustment unit, inlet camshaft Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	
EVAP canister Gasket set, cylinder head cover Delivery module Vacuum pump Exhaust manifold gasket ring Plastic filler pipe Intake manifold system Valvetronic actuator Blow-off valve High-pressure fuel pump Adjustment unit, outlet camshaft Adjustment unit, inlet camshaft Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	
Gasket set, cylinder head cover Delivery module Vacuum pump Exhaust manifold gasket ring Plastic filler pipe Intake manifold system Valvetronic actuator Blow-off valve High-pressure fuel pump Adjustment unit, outlet camshaft Adjustment unit, inlet camshaft Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	-
Delivery module Vacuum pump Exhaust manifold gasket ring Plastic filler pipe Intake manifold system Valvetronic actuator Blow-off valve High-pressure fuel pump Adjustment unit, outlet camshaft Adjustment unit, inlet camshaft Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	
Vacuum pump Exhaust manifold gasket ring Plastic filler pipe Intake manifold system Valvetronic actuator Blow-off valve High-pressure fuel pump Adjustment unit, outlet camshaft Adjustment unit, inlet camshaft Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	
Exhaust manifold gasket ring Plastic filler pipe Intake manifold system Valvetronic actuator Blow-off valve High-pressure fuel pump Adjustment unit, outlet camshaft Adjustment unit, inlet camshaft Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	
Plastic filler pipe Intake manifold system Valvetronic actuator Blow-off valve High-pressure fuel pump Adjustment unit, outlet camshaft Adjustment unit, inlet camshaft Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	
Intake manifold system Valvetronic actuator Blow-off valve High-pressure fuel pump Adjustment unit, outlet camshaft Adjustment unit, inlet camshaft Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	
Valvetronic actuator Blow-off valve High-pressure fuel pump Adjustment unit, outlet camshaft Adjustment unit, inlet camshaft Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	
Blow-off valve High-pressure fuel pump Adjustment unit, outlet camshaft Adjustment unit, inlet camshaft Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	-
High-pressure fuel pump Adjustment unit, outlet camshaft Adjustment unit, inlet camshaft Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	
Adjustment unit, outlet camshaft Adjustment unit, inlet camshaft Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	
Adjustment unit, inlet camshaft Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	, , , , , , , , , , , , , , , , , , ,
Plastic fuel tank Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	·
Exchange catalyst Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	
Basic control unit DME Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	Plastic fuel tank
Turbocharger Repair kit, torque converter Repair kit, mechatronics Catalyst	
Repair kit, torque converter Repair kit, mechatronics Catalyst	Basic control unit DME
Repair kit, mechatronics Catalyst	Turbocharger
Catalyst	Repair kit, torque converter
Radiator	
	Radiator

2016 BMW Emissions Related Parts List
228i Coupe, 228iX Coupe, 228i Convertible, 228iX Convertible
Part Name
RADIATOR
VALVE COVER GASKETS [GASKET SET, CYLINDER HEAD COVER]
OIL FILLER CAP
POSITIVE CRANKCASE VENTILATION GASKET [VENT HOSE O-RING]
POSITIVE CRANKCASE VENTILATION [VENT HOSE]
CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR]
CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING]
TEMPERATURE SENSOR [TEMPERATUR SENSOR WATER/OIL]
VALVETRONIC ACTUATOR [ECCENTRIC SHAFT ACTUATOR]
CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR]
KNOCK SENSOR [PING SENSOR]
INTAKE MANIFOLD CASKET(S)
INTAKE MANIFOLD GASKET(S) INTAKE MANIFOLD PRESSURE SENSOR
EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT
INTAKE CAMSHAFT POSITION ADJUSTMENT UNIT
TIMING CHAIN
VANOS VVT ACTUATOR
VANOS VVT AGTOATON VANOS VVT CENTRAL VALVE
EXHAUST MANIFOLD GASKET
TURBOCHARGER
TURBOCHARGER BYPASS [ELECTR. BLOW-OFF VALVE]
TURBOCHARGER WASTEGATE ACTUATOR [TURBOCHARGER DRIVE MOTOR]
THERMOSTAT
ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME]
IGNITION COIL
CHARGE AIR DUCT PRESSURE SENSOR
FRESH AIR INTAKE TUBE (INTAKE TO TURBOCHARGER)
FRESH AIR INTAKE TUBE GASKET/O-RING (INTAKE TO TURBOCHARGER)
LEFT CHARGE AIR DUCT (CAC TO THROTTLE)
LEFT CHARGE AIR DUCT GASKET/O-RING (CAC TO THROTTLE)
RIGHT CHARGE AIR DUCT (TURBOCHARGER TO CAC)
RIGHT CHARGE AIR DUCT GASKET/O-RING (TURBOCHARGER TO CAC)
CANISTER PURGE VALVE [FUEL TANK VENTILATION VALVE]
FUEL TANK BREATHER LINE
FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE]
FUEL LINE [FEED LINE]
HIGH-PRESSURE FUEL PUMP
HIGH-PRESSURE FUEL PUMP O-RING
FUEL INJECTOR
FUEL INJECTOR GASKET RING

2016 BMW Emissions Related Parts List
228i Coupe, 228iX Coupe, 228i Convertible, 228iX Convertible
Part Name
FUEL INJECTOR GASKET RING
FUEL RAIL SENSOR [SENSOR, HIGH-PRESSURE]
FUEL RAIL [HIGH-PRESSURE RAIL]
AIR CLEANER [INTAKE MUFFLER]
MASS AIRFLOW SENSOR (MAF) [HOT-FILM AIR MASS METER]
THROTTLE BODY
THROTTLE BODY GASKET
EVAPORATIVE EMISSION CANISTER BREATHER LINE
EVAPORATIVE EMISSION CANISTER SEALING GROMMET [ACTIVATED CHARCOAL FILTER]
EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER]
EVAPORATIVE VENT PIPE
NATURAL VACUUM LEAKAGE DETECTION SWITCH [LEAK DIAGNOSIS MODULE]
FUEL PUMP CONTROL MODULE [CONTROL UNIT FOR FUEL PUMP]
FUEL PUMP O-RING [DELIVERY MODULE O-RING]
FUEL PUMP CLOSURE RING
FUEL PUMP O-RING [DELIVERY MODULE O-RING]
FUEL PUMP [DELIVERY MODULE]
FUEL LINE [FEED LINE]
SCAVENGE AIR LINE
FUEL FILLER CAP
FUEL FILLER PIPE
FUEL FILLER PIPE EXTENSION
FUEL TANK
FUEL TANK VENT PIPE
CHARGE AIR COOLER
FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE]
REAR HEATED OXYGEN SENSOR [MONITORING LAMBDA PROBE]
CATALYTIC CONVERTER
CATALYTIC CONVERTER GASKET
TRANSMISSION CONTROL MODULE [MECHATRONIC]
TORQUE CONVERTER
ACCELERATOR PEDAL, AUTOMATIC
ACCELERATOR PEDAL, MANUAL

328i SULEV, 328i SA SULEV 328iX SA SULEV, 328xDrive GT SULEV,

P	ar	ŀΝ	Ja	m	e

ACCELERATOR PEDAL, AUTOMATIC

AIR CLEANER [INTAKE MUFFLER]

CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR]

CAMSHAFT POSITION SENSOR O-RING [PULSE GENERATOR O-RING]

CANISTER PURGE VALVE [FUEL TANK VENTILATION VALVE]

CATALYTIC CONVERTER

CATALYTIC CONVERTER GASKET

CHARGE AIR COOLER

CHARGE AIR DUCT PRESSURE SENSOR

CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR]

ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME]

ENGINE COOLANT TEMPERATURE SENSOR [TEMPERATUR SENSOR WATER/OIL]

EVAPORATIVE EMISSION CANISTER BREATHER LINE

EVAPORATIVE EMISSION CANISTER SEALING GROMMET [ACTIVATED CHARCOAL FILTER]

EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER]

EVAPORATIVE VENT PIPE

EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT

EXHAUST MANIFOLD GASKET

FRESH AIR INTAKE TUBE (INTAKE TO TURBOCHARGER)

FRESH AIR INTAKE TUBE GASKET/ O-RING (INTAKE TO TURBOCHARGER)

FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE]

FRONT FUEL LINE [FUEL FEED LINE]

FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE]

FUEL FILLER CAP

FUEL FILLER PIPE

FUEL FILLER PIPE EXTENSION

FUEL INJECTOR (CYLINDER 1 OR 2)

FUEL INJECTOR (CYLINDER 3 OR 4)

FUEL PUMP CLOSURE RING

FUEL PUMP CONTROL MODULE [CONTROL UNIT FOR FUEL PUMP]

FUEL PUMP GASKET [DELIVERY MODULE GASKET]

FUEL PUMP O-RING [DELIVERY MODULE O-RING]

FUEL PUMP [DELIVERY MODULE WITH LEVEL SENDER]

FUEL RAIL PRESSURE SENSOR [SENSOR, HIGH-PRESSURE]

FUEL RAIL [HIGH-PRESSURE RAIL]

FUEL TANK

FUEL TANK BREATHER LINE

FUEL TANK VENT PIPE

HIGH-PRESSURE FUEL PUMP

IGNITION COIL

INTAKE CAMSHAFT POSITION ADJUSTMENT UNIT

INTAKE MANIFOLD

INTAKE MANIFOLD GASKET(S)

KNOCK SENSOR (CYLINDER 1-2) [PING SENSOR]

2016 BMW Emissions Related Parts List	
328i SULEV, 328i SA SULEV 328iX SA SULEV, 328xDrive GT SULEV,	
Part Name	
Part Name	
KNOCK SENSOR (CYLINDER 3-4) [PING SENSOR]	
LEFT CHARGE AIR DUCT (CAC TO THROTTLE)	
LEFT CHARGE AIR DUCT GASKET O-RING (CAC TO THROTTLE)	
MANIFOLD ABSOLUTE PRESSURE SENSOR (MAP) [INTAKE MANIFOLD PRESSURE SENSOR]	
MASS AIRFLOW SENSOR (MAF) [HOT-FILM AIR MASS METER]	
NATURAL VACUUM LEAKAGE DETECTION SWITCH [LEAK DIAGNOSIS MODULE]	
OIL FILLER CAP	
OIL PRESSURE AND TEMPERATURE SENSOR	
OIL PRESSURE AND TEMPERATURE SENSOR GASKET	
POSITIVE CRANKCASE VENTILATION O-RING	
POSITIVE CRANKCASE VENTILATION [VENT HOSE]	
RADIATOR	
REAR FUEL LINE [FEED LINE]	
REAR HEATED OXYGEN SENSOR [MONITORING LAMBDA PROBE]	
RIGHT CHARGE AIR DUCT (TURBOCHARGER TO CAC)	
RIGHT CHARGE AIR DUCT GASKET/O-RING (TURBOCHARGER TO CAC)	
SCAVENGE AIR LINE	
THERMOSTAT	
THROTTLE BODY	
THROTTLE BODY GASKET	
TIMING CHAIN	
TORQUE CONVERTER	
TRANSMISSION CONTROL MODULE [MECHATRONIC]	
TURBOCHARGER TURBOCHARGER BY DAGGER LOW OFF VALVET	
TURBOCHARGER BYPASS [BLOW-OFF VALVE]	
TURBOCHARGER WASTEGATE ACTUATOR [TURBOCHARGER DRIVE MOTOR]	
VALVE COVER GASKETS [GASKET SET, CYLINDER HEAD COVER]	
VALVETRONIC ACTUATOR [ECCENTRIC SHAFT ACTUATOR] VANOS VVT ACTUATOR	
VANOS VVT ACTUATOR VANOS VVT CENTRAL VALVE	
VAINUO VVI UEINI KAL VALVE	

2016 BMW Emissions Related Parts List
428i Coupe SULEV
428iX Coupe SULEV
428i Convertible SULEV
428iX Convertible SULEV
428i Gran Coupé SULEV
428iX Gran Coupé SULEV
illost Gran Odapo COLLY
Part Name
DADIATOR
RADIATOR
ACCELERATOR PEDAL, AUTOMATIC
AIR CLEANER [INTAKE MUFFLER]
CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR]
CAMSHAFT POSITION SENSOR O-RING [PULSE GENERATOR O-RING]
CANISTER PURGE VALVE [FUEL TANK VENTILATION VALVE] CATALYTIC CONVERTER
CATALYTIC CONVERTER CATALYTIC CONVERTER GASKET
CHARGE AIR COOLER
CHARGE AIR COOLER CHARGE AIR DUCT PRESSURE SENSOR
CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR]
ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME]
ENGINE COOLANT TEMPERATURE SENSOR [TEMPERATUR SENSOR WATER/OIL]
EVAPORATIVE EMISSION CANISTER BREATHER LINE
EVAPORATIVE EMISSION CANISTER SEALING GROMMET [ACTIVATED CHARCOAL FILTER]
EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER]
EVAPORATIVE VENT PIPE
EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT
EXHAUST MANIFOLD GASKET
FRESH AIR INTAKE TUBE (INTAKE TO TURBOCHARGER)
FRESH AIR INTAKE TUBE GASKET/ O-RING (INTAKE TO TURBOCHARGER)
FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE]
FRONT FUEL LINE [FUEL FEED LINE]
FRONT FUEL LINE [FUEL HOSE]
FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE]
FUEL FILLER CAP
FUEL FILLER PIPE
FUEL FILLER PIPE EXTENSION
FUEL INJECTOR (CYLINDER 1 OR 2)
FUEL INJECTOR (CYLINDER 3 OR 4)
FUEL PUMP CLOSURE RING
FUEL PUMP CONTROL MODULE [CONTROL UNIT FOR FUEL PUMP]
FUEL PUMP GASKET [DELIVERY MODULE GASKET]
FUEL PUMP O-RING [DELIVERY MODULE O-RING]
FUEL PUMP [DELIVERY MODULE WITH LEVEL SENDER]
FUEL RAIL PRESSURE SENSOR [SENSOR, HIGH-PRESSURE]

2016 BMW Emissions Related Parts List
428i Coupe SULEV
428iX Coupe SULEV
428i Convertible SULEV
428iX Convertible SULEV
428i Gran Coupé SULEV
428iX Gran Coupé SULEV
Part Name
FUEL RAIL [HIGH-PRESSURE RAIL]
FUEL TANK
FUEL TANK BREATHER LINE
FUEL TANK VENT PIPE
HIGH-PRESSURE FUEL PUMP
IGNITION COIL
INTAKE CAMSHAFT POSITION ADJUSTMENT UNIT
INTAKE MANIFOLD
INTAKE MANIFOLD GASKET(S)
KNOCK SENSOR (CYLINDER 1-2) [PING SENSOR]
KNOCK SENSOR (CYLINDER 3-4) [PING SENSOR]
LEFT CHARGE AIR DUCT (CAC TO THROTTLE)
LEFT CHARGE AIR DUCT GASKET O-RING (CAC TO THROTTLE)
MANIFOLD ABSOLUTE PRESSURE SENSOR (MAP) [INTAKE MANIFOLD PRESSURE SENSOR]
MASS AIRFLOW SENSOR (MAF) [HOT-FILM AIR MASS METER]
NATURAL VACUUM LEAKAGE DETECTION SWITCH [LEAK DIAGNOSIS MODULE]
OIL FILLER CAP
OIL PRESSURE AND TEMPERATURE SENSOR
OIL PRESSURE AND TEMPERATURE SENSOR GASKET
POSITIVE CRANKCASE VENTILATION O-RING [VENT HOSE O-RING
POSITIVE CRANKCASE VENTILATION [VENT HOSE]
REAR FUEL LINE [FEED LINE]
REAR HEATED OXYGEN SENSOR [MONITORING LAMBDA PROBE]
RIGHT CHARGE AIR DUCT (TURBOCHARGER TO CAC) RIGHT CHARGE AIR DUCT GASKET/O-RING (TURBOCHARGER TO CAC)
SCAVENGE AIR LINE
THERMOSTAT THROTTLE BODY
THROTTLE BODY THROTTLE BODY GASKET
TIMING CHAIN
TORQUE CONVERTER
TRANSMISSION CONTROL MODULE [MECHATRONIC]
TURBOCHARGER
TURBOCHARGER BYPASS [BLOW-OFF VALVE]
TURBOCHARGER WASTEGATE ACTUATOR [TURBOCHARGER DRIVE MOTOR]
VALVE COVER GASKETS [GASKET SET, CYLINDER HEAD COVER]
VALVETRONIC ACTUATOR [ECCENTRIC SHAFT ACTUATOR]
VANOS VVT ACTUATOR
VANOS VVT CENTRAL VALVE

2016 BMW Emissions Related Parts List
230i Coupe - M, A
230i Coupe xDrive - A
230i Convertible - A
230i Convertible xDrive - A
Part Name
ACCELERATOR PEDAL, AUTOMATIC
ACCELERATOR PEDAL, MANUAL
AIR CLEANER [INTAKE SILENCER]
BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT]
CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING]
CATALYTIC CONVERTER
CHARGE AIR COOLER
CHARGE AIR DUCT TO THROTTLE BODY GASKET [PREFORMED SEAL]
CHARGE AIR DUCT, CAC TO THROTTLE BODY
CHARGE AIR TEMPERATURE AND PRESSURE SENSOR [T-MAP SENSOR, 3.5 BAR]
CHARGE AIR TUBE
COOLANT PUMP W/ THERMOSTAT
COOLANT TEMPERATURE SENSOR
CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR]
ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME]
EVAPORATIVE CANISTER PURGE VALVE [FUEL TANK BREATHER VALVE]
EVAPORATIVE CANISTER VENT PIPE
EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER]
EVAPORATIVE VENT PIPE W/ DUST FILTER
EVAPORATIVE VENT PIPE WITH NATURAL VACUUM LEAKAGE DETECTION PRESSURE SWITCH [LEAK DIAGNOSIS MODULE]
EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT
EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR]
EXHAUST MANIFOLD GASKET
EXHAUST VANOS VVT ACTUATOR
FRESH AIR INTAKE TUBE (INTAKE TO TURBOCHARGER)
FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE]
FRONT FUEL LINE [FEED LINE]
FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE]
FRONT SCAVENGE AIR LINE
FRONT WHEEL SPEED SENSOR [DSC PULSE GENERATOR, FRONT]
FUEL FILLER CAP
FUEL FILLER NECK
FUEL FILLER PIPE EXTENSION
FUEL INJECTOR
FUEL INJECTOR O-RING
FUEL LINE TO HIGH PRESSURE FUEL PUMP [FEED LINE]
FUEL PUMP CLOSURE RING
FUEL PUMP CONTROL MODULE [CONTROL UNIT FOR FUEL PUMP]

2016 BMW Emissions Related Parts List
230i Coupe - M, A
230i Coupe xDrive - A
230i Convertible - A
230i Convertible xDrive - A
Part Name
FUEL PUMP CONTROL MODULE [CONTROL UNIT FOR FUEL PUMP]
FUEL PUMP O-RING [DELIVERY MODULE O-RING]
FUEL PUMP W/ LEVEL SENSOR [SUPPLY/DELIVERY MODULE]
FUEL RAIL PRESSURE SENSOR [SENSOR, HIGH-PRESSURE]
FUEL RAIL [HIGH-PRESSURE RAIL]
FUEL TANK
FUEL TANK BREATHER LINE
HIGH LOAD HEATED PCV PIPE
HIGH LOAD UNHEATED PCV PIPE
HIGH PRESSURE FUEL PUMP GASKET [PROFILE GASKET]
HIGH-PRESSURE FUEL PUMP
IGNITION COIL
INTAKE CAMSHAFT POSITION ADJUSTMENT UNIT
INTAKE CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR]
INTAKE MANIFOLD
INTAKE MANIFOLD GASKET(S)
INTAKE VANOS VVT ACTUATOR
KNOCK SENSOR (CYL 1,2) [PING SENSOR]
KNOCK SENSOR (CYL 3,4) [PING SENSOR]
LOWER TIMING CHAIN
MANIFOLD ABSOLUTE PRESSURE AND TEMPERATURE SENSOR (MAPT)
[INTAKE MANIFOLD PRESSURE SENSOR 2.5 BAR]
MASS AIRFLOW SENSOR (MAF) O-RING [HOT-FILM AIR MASS METER]
MASS AIRFLOW SENSOR (MAF) [HOT-FILM AIR MASS METER]
MIDDLE FUEL LINE [FUEL HOSE]
OIL FILLER CAP
OIL PRESSURE SENSOR
PCV FLUSHING PIPE
REAR FUEL LINE [FEED LINE]
REAR HEATED OXYGEN SENSOR [MONITORING LAMBDA PROBE]
REAR WHEEL SPEED SENSOR [DSC PULSE GENERATOR, REAR]
RIGHT CHARGE AIR DUCT (TURBOCHARGER TO CAC)
SCAVENGE AIR LINE
THROTTLE BODY
THROTTLE BODY GASKET
TORQUE CONVERTER
TRANSMISSION CONTROL MODULE
TRANSMISSION CONTROL VALVE BODY
TRANSMISSION ROTATIONAL SPEED SENSOR
TURBOCHARGER

2017 BMW Emissions Related Parts List
230i Coupe - M, A
230i Coupe xDrive - A
230i Convertible - A
230i Convertible xDrive - A
Part Name
TURBOCHARGER AIR DISCHARGE DUCT
TURBOCHARGER TO CATALYTIC CONVERTER GASKET
TURBOCHARGER TO CATALYTIC CONVERTER RING CLAMP
UPPER TIMING CHAIN
VALVE COVER GASKETS [GASKET SET, CYLINDER HEAD COVER]
VALVETRONIC ACTUATOR O-RING [ECCENTRIC SHAFT ACTUATOR]
VALVETRONIC ACTUATOR [ECCENTRIC SHAFT ACTUATOR]
VANOS VVT CENTRAL VALVE

2017 BMW Emissions Related Parts List
330i - M & A
330i xDrive - A
330i xDrive Sports Wagon - A
330i xDrive Gran Turismo - A
Part Name
ACCELERATOR PEDAL, AUTOMATIC
ACCELERATOR PEDAL, MANUAL
AIR CLEANER [INTAKE SILENCER]
CANISTER PURGE VALVE [FUEL TANK BREATHER VALVE]
CATALYTIC CONVERTER GASKET
CATALYTIC CONVERTER SCREW CLAMP
CHARGE AIR DUCT
CHARGE AIR DUCT GASKET
CHARGE AIR DUCT TO CAC [CHARGE AIR LINE]
CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE]
CHARGE AIR DUCT TO/FROM CAC GASKET [PREFORMED SEAL]
CHARGE AIR TEMPERATURE AND PRESSURE SENSOR [T-MAP SENSOR, 3.5 BAR]
CLOSE-COUPLED CATALYTIC CONVERTER [RP-PRIMARY CATALYTIC CONV]
COOLANT PUMP WITH THERMOSTAT
COOLANT TEMPERATURE SENSOR
CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR]
CYLINDER HEAD AIR DISCHARGE FITTING
BRAKE SYSTEM CONTROL MODULE W/ACC [DSC CONTROL UNIT]
BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT]
ELECTRIC COOLANT PUMP
ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME]
ENGINE COOLANT TEMPERATURE SENSOR O-RING [O-RING]
EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE]
EVAPORATIVE EMISSION CANISTER SEALING GROMMET [ACTIVATED CHARCOAL FILTER]
EVAPORATIVE EMISSION CANISTER VENT PIPE WITH DUST FILTER
EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER]
EVAPORATIVE VENT LINE WITH DIFFERENTIAL PRESSURE SENSOR
EVAPORATIVE VENT PIPE [FUEL TANK BREATHER LINE]
EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT
EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR]
EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING]
EXHAUST MANIFOLD GASKET
EXHAUST VANOS WT ACTUATOR
FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE]
FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FUEL HOSE]
FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE]
FRONT FUEL LINE TO ENGINE BAY [FEED LINE]
FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE]
FRONT FUEL LINE [FEED LINE]
FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE]
FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT
FUEL FILLER CAP

2017 BMW Emissions Related Parts List
330i - M & A
330i xDrive - A
330i xDrive Sports Wagon - A
330i xDrive Gran Turismo - A
Part Name
FUEL FILLER NECK
FUEL FILLER PIPE EXTENSION
FUEL INJECTOR
FUEL INJECTOR O-RING
FUEL PUMP CLOSURE RING
FUEL PUMP CONTROL MODULE [CONTROL UNIT FOR FUEL PUMP]
FUEL PUMP O-RING [DELIVERY MODULE O-RING]
FUEL PUMP W/LEVEL SENSOR [DELIVERY MODULE]
FUEL RAIL PRESSURE SENSOR [SENSOR, HIGH-PRESSURE]
FUEL RAIL [HIGH-PRESSURE RAIL]
FUEL TANK
FUEL TANK BREATHER LINE WITH RESONATOR
FUEL TANK VENT PIPE
FUEL TANK VENT PIPE FUEL TEMPERATURE SENSOR [TEMP SENSOR, LEAK DIAGNOSIS]
HIGH-DEMAND PCV PIPE WITH HEATER [VENT PIPE]
HIGH-PRESSURE FUEL PUMP
IGNITION COIL
INTAKE CAMSHAFT POSITION ADJUSTMENT UNIT
INTAKE CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR]
INTAKE CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING]
INTAKE MANIFOLD CACKET
INTAKE MANIFOLD GASKET
INTAKE VANOS VVT ACTUATOR
KNOCK SENSOR CYL 1-2 [PING SENSOR]
KNOCK SENSOR CYL 3-4 [PING SENSOR]
LOW-DEMAND PCV PIPE [VENT PIPE]
LOWER TIMING CHAIN
MANIFOLD ABSOLUTE PRESSURE AND TEMPERATURE (T-MAP) SENSOR
MASS AIRFLOW SENSOR (MAF) O-RING [O-RING]
MASS AIRFLOW SENSOR (MAF) [HOT-FILM AIR MASS METER]
NATURAL VACUUM LEAK DIAGNOSIS MODULE
OIL FILLER CAP
REAR FUEL FEED LINE [FRONT FUEL LINE]
REAR HEATED OXYGEN SENSOR [MONITORING LAMBDA PROBE]
REAR WHEEL SPEED SENSOR DSC PULSE GENERATOR, REAR
SCAVENGE AIR LINE
SUCTION JET PUMP WITH LINE
THROTTLE BODY
THROTTLE BODY GASKET
TORQUE CONVERTER

2017 BMW Emissions Related Parts List
330i - M & A
330i xDrive - A
330i xDrive Sports Wagon - A
330i xDrive Gran Turismo - A
Part Name
TRANSMISSION ELECTRONIC CONTROL MODULE [CONTROL UNIT EGS]
TRANSMISSION INPUT SPEED SENSOR [ROTATIONAL-SPEED SENSOR]
TURBOCHARGER AIR DISCHARGE DUCT
TURBOCHARGER GASKET RING
TURBOCHARGER INTERCOOLER [CHARGE-AIR COOLER]
TURBOCHARGER SCREW CLAMP
TURBOCHARGER WITH EXH MANIFOLD AND WASTEGATE ACTUATOR
UNDER-BODY CATALYTIC CONVERTER [RP-CATALYTIC CONV WITH CENTER MUFFLER]
UPPER TIMING CHAIN
VALVE COVER GASKET [PROFILE SEAL CYLINDER HEAD COVER]
VALVETRONIC ACTUATOR O-RING [GASKET]
VALVETRONIC ACTUATOR [ECCENTRIC SHAFT ACTUATOR]
VANOS VVT CENTRAL VALVE

2017 BMW Emissions Related Parts List
430i Coupe S - A
430i xDrive Coupe S - A
430i Convertible S - A
430i xDrive Convertible S - A
430i Gran Coupé S - M, A
430i xDrive Gran Coupé S - A
4301 xb11ve di ai1 Coupe 3 - A
Part Name
DRAVE OVOTEM CONTROL MODULE (DCC CONTROL LINET)
BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT]
ACCELERATOR PEDAL, AUTOMATIC ACCELERATOR PEDAL, MANUAL
,
AIR CLEANER [INTAKE SILENCER] CANISTER PURGE VALVE [FUEL TANK BREATHER VALVE]
CATALYTIC CONVERTER GASKET
CATALYTIC CONVERTER GASKET CATALYTIC CONVERTER SCREW CLAMP
CHARGE AIR DUCT
CHARGE AIR DUCT GASKET
CHARGE AIR DUCT TO CAC [CHARGE AIR LINE]
CHARGE AIR DUCT TO CAC [CHARGE AIR LINE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE]
CHARGE AIR DUCT TO CHARGE AIR TOBE [CHARGE AIR TOBE] CHARGE AIR DUCT TO/FROM CAC GASKET [PREFORMED SEAL]
CHARGE AIR TEMPERATURE AND PRESSURE SENSOR [T-MAP SENSOR, 3.5 BAR]
CATALYTIC CONVERTER [RP-PRIMARY CATALYTIC CONV]
COOLANT PUMP WITH THERMOSTAT
COOLANT TEMPERATURE SENSOR
CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR]
CYLINDER HEAD AIR DISCHARGE FITTING
ELECTRIC COOLANT PUMP
ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME]
ENGINE COOLANT TEMPERATURE SENSOR O-RING [O-RING]
EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE]
EVAPORATIVE EMISSION CANISTER SEALING GROMMET [ACTIVATED CHARCOAL FILTER]
EVAPORATIVE EMISSION CANISTER VENT PIPE WITH DUST FILTER
EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER]
EVAPORATIVE VENT LINE WITH DIFFERENTIAL PRESSURE SENSOR
EVAPORATIVE VENT PIPE [FUEL TANK BREATHER LINE]
EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT
EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR]
EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING]
EXHAUST MANIFOLD GASKET
EXHAUST VANOS VVT ACTUATOR
FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE]
FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FUEL HOSE]
FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE]
FRONT FUEL LINE TO ENGINE BAY [FEED LINE]
FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE]
FRONT FUEL LINE [FEED LINE]

2017 BMW Emissions Related Parts List
430i Coupe S - A
430i xDrive Coupe S - A
430i Convertible S - A
430i xDrive Convertible S - A
430i Gran Coupé S - M, A
430i xDrive Gran Coupé S - A
Part Name
FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE]
FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT
FUEL FILLER CAP
FUEL FILLER NECK
FUEL FILLER PIPE EXTENSION
FUEL INJECTOR
FUEL INJECTOR O-RING
FUEL LINE (TO HP FUEL PUMP) [FEED LINE]
FUEL PUMP CLOSURE RING
FUEL PUMP CONTROL MODULE [CONTROL UNIT FOR FUEL PUMP]
FUEL PUMP O-RING [DELIVERY MODULE O-RING]
FUEL PUMP W/ LEVEL SENSOR [DELIVERY MODULE]
FUEL RAIL PRESSURE SENSOR [SENSOR, HIGH-PRESSURE]
FUEL RAIL [HIGH-PRESSURE RAIL]
FUEL TANK
FUEL TANK VENT PIPE
FUEL TEMPERATURE SENSOR [TEMP SENSOR, LEAK DIAGNOSIS]
HIGH-DEMAND PCV PIPE WITH HEATER [VENT PIPE]
HIGH-PRESSURE FUEL PUMP
IGNITION COIL
INTAKE CAMSHAFT POSITION ADJUSTMENT UNIT
INTAKE CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR]
INTAKE CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING]
INTAKE MANIFOLD
INTAKE MANIFOLD GASKET
INTAKE VANOS VVT ACTUATOR
KNOCK SENSOR CYL 1-2 [PING SENSOR]
KNOCK SENSOR CYL 3-4 [PING SENSOR]
LOW-DEMAND PCV PIPE [VENT PIPE]
LOWER TIMING CHAIN
MANIFOLD ABSOLUTE PRESSURE AND TEMPERATURE (T-MAP) SENSOR
MASS AIRFLOW SENSOR (MAF) O-RING [O-RING]
MASS AIRFLOW SENSOR (MAF) [HOT-FILM AIR MASS METER]
NATURAL VACUUM LEAK DIAGNOSIS MODULE (NVLD II MODULE)
OIL FILLER CAP
REAR FUEL FEED LINE
REAR HEATED OXYGEN SENSOR [MONITORING LAMBDA PROBE]
REAR WHEEL SPEED SENSOR DSC PULSE GENERATOR, REAR

2017 BMW Emissions Related Parts List
430i Coupe S - A
430i xDrive Coupe S - A
430i Convertible S - A
430i xDrive Convertible S - A
430i Gran Coupé S - M, A
430i xDrive Gran Coupé S - A
Part Name
REAR WHEEL SPEED SENSOR, VEHICLES WITH ACC DSC PULSE GENERATOR, REAR
SCAVENGE AIR LINE
SUCTION JET PUMP WITH LINE
THROTTLE BODY
THROTTLE BODY GASKET
TORQUE CONVERTER
TRANSMISSION CONTROL VALVE BODY [MECHATRONIC]
TRANSMISSION ELECTRONIC CONTROL MODULE [CONTROL UNIT EGS]
TRANSMISSION INPUT SPEED SENSOR [ROTATIONAL-SPEED SENSOR]
TURBOCHARGER AIR DISCHARGE DUCT
TURBOCHARGER GASKET RING
TURBOCHARGER INTERCOOLER [CHARGE-AIR COOLER]
TURBOCHARGER SCREW CLAMP
TURBOCHARGER WITH EXH MANIFOLD AND WASTEGATE ACTUATOR
UNDER-BODY CATALYTIC CONVERTER [RP-CATALYTIC CONV WITH CENTER MUFFLER]
UPPER TIMING CHAIN
VALVE COVER GASKET [PROFILE SEAL CYLINDER HEAD COVER]
VALVETRONIC ACTUATOR O-RING [GASKET]
VALVETRONIC ACTUATOR [ECCENTRIC SHAFT ACTUATOR]
VANOS VVT CENTRAL VALVE

2017 BMW Emissions Related Parts List
530i - A, SP
530i xDrive - A, SP
Part Name
HEAT MANAGEMENT SYSTEM
POSITIVE CRANKCASE VENTILATION [VENT PIPE]
CYLINDER HEAD AIR DISCHARGE FITTING
TEMPERATURE SENSOR [TEMPERATUR SENSOR CYLINDER HEAD]
VALVETRONIC ACTUATOR
VALVETRONIC ACTUATOR GASKET
CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR]
CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING]
OIL FILLER CAP
VALVE COVER GASKETS [PROFILE SEAL FOR CYLINDER HEAD COVER]
VANOS VVT ACTUATOR
KNOCK SENSOR [PING SENSOR]
OIL PRESSURE SENSOR
TEMPERATURE SENSOR [TEMPERATUR SENSOR WATER/OIL]
INTAKE SYSTEM SEAL
INTAKE SYSTEM WITH CHARGE AIR COOLER
MANIFOLD ABSOLUTE PRESSURE AND TEMP. SENSOR (MAPT) [INTAKE MANIFOLD PRES. SENSOR]
LOWER TIMING CHAIN
CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR]
EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT
INTAKE CAMSHAFT POSITION ADJUSTMENT UNIT
UPPER TIMING CHAIN
VANOS VVT CENTRAL VALVE [CENTRAL VALVE VANOS SHORT]
EXHAUST MANIFOLD GASKET
TURBOCHARGER
TURBOCHARGER CLAMP
TURBOCHARGER GASKET
TURBOCHARGER WASTEGATE ACTUATOR
ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME]
IGNITION COIL
CHARGE AIR DUCT (CAC TO THROTTLE)
CHARGE AIR DUCT GASKET/O-RING (TURBOCHARGER TO CAC)
CHARGE AIR DUCT PRESSURE SENSOR
CHARGE AIR TEMPERATURE SENSOR
FRESH AIR DUCT CONNECTING CLAMP
FRESH AIR DUCT TO INTAKE MANIFOLD CLAMP
FRESH AIR INTAKE TUBE (INTAKE TO TURBOCHARGER)
FRESH AIR INTAKE TUBE CLIP (INTAKE TO TURBOCHARGER)
FRESH AIR INTAKE TUBE GASKET/ O-RING (INTAKE TO TURBOCHARGER)
FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE]
FUEL LINE [FUEL HOSE]
FUEL SUPPLY LINE [SUPPLY LINE TO ENGINE COMPARTMENT]

2017 BMW Emissions Related Parts List
530i - A, SP
530i xDrive - A, SP
Part Name
HIGH-PRESSURE FUEL PUMP
FUEL INJECTOR
FUEL INJECTOR GASKET RING
FUEL RAIL SENSOR [SENSOR, HIGH-PRESSURE]
FUEL RAIL [HIGH-PRESSURE RAIL]
AIR CLEANER [INTAKE MUFFLER]
MASS AIRFLOW SENSOR (MAF) [HOT-FILM AIR MASS METER]
FUEL TANK BREATHER LINE
FUEL TANK BREATHER VALVE
SUCKING JET PUMP
THROTTLE BODY
THROTTLE BODY GASKET
EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER]
LEAK DIAGNOSIS MODULE DUST FILTER
LEAKAGE DETECTION SWITCH SEALING GROMMET
NATURAL VACUUM LEAKAGE DETECTION SWITCH [PRESSURE SWITCH, LEAK DIAGNOSIS MODULE]
REAR SCAVENGE AIR LINE
SUPPLEMENTARY EVAPORATIVE EMISSION CANISTER [SUPPLEMENTARY CARBON CANISTER]
FUEL PUMP CONTROL MODULE [CONTROL UNIT FOR FUEL PUMP]
FRONT PART REAR FUEL LINE [FRONT FEED LINE]
FRONT SCAVENGE AIR LINE
REAR PART REAR FUEL LINE [REAR FEED LINE]
FUEL LEVEL SENSOR
FUEL PUMP CLOSURE RING
FUEL PUMP O-RING [DELIVERY MODULE O-RING]
FUEL PUMP [DELIVERY MODULE]
LEAKAGE DETECTION TEMPERATUR SENSOR [TEMP. SENSOR, LEAK DIAGNOSIS MODULE]
FUEL FILLER CAP
FUEL FILLER PIPE
FUEL FILLER PIPE EXTENSION
FUEL FILLER PIPE EXTENSION CLAMP
FUEL TANK
CATALYTIC CONVERTER
FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE]
REAR HEATED OXYGEN SENSOR [MONITORING LAMBDA PROBE]
TRANSMISSION CONTROL MODULE [MECHATRONIC]
TORQUE CONVERTER
WHEEL SPEED SEONSOR, FRONT [DSC PULSE GENERATOR, FRONT]
WHEEL SPEED SEONSOR, REAR [DSC PULSE GENERATOR, REAR] DSC CONTROL UNIT
ACCELERATOR PEDAL, AUTOMATIC

X1 xDrive 28i, Automatic Part Name ACCELERATOR PEDAL, AUTOMATIC AIR CLEANER [INTAKE SILENCER] CANISTER PURGE VALVE [FUEL TANK BREATHER VALVE] CANISTER VENT PIPE WITH LEAK DIAGNOSIS MODULE / PRESSURE SENSOR CATALYTIC CONVERTER GASKET CATALYTIC CONVERTER GASKET CATALYTIC CONVERTER SCREW CLAMP CHARGE AIR DUCT TO CAC [CHARGE AIR LINE] CHARGE AIR DUCT TO CARDE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO/FROM CAC GASKET [PREFORMED SEAL] CHARGE AIR TEMPERATURE AND PRESSURE SENSOR [T-MAP SENSOR, 3.5 BAR] CHARGE AIR TUBE CHARGE AIR TUBE CHARGE AIR TUBE GASKET CLOSE-COUPLED CATALYTIC CONVERTER [RP-PRIMARY CATALYTIC CONV] COOLANT PUMP WITH THERMOSTAT COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR (CKP) [CRANKSHAFT SENSOR] CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE [ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR PIPE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT HEALE DO SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER PIPE EXTENSION FUEL FILLER PIPE EXTENSION FUEL FILLER PIPE EXTENSION FUEL FILLER PIPE EXTENSION	2017 BMW Emissions Related Parts List
Part Name ACCELERATOR PEDAL, AUTOMATIC AIR CLEANER [INTAKE SILENCER] CANISTER PURGE VALVE [FUEL TANK BREATHER VALVE] CANISTER PURGE VALVE [FUEL TANK BREATHER VALVE] CANISTER VENT PIPE WITH LEAK DIAGNOSIS MODULE / PRESSURE SENSOR CATALYTIC CONVERTER SCREW CLAMP CHARGE AIR DUCT TO CAC [CHARGE AIR LINE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO/FROM CAC GASKET [PREFORMED SEAL] CHARGE AIR TUBE CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR TEMPERATURE AND PRESSURE SENSOR [T-MAP SENSOR, 3.5 BAR] CHARGE AIR TUBE CHARGE AIR TUBE GASKET CLOSE-COUPLED CATALYTIC CONVERTER [RP-PRIMARY CATALYTIC CONV] COOLANT PUMP WITH THERMOSTAT COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR O-RING [O-RING] CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR] CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE [CEM] [CONTROL UNIT DME] EVAPORATIVE EMISSION CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GAPSKET [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GAPSKET [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GAPSKET [PULSE GENERATOR] FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT HEALE SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	X1 sDrive 28i, Automatic
Part Name ACCELERATOR PEDAL, AUTOMATIC AIR CLEANER (INTAKE SILENCER) CANISTER PURGE VALVE (FUEL TANK BREATHER VALVE) CANISTER PURGE VALVE (FUEL TANK BREATHER VALVE) CANISTER VENT PIPE WITH LEAK DIAGNOSIS MODULE / PRESSURE SENSOR CATALYTIC CONVERTER GASKET CATALYTIC CONVERTER SCREW CLAMP CHARGE AIR DUCT TO CAC (CHARGE AIR LINE) CHARGE AIR DUCT TO CHARGE AIR TUBE (CHARGE AIR TUBE) CHARGE AIR DUCT TO CHARGE AIR TUBE (CHARGE AIR TUBE) CHARGE AIR DUCT TO/FROM CAC GASKET (PREFORMED SEAL) CHARGE AIR TUBE CHARGE AIR TUBE (CHARGE AIR TUBE) CHARGE AIR TUBE GASKET CLOSE-COUPLED CATALYTIC CONVERTER (RP-PRIMARY CATALYTIC CONV) COOLANT PUMP WITH THERMOSTAT COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR (CHP) (CONTROL UNIT) CRANKSHAFT POSITION SENSOR (CKP) (CRANKSHAFT SENSOR) CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) (CONTROL UNIT DME) EVAPORATIVE EMISSION CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION DUST FILTER EVAPORATIVE EMISSION DUST FILTER EVHAUST CAMSHAFT POSITION ADJUSTMENT UNIT EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT EXHAUST CAMSHAFT POSITION SENSOR (CMP) (PULSE GENERATOR) EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING) EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING) EXHAUST CAMSHAFT POSITION SENSOR (CMP) (FULSE GENERATOR) EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING) EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING) EXHAUST CAMSHAFT POSITION SENSOR (CMP) (FULSE GENERATOR) FRESH AIR INTAKE TO TURBOCHARGER (FILTERED AIR PIPE) FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) (HIGH PRESSURE PIPE) FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) (HIGH PRESSURE PIPE) FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) (HIGH PRESSURE PIPE) FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) (HIGH PRESSURE PIPE) FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) (HIGH PRESSURE PIPE) FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) (HIGH PRESSURE PIPE) FRONT FUEL LINE (FUEL PU	·
ACCELERATOR PEDAL, AUTOMATIC AIR CLEANER [INTAKE SILENCER] CANISTER PURGE VALVE [FUEL TANK BREATHER VALVE] CANISTER PURGE VALVE [FUEL TANK BREATHER VALVE] CANISTER VENT PIPE WITH LEAK DIAGNOSIS MODULE / PRESSURE SENSOR CATALYTIC CONVERTER GASKET CATALYTIC CONVERTER SCREW CLAMP CHARGE AIR DUCT TO CAC [CHARGE AIR LINE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR TEMPERATURE AND PRESSURE SENSOR [T-MAP SENSOR, 3.5 BAR] CHARGE AIR TUBE GASKET CLOSE-COUPLED CATALYTIC CONVERTER [RP-PRIMARY CATALYTIC CONV] COOLANT PUMP WITH THERMOSTAT COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR O-RING [O-RING] CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR] CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR O-RING] EXHAUST VANOS VYT ACTUATOR FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT HEAL ESPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER CAP FUEL FILLER CAP FUEL FILLER PIPE EXTENSION	AT ABITY 201, Automatic
ACCELERATOR PEDAL, AUTOMATIC AIR CLEANER [INTAKE SILENCER] CANISTER PURGE VALVE [FUEL TANK BREATHER VALVE] CANISTER PURGE VALVE [FUEL TANK BREATHER VALVE] CANISTER VENT PIPE WITH LEAK DIAGNOSIS MODULE / PRESSURE SENSOR CATALYTIC CONVERTER GASKET CATALYTIC CONVERTER SCREW CLAMP CHARGE AIR DUCT TO CAC [CHARGE AIR LINE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR TEMPERATURE AND PRESSURE SENSOR [T-MAP SENSOR, 3.5 BAR] CHARGE AIR TUBE GASKET CLOSE-COUPLED CATALYTIC CONVERTER [RP-PRIMARY CATALYTIC CONV] COOLANT PUMP WITH THERMOSTAT COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR O-RING [O-RING] CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR] CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR O-RING] EXHAUST VANOS VYT ACTUATOR FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT HEAL ESPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER CAP FUEL FILLER CAP FUEL FILLER PIPE EXTENSION	Part Name
AIR CLEANER [INTAKE SILENCER] CANISTER PURGE VALVE [FUEL TANK BREATHER VALVE] CANISTER VENT PIPE WITH LEAK DIAGNOSIS MODULE / PRESSURE SENSOR CATALYTIC CONVERTER GASKET CATALYTIC CONVERTER SCREW CLAMP CHARGE AIR DUCT TO CAC [CHARGE AIR LINE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR TUBE CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR TUBE GASKET CLOSE-COUPLED CATALYTIC CONVERTER [RP-PRIMARY CATALYTIC CONV] COOLANT PUMP WITH THERMOSTAT COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR (CKP) [CRANKSHAFT SENSOR] CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST CAMSHAFT POSITION SENSOR GENERATOR, FRONT FUEL LINE [OUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT FUEL HOSE OSENSOR DSC PULSE GENERATOR,	1 ditivalio
AIR CLEANER [INTAKE SILENCER] CANISTER PURGE VALVE [FUEL TANK BREATHER VALVE] CANISTER VENT PIPE WITH LEAK DIAGNOSIS MODULE / PRESSURE SENSOR CATALYTIC CONVERTER GASKET CATALYTIC CONVERTER SCREW CLAMP CHARGE AIR DUCT TO CAC [CHARGE AIR LINE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR TUBE CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR TUBE GASKET CLOSE-COUPLED CATALYTIC CONVERTER [RP-PRIMARY CATALYTIC CONV] COOLANT PUMP WITH THERMOSTAT COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR (CKP) [CRANKSHAFT SENSOR] CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST CAMSHAFT POSITION SENSOR GENERATOR, FRONT FUEL LINE [OUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT FUEL HOSE OS ENSOR DSC PULSE GENERATOR	ACCELERATOR PEDAL ALITOMATIC
CANISTER PURGE VALVE [FUEL TANK BREATHER VALVE] CANISTER VENT PIPE WITH LEAK DIAGNOSIS MODULE / PRESSURE SENSOR CATALYTIC CONVERTER GASKET CATALYTIC CONVERTER SCREW CLAMP CHARGE AIR DUCT TO CAC [CHARGE AIR LINE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO/FROM CAC GASKET [PREFORMED SEAL] CHARGE AIR TEMPERATURE AND PRESSURE SENSOR [T-MAP SENSOR, 3.5 BAR] CHARGE AIR TUBE GASKET CLOSE-COUPLED CATALYTIC CONVERTER [RP-PRIMARY CATALYTIC CONV] COOLANT PUMP WITH THERMOSTAT COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR O-RING [O-RING] CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR] CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR O-RING] EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR PIPE] FRONT FUEL LINE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL LINE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL LINE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT HEATED OXYGEN SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER RECK	
CANISTER VENT PIPE WITH LEAK DIAGNOSIS MODULE / PRESSURE SENSOR CATALYTIC CONVERTER GASKET CATALYTIC CONVERTER SCREW CLAMP CHARGE AIR DUCT TO CAC [CHARGE AIR LINE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO/FROM CAC GASKET [PREFORMED SEAL] CHARGE AIR TEMPERATURE AND PRESSURE SENSOR [T-MAP SENSOR, 3.5 BAR] CHARGE AIR TUBE CHARGE AIR TUBE CHARGE AIR TUBE GASKET CLOSE-COUPLED CATALYTIC CONVERTER [RP-PRIMARY CATALYTIC CONV] COOLANT PUMP WITH THERMOSTAT COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR O-RING [O-RING] CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR] CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST CAMSHAFT POSITION SENSOR [REGULATING LAMBDA PROBE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED	
CATALYTIC CONVERTER GASKET CATALYTIC CONVERTER SCREW CLAMP CHARGE AIR DUCT TO CAC [CHARGE AIR LINE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO/FROM CAC GASKET [PREFORMED SEAL] CHARGE AIR TEMPERATURE AND PRESSURE SENSOR [T-MAP SENSOR, 3.5 BAR] CHARGE AIR TUBE CHARGE AIR TUBE GASKET CLOSE-COUPLED CATALYTIC CONVERTER [RP-PRIMARY CATALYTIC CONV] COOLANT PUMP WITH THERMOSTAT COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR O-RING [O-RING] CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR] CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST CAMSHAF	
CATALYTIC CONVERTER SCREW CLAMP CHARGE AIR DUCT TO CAC [CHARGE AIR LINE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO/FROM CAC GASKET [PREFORMED SEAL] CHARGE AIR TEMPERATURE AND PRESSURE SENSOR [T-MAP SENSOR, 3.5 BAR] CHARGE AIR TUBE CHARGE AIR TUBE CHARGE AIR TUBE GASKET CLOSE-COUPLED CATALYTIC CONVERTER [RP-PRIMARY CATALYTIC CONV] COOLANT PUMP WITH THERMOSTAT COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR O-RING [O-RING] CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR] CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENER	
CHARGE AIR DUCT TO CAC [CHARGE AIR LINE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO JEROM CAC GASKET [PREFORMED SEAL] CHARGE AIR TEMPERATURE AND PRESSURE SENSOR [T-MAP SENSOR, 3.5 BAR] CHARGE AIR TUBE CHARGE AIR TUBE GASKET CLOSE-COUPLED CATALYTIC CONVERTER [RP-PRIMARY CATALYTIC CONV] COOLANT PUMP WITH THERMOSTAT COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR O-RING [O-RING] CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR] CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHA	
CHARGE AIR DUCT TO CHARGE AIR TUBE [CHARGE AIR TUBE] CHARGE AIR DUCT TO/FROM CAC GASKET [PREFORMED SEAL] CHARGE AIR TEMPERATURE AND PRESSURE SENSOR [T-MAP SENSOR, 3.5 BAR] CHARGE AIR TUBE CHARGE AIR TUBE CHARGE AIR TUBE GASKET CLOSE-COUPLED CATALYTIC CONVERTER [RP-PRIMARY CATALYTIC CONV] COOLANT PUMP WITH THERMOSTAT COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR O-RING [O-RING] CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR] CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST VANOS WY ACTUATOR FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE (FUEL PUMP TO FUEL RIAL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT FUEL FILLER RECK FUEL FILLER RECK	
CHARGE AIR DUCT TO/FROM CAC GASKET [PREFORMED SEAL] CHARGE AIR TEMPERATURE AND PRESSURE SENSOR [T-MAP SENSOR, 3.5 BAR] CHARGE AIR TUBE CHARGE AIR TUBE GASKET CLOSE-COUPLED CATALYTIC CONVERTER [RP-PRIMARY CATALYTIC CONV] COOLANT PUMP WITH THERMOSTAT COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR O-RING [O-RING] CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR] CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR D-RING] EXHAUST CAMSHAFT POSITION SENSOR [RILTERED AIR PIPE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER NECK FUEL FILLER NECK	
CHARGE AIR TEMPERATURE AND PRESSURE SENSOR [T-MAP SENSOR, 3.5 BAR] CHARGE AIR TUBE CHARGE AIR TUBE GASKET CLOSE-COUPLED CATALYTIC CONVERTER [RP-PRIMARY CATALYTIC CONV] COOLANT PUMP WITH THERMOSTAT COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR O-RING [O-RING] CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR] CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST CAMSHAFT POSITION SENSOR PRESSURE PIPE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	
CHARGE AIR TUBE CHARGE AIR TUBE GASKET CLOSE-COUPLED CATALYTIC CONVERTER [RP-PRIMARY CATALYTIC CONV] COOLANT PUMP WITH THERMOSTAT COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR O-RING [O-RING] CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR] CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST MANIFOLD GASKET EXHAUST VANOS VYT ACTUATOR FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK	
CHARGE AIR TUBE GASKET CLOSE-COUPLED CATALYTIC CONVERTER [RP-PRIMARY CATALYTIC CONV] COOLANT PUMP WITH THERMOSTAT COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR O-RING [O-RING] CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR] CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST MANIFOLD GASKET EXHAUST VANOS VYT ACTUATOR FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	
CLOSE-COUPLED CATALYTIC CONVERTER [RP-PRIMARY CATALYTIC CONV] COOLANT PUMP WITH THERMOSTAT COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR O-RING [O-RING] CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR] CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST MANIFOLD GASKET EXHAUST VANOS WIT ACTUATOR FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER NECK FUEL FILLER NECK	
COOLANT PUMP WITH THERMOSTAT COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR O-RING [O-RING] CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR] CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST MANIFOLD GASKET EXHAUST VANOS WIT ACTUATOR FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO BIGINE BAY [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER NECK FUEL FILLER NECK	
COOLANT TEMPERATURE SENSOR COOLANT TEMPERATURE SENSOR O-RING [O-RING] CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR] CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST WANOS VOT ACTUATOR FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	
COOLANT TEMPERATURE SENSOR O-RING [O-RING] CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR] CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST MANIFOLD GASKET EXHAUST VANOS VVT ACTUATOR FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER NECK	
CRANKSHAFT POSITION SENSOR (CKP) [CRANKSHAFT SENSOR] CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST MANIFOLD GASKET EXHAUST VANOS VYT ACTUATOR FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	
CYLINDER HEAD AIR DISCHARGE FITTING BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST MANIFOLD GASKET EXHAUST WANOS VYT ACTUATOR FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	
BRAKE SYSTEM CONTROL MODULE [DSC CONTROL UNIT] ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST MANIFOLD GASKET EXHAUST WANOS VVT ACTUATOR FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	, ,,
ELECTRIC COOLANT PUMP ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST MANIFOLD GASKET EXHAUST WANIFOLD GASKET EXHAUST VANOS WIT ACTUATOR FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	
ENGINE CONTROL MODULE (ECM) [CONTROL UNIT DME] EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST MANIFOLD GASKET EXHAUST VANOS VVT ACTUATOR FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	
EVAPORATIVE CANISTER PURGE PIPE [BREATHER LINE] EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST MANIFOLD GASKET EXHAUST VANOS VVT ACTUATOR FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	
EVAPORATIVE EMISSION CANISTER [ACTIVATED CHARCOAL FILTER] EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST MANIFOLD GASKET EXHAUST VANOS VVT ACTUATOR FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	
EVAPORATIVE EMISSION DUST FILTER EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST MANIFOLD GASKET EXHAUST VANOS VVT ACTUATOR FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	
EXHAUST CAMSHAFT POSITION ADJUSTMENT UNIT EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST MANIFOLD GASKET EXHAUST VANOS WT ACTUATOR FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	
EXHAUST CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR] EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST MANIFOLD GASKET EXHAUST VANOS VVT ACTUATOR FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	
EXHAUST CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING] EXHAUST MANIFOLD GASKET EXHAUST VANOS VVT ACTUATOR FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	
EXHAUST MANIFOLD GASKET EXHAUST VANOS WT ACTUATOR FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	
EXHAUST VANOS WT ACTUATOR FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	
FRESH AIR INTAKE TO TURBOCHARGER [FILTERED AIR PIPE] FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	
FRONT FUEL HOSE TO HIGH-PRESSURE PUMP [FUEL HOSE] FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	
FRONT FUEL LINE (FUEL PUMP TO FUEL RAIL) [HIGH PRESSURE PIPE] FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	•
FRONT FUEL LINE TO ENGINE BAY [FEED LINE] FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	
FRONT FUEL LINE TO HIGH-PRESSURE PUMP [FEED LINE] FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	, , , , , , , , , , , , , , , , , , , ,
FRONT HEATED OXYGEN SENSOR [REGULATING LAMBDA PROBE] FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	
FRONT SCAVENGE AIR LINE FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	
FRONT WHEEL SPEED SENSOR DSC PULSE GENERATOR, FRONT FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	
FUEL FILLER CAP FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	
FUEL FILLER NECK FUEL FILLER PIPE EXTENSION	·
FUEL FILLER PIPE EXTENSION	
	FUEL INJECTOR O-RING
FUEL PUMP CLOSURE RING	

2017 BMW Emissions Related Parts List
X1 sDrive 28i, Automatic
X1 xDrive 28i, Automatic
A 1 ADTIVE 201, Automatic
Part Name
FUEL PUMP CONTROL MODULE [CONTROL UNIT FOR FUEL PUMP]
FUEL PUMP O-RING [DELIVERY MODULE O-RING]
FUEL PUMP [DELIVERY MODULE]
FUEL RAIL PRESSURE SENSOR [SENSOR, HIGH-PRESSURE]
FUEL RAIL [HIGH-PRESSURE RAIL]
FUEL TANK
FUEL TEMPERATURE SENSOR [TEMP SENSOR, LEAK DIAGNOSIS]
HIGH-DEMAND PCV PIPE WITH HEATER [VENT PIPE]
HIGH-PRESSURE FUEL PUMP
IGNITION COIL
INTAKE CAMSHAFT POSITION ADJUSTMENT UNIT
INTAKE CAMSHAFT POSITION SENSOR (CMP) [PULSE GENERATOR]
INTAKE CAMSHAFT POSITION SENSOR GASKET [PULSE GENERATOR O-RING]
INTAKE MANIFOLD
INTAKE MANIFOLD GASKET
INTAKE VANOS VVT ACTUATOR
KNOCK SENSOR [PING SENSOR]
LOW-DEMAND PCV PIPE [VENT PIPE]
LOWER TIMING CHAIN
MANIFOLD ABSOLUTE PRESSURE AND TEMPERATURE (T-MAP) SENSOR
MASS AIRFLOW SENSOR (MAF) O-RING [O-RING]
MASS AIRFLOW SENSOR (MAF) [HOT-FILM AIR MASS METER]
MUFFLER CLAMP
NON-RETURN VALVE FOR BRAKE BOOSTER VACUUM
OIL FILLER CAP
REAR FUEL FEED LINE
REAR HEATED OXYGEN SENSOR [MONITORING LAMBDA PROBE]
REAR WHEEL SPEED SENSOR DSC PULSE GENERATOR, REAR
SCAVENGE AIR LINE
THROTTLE BODY
THROTTLE BODY GASKET
TORQUE CONVERTER
TRANSMISSION CONTROL VALVE BODY [MECHATRONIC]
TRANSMISSION ELECTRONIC CONTROL MODULE [CONTROL UNIT EGS]
TRANSMISSION INPUT SPEED SENSOR [ROTATIONAL-SPEED SENSOR]
TURBOCHARGER AIR DISCHARGE DUCT
TURBOCHARGER GASKET RING
TURBOCHARGER INTERCOOLER [CHARGE-AIR COOLER]
TURBOCHARGER SCREW CLAMP
TURBOCHARGER WITH EXH MANIFOLD AND WASTEGATE ACTUATOR
UPPER TIMING CHAIN
VALVE COVER GASKET [PROFILE SEAL CYLINDER HEAD COVER]

2017 BMW Emissions Related Parts List
X1 sDrive 28i, Automatic
X1 xDrive 28i, Automatic
Part Name
VALVETRONIC ACTUATOR [ECCENTRIC SHAFT ACTUATOR]
VANOS VVT CENTRAL VALVE