
QUICK START GUIDE

Charge Unit for 24 Hours Prior to First Use.



2 Insert Tip:



Note: For first time use, use blue low pressure tip. To increase water pressure, use the clear high pressure tip.

Fill the Reservoir:



Unplug charging cord from unit prior to filling with water and during use.



Lift the flip top on reservoir and fill with lukewarm water. Refill as needed. 4 Usage:

<u>Caution:</u> Do not press tip eject button while unit is running.

Be sure tip is fully engaged before turning **ON**.



Note: OFF button is located directly below the ON button.

continued on back

This device is only compatible with a voltage system of 230VAC, 50Hz. Do not plug this device into a voltage system that is different.