



Troubleshooting:

Some turn signal levers are triggered with a very light touch, if you are having issues with the clamp triggering the turn signal lever without use, try moving the clamp farther up or down the turn signal lever. If issues persist, please contact us at support@gosafedrive.com or call support at [708-683-7618](tel:708-683-7618).