



HD SMART WI-FI CAMERA USER MANUAL

EASY INSTALLATION

The Smart home device only supports 2.4Ghz frequency. If your router supports both 2.4Ghz and 5Ghz frequency. The 5G network is usually labeled as "Router-5G" so please connect to the other one.

Each smart home device can only be registered to one account, but it can be shared with others by using the sharing function of the app.

This Smart Wi-Fi Camera and App is compatible with the devices using iOS 8.0 and above with Wi-Fi option, or Android 5.0 and above with Wi-Fi option.

Download and Install Eco4life App

Methods 1: Scanning the below QR code to download "eco4life" App

Methods 2: Download the app by searching "eco4life" App from Google Play store(Android) or Apple Store(iOS).





Please Enter the "eco4life" App, Click "Sign up" to Register an account and log in.

Quick Mode Configurations

- 1 Power on: Connect the USB power to the camera.
- 2 Your device will rotate 360 degrees, and then the indicator light will flash and go into network mode.
[Note: If reset is required, please press the Reset for several seconds until the camera starts to beep.]
- 3 Press "add device" icon, choose "IP camera" from app and click "next step".
- 4 Select your 2.4Ghz Wi-Fi network and enter password

- 5 Tap "Continue", the mobile phone will show a QR code. Use the device to scan the QR code that is 15 to 20 cm away from the phone.
- 6 Click "I Heard a Prompt" when you hear a prompt sound. The device enters the state of connecting and distributing the networks, then waiting for the completion of adding the device.



SAFETY INSTRUCTIONS

Keep the camera away from extreme heat sources or fire.

Do not use the camera if it has been dropped or damaged in any way.

Repairs to electrical equipment should only be performed by a qualified electrician.

Improper repairs may place the user at serious risk.

Keep the camera free from dust, lint etc.

Do not use this camera for anything other than its intended use

Keep the camera out of reach of children.

This product is not a toy.

SUPPORT

For more troubleshooting help, please visit <https://eco4lifehome.com/pages/contact-us> for web support or send us an email at cs@sonicgracehome.com.

You can also go to <https://mall.eco4lifehome.com/pages/support> to download full product manual.