



HOW TO FILL



Remove water tank cap.



Add clean water and replace cap.
Hot or cold water is ok.
33°F -120°F



Replace water tank cap.

HOW TO USE



Press power button to turn on system. Pump will turn on and off automatically.
Pump will NOT turn off automatically when water tank is empty.
ON/OFF valve should be in the ON position to spray.



The volt meter will show the battery life.
13v to 11v = Normal range
10.8v or lower = Charge battery
Below 10.5 volts can damage the battery.



To charge battery, open water cover and plug in car or wall charger into the charging port.
Keep the cover closed when not in use.