



## **INSTRUCTIONS FOR USE:**

1. Remove a drain plug from your RinseKit.



2. Place the pump in the drain plug hole and hand tighten it firmly in place.



3. Hand pump pressure into the unit to 65 psi. Use the pressure gauge to guide you.



For more information, visit the FAQ page on our website at <a href="https://www.rinsekit.com">www.rinsekit.com</a>

If you do not have access to a hose bib or sink and want to pressurized your RinseKit remotely, follow these instructions.

- 1. Unscrew a drain plug from your RinseKit and pour water into the tank.
- 2. When the RinseKit is 95% full and there is about 1 inch of air space at the top, install the Pressure Booster Pump by placing it in the drain plug hole and turning it in a clockwise direction.
- 3. When the pump is securely installed, use your hand to pump pressure into the unit. Make sure to look at the pressure gauge located on the top of the pump to ensure that you are pressurizing your RinseKit to the recommended 65psi.

NOTE: Once installed, the Pressure Booster Pump does not need to be removed from the RinseKit. It can be used as a seal instead of a drain plug.

## **Questions? Contact us!** 1-800-613-5764

info@rinsekit.com

