



# User Manual EASY COVER

# User Manual EASY COVER









### **HOW TO USE ON CARSEAT**






- Seat your child in the car seat and fasten the safety harness as per manufacturer's instructions.
- Pull your child's arms through the built-in sleeves and roll them up as desired.




- Snap the oversized collar at the back of the neck.
- To create a leg pouch for your child, adjust the length by starting with either the right or left side and see steps A, B, C below.

# ADJUSTING LENGTH POUCH



- **A.** Fold the corner inward.
- **B.** Secure corner closed using snaps A or B to connect with 5, 4, 3, 2, or 1 to your child's height.



C. Repeat steps 4a and 4b for the other side

The Easy Cover can be used in the same way indoors either on the couch or at sleepovers and even at chilly outdoor sport games.

# HOW TO USE ON STROLLER



To use on stroller, simply follow the steps 1 through 6 above.

The Easy Cover is machine washable. Remove the faux fur trim before machine washing. The care label is located on the internal side of the product.