


For BALANCED output:
mount R23, leave R24 open

For SINGLE ENDED output
with GROUND SENSE:
mount R24, leave R23 open

Do NOT mount both R23 and R24



**MUSES72320 Volume Control with Ground Sense
Left Ch. + PSU**

TITLE: bvc+gs_muses


Document Number:

REV:

Date: 5/28/19 10:43

Sheet: 1/2





MUSES72320 Volume Control with Ground Sense Right Ch. + SPI	
TITLE: bvc+gs_muses	
Document Number:	REV:
Date: 5/28/19 10:43	Sheet: 2/2