


TECHNICAL DIAGRAM
 OLIVE HARVESTER
 X.QUATTRO SUPERVELOCE CF
 MODEL TYPE: 6000
 rev.5



copyright© AGROTECHNIC CRETE S.A

SPARE PARTS LIST - X.QUATTRO SUPERVELOCE CF MODEL: TYPE 6000 DIAGRAM REV.5

Item No.	Part No.	Description	# in model	Notes
1	4054	Head Cover rear	1	
2	4055	Head Cover front	1	
3	4056	Shaft w. Pinion Gear N14 set	1	With gear, b.bearings, eccentric ends
4	4057	Crown Gear N14 with 8mm shaft	1	With shaft 8mm / No bearings - No pin
5	4058	Ball Bearing 608zz	2	For 8mm head shaft
6	4059	Slotted Pin HD 3x16mm	2	Heavy Duty 3x16mm
7	4060	Shaft 8mm w. Crown gear N14 set	1	Set with Gear, bearings, pin
8	4061	Ball Bearing 6800zz	8	For x.quattro mechanism
9	4062	X. Quattro Mechanism set	2	Includes 4 ball bearings
10	4063	Semisphere Carbon	4	1 Semisphere with 8 sticks
11	4064	Carbon Stick	32	Snap-lock replaceable
12	4065	Self lock M7 nut	2	
13	4066	Slotted Pin 3x18mm	2	3x18mm
14	4067	Coupler for head D10	1	Head gearbox side, (grey colour)
15	4068	Internal Transmission Shaft 2.0m	1	Without couplers, rollers, clips
16	4171	Retaining Spring Clip 10mm	10	
17	4070	Roller Guide D10	5	
18	4071	Coupler for Motor D10	1	Motor side (black colour)
19	4072	Internal Transmission shaft 2.0m set	1	Set with couplers, rollers
20	4073	Carbon Fiber tube Ø29 2,0M	1	
21	4187	Tube Clamp D29 with pin	1	With locking pin
22	4075	Plastic Screw Torx 4x16	15	For case of head, motor and cable
23	4173	Retaining ring for bearing F698zz	1	V.2 for flange bearing 698zz
24	4077	Motor Assembly SV	1	Includes b/bearings, pin, ring.
25	4078	Motor Housing front SV	1	Switch side
26	4079	Motor Housing rear SV	1	Cable side
27	4080	Cable Cover	1	For cable attachment
28	4081	Cable Gland with Spiral	1	Includes nut
29	4082	Knob of Potentiometer	1	
30	4083	On-Off Switch 30A.	1	
31	4084	Electronic Module SV	1	With potentiometer
32	4085	Potentiometer	1	Without wiring
33	4086	Fuse 30A.	1	For battery kit
34	4087	Cable 14m set	1	With slide and Y type terminals
35	4088	Battery Kit set	1	2 clips, fuse holder, fuse
36	4089	Screw 3x10mm	2	For tube head assembly
37	4090	Slide Type Terminal	2	For on-off switch
38	4091	Y Type Terminal	2	For cable - battery kit
39	4172	Ball bearing F698zz	1	With flange
40	4115	X.Quattro Sphere	2	With semisheses, mechanism, bearings

online catalogue and ordering at:
www.agrotechnic.com