EdenPURE® GEN70 Super Personal Heater/Cooler EASY START-UP GUIDE

- 1. Plug the power cord supply into a grounded wall outlet (110V).
- 2. Press the power button on the back of the unit to turn the heater on.



- 3. Press the ON/OFF button on the control panel on the top of the unit. The heater will run at high heat. You will see a large red light across the front. If you want low heat, push the button that says Heat low/high once. Low heat will come on. You can tell that it is low heat because the red light across the front will be smaller. If you want cooling, push the fan button and the light across the front will turn blue.
- 4. FAN: Press the FAN button on the control panel. A blue light will come on and the PTC will stop working. Only the fan will run, producing a powerful stream of air to cool you and your surroundings.
- 5. SWIVEL: When you press the SWIVEL button, the heater will oscillate automatically. When you press it again, it will stop.
- 6. ON/OFF: When you press the ON/OFF button after the unit is on, the unit will shut off. The fan will automatically blow for another 20 seconds, which helps to extend the lifetime of the PTC.

