



# Leather Handle Kit



Our Leather Handle Kit allows makers to add handles to any project simply and easily.  
No sewing or hardware is required.

The handles, cords, and washers are made of vegetable-tanned leather and are used to create a reinforced attachment on any cloth or knit bag. After installation, the handles will have a sturdy connection and allow carrying of market purchases, knitting projects, tools, or anything that will fit. When the bag needs washing, simply remove the leather handles, wash, and re-attach the handles.

## Each Package Includes:

- 2 leather straps – 16 in X 0.5 in /41 cm X 13 mm
- 4 leather “washers” - 1in X 0.5 in /2.5 cm X 13 mm
- 4 leather cords - 2 mm x 5”/12.5 cm
- Instructions for attaching to a bag
- Instructions for sewing your own cloth bag

## User will supply:

- Bag [one of your own making or pre-sewn Cocoknits Four Corner Bag, sold separately]
- Pointed object - US 2 / 2-3mm knitting needle, tapestry needle, or cable needle (for poking hole in bag).

Julie designed these Leather Handle kits to be simple and useful for a multitude of applications. They are sold separately from our Four Corner Bags since they can be used for other projects as well.

Vegetable tanning of leather is an organic process that uses biodegradable vegetable material instead of chemicals and metals to preserve leather. It creates leather that is sturdy, hard wearing, and develops a patina with age. As a natural product, there will be variation in the coloration of the pieces in this kit. The end user may wish to treat the leather with wax or a leather conditioner to keep it supple over time.

