



ASSEMBLY INSTRUCTIONS


Please read instructions carefully before assembling this product.



























Tighten the other two remaining screws to the metal bar.




























Adjust armrest by moving forwards and backwards







Pull handle upwards to move the seat forwards and backwards by 60mm. Push handle down to lock the seat.



Pull the handle up or push down to lock or unlock the angle of the backrest.

ATTENTION

WARNING - FAILURE TO FOLLOW THESE INSTRUCTIONS MAY RESULT IN SERIOUS INJURY:

1. THIS PRODUCT IS DESIGNED FOR SITTING ONLY. DO NOT STAND ON THIS PRODUCT. DO NOT USE AS A STEP LADDER.

2.DO NOT USE THIS PRODUCT UNLESS ALL BOLTS AND PARTS ARE TIGHTENED FIRMLY.

3.IF ANY PARTS ARE MISSING, DAMAGED OR WORN, STOP USING THIS PRODUCT. REPAIR THE PRODUCT WITH THE REPLACEMENT PARTS PROVIDED BY THE MANUFACTURER.

4.DO NOT SIT ON THE ARMREST OF THIS PRODUCT.

5.THIS PRODUCT IS DESIGNED FOR ONE PERSON TO SIT AT A TIME.

6.FOR CHILDREN UNDER THE AGE OF 10, PLEASE USE UNDER ADULT SUPERVISION.