

Wildwood Desk

Tabletop Assembly Instructions



EFFYDESK

Thanks for choosing EFFYDESK!

We hope you enjoy the most coveted solid wood tabletop. May this desk serve as a stepping stone in your journey to healthy living.

It's time to *work with wonder* again.


Tools Required



3mm Allen key
(included)




4mm Allen key
(included)



Screwdriver


Tabletop Parts



Control Box



Power Cable




Extension Cord

Step 1

Connecting your wireless charger

- 1.1 Begin, by taking the split cable and grabbing the rounded end. Insert this end into the wireless charging plate found underneath the solid wood table top.




1.2 **For small size solid wood table tops**

You must bend the wire after connecting to the wireless charging plate. This step must be done before attaching the frame. This will avoid the wireless charging cable from being compressed under the frame.

For medium and large size solid wood table tops

Disregard this step.




- 1.3 Use the last and third end of the split power cable to plug into the control box. The remaining cable end will be placed into the HS Keypad port beside ports M1 and M2.



Proceed with the *Business Desk* Instruction Manual OR the *Home Desk* Instruction Manual.

EFFYDESK Instruction Manual



Technical Data

Segment Column	3	Input Voltage	100-240V
Maximum Load	310 lbs	Speed	35mm/s
Recommended Load	< 240 lbs	Certification	UL
Height Range	24" to 50"		

Accessories List

Ax8 MX12	Bx4 MX8	Cx12 MX18 Or MX16
Dx5 Zip Tie	Ex12 Rubber Pad	Fx2 MX12
Hx8 MX10	Ix6 MX10	Jx2 Hangers

Tools Required



Parts List

No.	Control Box	Qty
①		1

No.	Power Cable	Qty
②		1

No.	Lifting Column	Qty
③		2

No.	Foot	Qty
④		2

No.	Extension Cord	Qty
⑤		1

No.	Side Bracket	Qty
⑥		2

No.	Keypad	Qty
⑦		1

No.	Crossbar	Qty
⑧		1

No.	Cable Tray	Qty
⑨		1

Thank you for your order!
 If you have any issues with your product, please feel free to contact us via team@effydesk.ca or info@effydesk.ca. We will help you resolve the issue as soon as possible.
 For more information, please visit <https://effydesk.ca/pages/how-to-assemble-your-height-adjustable-standing-desk>

How to


Replace Wireless Charger

- 1 To replace the wireless charger, disconnect the power cable.




- 2 Remove the screws found on the wireless charging plate found underneath the tabletop. Repeat this step on the replacement wireless charging plate.





Remove screws from new wireless charger



Remove plate backing



Old Wireless Charger



- 3 Remove the old wireless charging plate and place the new wireless charging plate in its place. Use the same 4 screws you removed from the original to attach the new wireless charging plate underneath the desk.



- 4 Replug the wireless charging cord to the new wireless charging plate. Then use the power cable to connect to a nearby outlet. Place your device right on your desk and watch as it fast charges.





Your Wildwood desk is all set!

If you have any further questions don't hesitate to email our team of lovely EFFY experts at team@effydesk.ca

In addition, you can always book an **in-person** or **virtual installation support appointment**. You can find these options on our website under the Resources tab on our main navigation menu.

EFFYDESK

#110 - 2440 Canoe Ave
Coquitlam, BC
V3K 6C2

team@effydesk.ca
604.715.7577
effydesk.com