




Assembly and Installation Instructions for Model

30010/11FM




CAUTION - RISK OF FIRE

Installation of this fixture should be done by a licensed electrician or by a person familiar with local electrical codes and the construction and operation of this fixture.

Warning please make sure the electrical breaker is shut off before commencing with this installation. Read and familiarize yourself with these instructions before commencing.

This fixture is certified for ceiling mounting only and is suitable for Damp locations and dimmable with a Triac Dimmer. Supplied with a 120v A/C LED panel with a clear glass cover plate, no driver required.

Package Contents		
Part	Description	Qty
A	Mounting bracket	1
B	Junction-Box mounting bolts	2
C	Ceiling screws and anchors	2
D	Electrical wire connectors	3
E	Fixture assembly	1
F	Fixture mounting screws	3
F	Electrical wire connectors	3
G	Acrylic diffuser	1
H	Glass diffuser	1
I	Mounting bracket	1
J	Allen wrench and screw	1



Installing the fixture *please ensure the electrical breaker is switched off before commencing*

- Loosely attach the supplied Mounting Bracket (A) with the two supplied mounting bolts (B) to the Junction-Box. With a pencil mark the two holes for the supplied Ceiling Anchors (C), remove the mounting bracket and drill two holes for the ceiling anchors and insert the two plastic anchors. Making sure the electrical supply wires from the Junction-Box are inserted through the mounting bracket, re-attach the mounting bracket to the Junction Box and secure with both the Junction box mounting bolts and the ceiling anchor screws.
- Connect the supply wires to the fixture wires using the supplied Electrical wire connectors (F). White supply wire to the White fixture wire, Black supply wire to Black fixture wire and the ground Bare Copper or Green wire to the Green fixture wire. Once the electrical wire connectors are securely fastened it is recommended to tape these connectors with electrical tape.
- Attach the Fixture Assembly (E) to the Mounting Bracket (A) with supplied Mounting Screws (F).
- Attach Acrylic Diffuser (G) and hold in place whilst sliding into the two slots of the side brackets the Glass Diffuser (H). Attach the Mounting Bracket (H) and secure in place with Allan Screw (J)
- Switch on the electrical breaker switch and your new fixture is ready for many years of trouble free use