

7 static single colors:



9 colorful dynamic light effects:


1. Full color gradient
2. Full color flow clockwise
3. Rainbow clockwise
4. Full color section two-way flow
5. Light blue with red dots flow clockwise
6. Full color section meteor with white color surround
7. Green & White gradient clockwise
8. Colorful (Full color flash)
9. Enthusiasm (Orange/Yellow/Red color flow)

6 dynamic light effects under music modes:

1. Full colors flow
2. Full colors pulse
3. Full colors short section flash
4. Full colors gradient pulse
5. Blue/Red/White color flow
6. Purple color flow



LED Neon Rope Light Combo



Indicator Light



Switch Button:

Single press on the button to turn on/off the light

Static Single Color Modes Changing Button:

Single press on the button to change light color

Colorful Dynamic Modes Changing Button:

Single press on the button to change dynamic light effects

Music Modes Changing Button:

Single press on the button to change dynamic light effects according to the music rhythm.

Switch Button:

Single press on the button to turn on/off the light
Long press for 3s to adjust the brightness (5 brightness levels)

Static Single Color Modes Changing Button:

Single press on the button to change light color
Long press for 3s to adjust the dynamic lighting speed

Music Modes Changing Button:

Single press on the button to change dynamic light effects according to the music rhythm.

