

## AllStitch Embroidery Supplies: Home Embroidery Machine Bobbin Size Comparison Chart

*This information has been provided to us by our customers, we can not be held accountable for incorrect information. Please contact us with any errors or additions to this information.*

*To be 100% sure whether your machine takes Style L or 15/A bobbins, it may be a good idea to check you machine manual.*

To Purchase Embroidery Bobbin Visit [www.AllStitch.com](http://www.AllStitch.com)

Machine Brand	<b>Style L Bobbins</b> (Similar to Brother SA-155)	<b>Class 15 / Style A Bobbins</b> (Similar to Brother SA-156)
<b>Babylock</b>	Alliance (BNAL) Endurance 2 (BND9-2) Enterprise BNT10, BNT10L, ENT10 Embroidery Professional EMP6, BMP6, BMP8 & BMP9 BND9, BND9-2 Ellageo (ESG, ESG2, ESG3) Ellure (ESL) Esante (ESE, ESE2, ESI, ESI2) Espire (ESP) Jane (BL500A) Quilter's Choice Pro (BLQP) Endurance 6 Needle (BND9)	Aventura (BLMAV) Crafter's Choice (BLCC) Creative Pro (BL37), Creative Pro (BL40) Decorator's Choice (BLDC) Destiny (BLDY) Ellageo (BLL), Ellageo Plus (BLL2) Ellure (BLR), Ellure Plus (BLR3) Ellisimo (BLSO), Elisimo Gold (BLSOG), Elisimo Gold 2 (BLSOG2) Ellegante (BLG), Ellegante 2 (BLG2), Ellegante 3 (BLG3) Esante (BLN) Espire (BLSR) Flourish (BLFMO) Grace (BL40A) Journey (BLJY) Intrigue (INT) Quilter's Choice (BLQC) Sofia (BL137A2), Sofia 2 (BL137A2) Spirit (BLPY) Symphony (BLSY) Unity (BLTY)
<b>Bernette</b>	Deco 350 & 650 (by Brother)	
<b>Bernina</b>	Artista 165, 170, 180, 185QEE, 200E, 630E, 640E Aurora 430QEE, 440QEE Deco 300, 500, 600, 930	Deco 330, 340 Bernette 730E & 740E

Machine Brand	<b>Style L Bobbins</b> (Similar to Brother SA-155)	<b>Class 15 / Style A Bobbins</b> (Similar to Brother SA-156)
<b>Brother</b>	<b>CS-8072</b> <b>PC-2800, 3000, 5000, 6000, 6500, 7000, 7500, 8200, 8500D</b> <b>PE-100, 150, 150V, 170D, 180D, 190D, 200, 300S, 400D</b> <b>PR-600, 600II, 600C, 620, 620II, 650, 655, 1000, 1000E</b> <b>PRS-100</b> <b>PS-1000, 1250, 1700, 1800, 1900, 1950, 2100, 2200, 2300, 2500</b> <b>ULT-2001, 2002D, 2003D</b>	<b>BB- 370</b> <b>BC-1000</b> <b>BP- 2100, 2800</b> <b>CE-4000, 1100PRW, 5000PRW, 5500PRW, 7070PRW, 8080PRW, 8150</b> <b>CP-6500, 7500</b> <b>CS-100T, 5055PRW, 6000, 6000B, 6000i, 6000T, 8150</b> <b>Designio- DZ3000, DZ820E</b> <b>DreamCreator- VM5100, VQ2400</b> <b>Dream Machine - XV8500D</b> <b>DreamWeaver- VQ3000</b> <b>DreamWeaver XE- VE2200VM6200D</b> <b>Duetta 4500D, Duetta 2 4750D</b> <b>ES-2000, EX-660</b> <b>HE- 1, 120, 240; HC - 1850; HS-2000, 2500</b> <b>Innov-is 40, 40e, 80, 85e, 900D, 950D, 1000, 1500D, 2500D, 2800D, 4000D, 5000, 6750D, NX570Q</b> <b>JX- 2517</b> <b>LB - 6770PRW, 6800PRW, 6800THRD</b> <b>LS - 30, 590,1217, 2125, 2125i, 6770</b> <b>LX- 2500, 2763, 3125, 3125E, 3850</b> <b>NX-200, 250, 400, 400Q, 450, 450Q, 600, 650Q</b> <b>Pacesetter PS21, PS-3700</b> <b>PC-210, 210PRW, 420, 420PRW</b> <b>PE-500, 700, 700II, 750D, 770, 780D</b> <b>Project Runway- 85e</b> <b>Quattro 6000D, Quattro 2 6700D, Quattro 3</b> <b>QC-1000</b> <b>SC- 9500</b> <b>SE-270D, 350, 400, 425</b> <b>Simplicity- SB170, SB3129, SB530T, SB700T, SB7050E, SB7500, SB7900E, SC3000, SC9500, SE270D, SE350, SE400, SE425, SM2700, SM8270, SQ9000, SQ9050, SQ9185</b> <b>SM- 2700</b> <b>SQ - 9000, 9050</b> <b>VX-1435</b> <b>XB- 2510</b> <b>XL-2230, 2600, 2600i, 2610, 2800, 3100, 3500, 3500T, 3510, 3750, 5130, 5232, 5340, 5500, 5600, 5700, 6452, 3510, 3500T, 6562, 7700</b> <b>XM- 2701</b> <b>XR- 40, 46C, 52C, 65T, 1300, 4040, 7700, 9000, 9500PRW</b>

Machine Brand	Style L Bobbins (Similar to Brother SA-155)	Class 15 / Style A Bobbins (Similar to Brother SA-156)
<b>Husqvarna</b>	Viking Designer I, II, Diamond Viking Designer Ruby Viking Quilt Designer II Viking Platinum 950E Viking Scandinavia 100, 300, 400	
<b>Janome</b>	MB-4	All new Elna Memory Craft 200E, 350E, 9900, 11000, 12000, 15000 5000, 9000, 9500, 9700, 300E, 350E, 10000, 10001 <i>(Just about all Janome's use the Class 15/StyleA)</i>
<b>Juki</b>	TL-98	T-100, E80
<b>Kenmore</b>		All Models
<b>Pfaff</b>	Creative 2170, 2144, 2134, 2124 2140, 7570, Creative Vision	
<b>Quantum Futura</b>		100, 104, 117,, 118, 132, 132Q, 140Q 2623, 2638, 2639, 2662, 3962 IZEK 7400 series
<b>Singer</b>		6400 Series 7312, 7322, 7350 Scholastic, Scholastic Plus XL1000, XL6000 9910, 9920, 9940
	Singer recommends <b>not</b> using prewound bobbins in the following Futura Embroidery machines: CE-100, CE-150, CE-200, CE-250 and CE-350	
<b>Viking</b>	Designer I, II, SE, Viking Rose	
<b>White</b>	3300, 4400	Rotary

*This information has been provided to us by our customers, we can not be held accountable for incorrect information.  
Please contact us with any errors or additions to this information.*

*To be 100% sure whether your machine takes Style L or 15/A bobbins,  
it may be a good idea to consult your owner's manual.*

To purchase embroidery bobbins,  
please visit: [www.AllStitch.com](http://www.AllStitch.com)