



Barbeque Grill CLEANER + DEGREASER

REMOVES HEAVY GREASE BUILD UP

For bbq grills (interior & exterior), grates, ovens, microwaves, pot/pans, porcelain, ceramic ware, stainless steel, rotisseries, and burner drip pans.

- Dissolves and cleans tough burned-on grease, food, and residue.
- Fast, streak-free formula.
- Leaves no oily residue.
- Contains no phosphates.

DIRECTIONS

Allow hot surfaces to cool before cleaning. For exterior surfaces, test in an inconspicuous area prior to use. Avoid electrical connections, switches, heating elements, thermostats, pilot lights, etc.

Grates: Spray product liberally onto surfaces, and allow product to stand 1-2 minutes. Scrub with a grill brush. Rinse clean with water.

All Other Surfaces: Spray directly onto soiled surfaces. Wait 1-2 minutes, then wipe away soil and residue with a clean cloth or sponge. Scrubbing may be necessary on heavily encrusted areas. Wipe clean with wet sponge or cloth. To achieve a brilliant shine on stainless steel, use Nuvera™ Stainless Steel Cleaner + Polish.

Description Nuvera™ Barbeque Grill Cleaner + Degreaser
 Size 24 fl. oz. (709 ml)
 Manufacturer Item Number 41010
 Item UPC 790732410108
 Case Code 10790732410105



nuveraproducts.com