

CLEANER Maker

FOR SINGLE AND MULTI-CUP MACHINES

Quickly removes lime and mineral build up from coffee makers and other appliances. Keeps your coffee maker clean for great tasting results.

DIRECTIONS

For sensitive skin, please wear household rubber gloves. Rinse sink and other cleaned items after using product. Always follow appliance manufacturer's instructions and precautions.

Automatic Drip Coffee Maker: Remove any used or unused coffee from machine. Fill reservoir with water. Add 1 oz of cleaner for every 16oz. (2 cups) of water. Run solution through a complete cycle of the coffee maker. After brew cycle is complete, discard pot contents down sink drain. Rinse coffee maker thoroughly by cycling 2 reservoirs of fresh, clean water through machine. Repeat cleaning procedures monthly to maintain coffee maker in its top operating condition.

Single Cup Coffee Maker: Remove any used or unused coffee from machine. Fill reservoir with water. Add 1 oz of cleaner for every 16oz. (2 cups) of water. Place cup in coffee maker and run a brew cycle. After brew cycle is complete, discard cup contents down sink drain. Repeat until reservoir is empty. After cleaning is complete, rinse coffee maker thoroughly by cycling 2 reservoirs of fresh, clean tap water through machine. Wash reservoir before each cycle. Repeat cleaning procedures monthly to maintain coffee maker in its top operating condition.

Description	Nuvera® Coffee Maker Cleaner
Size	8 fl. oz. (237 ml)
Manufacturer Item Number	
Item UPC	

nuveraproducts.com

