



# Cooktop CLEANER

## REMOVES GREASE, LEAVES A STREAK-FREE SHINE

Gentle but effective formula cleans without scratching or leaving a residue. Cleans and shines all types of cooktop surfaces: glass-ceramic, enamel, stainless steel, chrome. Removes tough burnt-on food spills and splatters.

## DIRECTIONS

For sensitive skin, please wear household rubber gloves. Do not use Nuvera™ Cooktop Cleaner in combination with other cleaning products.

Allow cooktop to cool before cleaning. Apply product to surface. Rub in a circular motion with paper towel, sponge, or cloth to clean (avoid steel wool or abrasive pads). Wipe off excess and buff with paper towel or dry cloth. Close cap after use. Use regularly to protect and maintain your cooktop.

Description . . . . .	Nuvera™ Cooktop Cleaner
Size . . . . .	8 fl. oz. (236 ml)
Manufacturer Item Number . . . . .	41023
Item UPC . . . . .	790732410238
Case Code . . . . .	10790732410235

