



INSTRUCTIONS





PART LIST




- 1 Grill Grate x 1
- 2 Grill Collar x 1
- 3 Firepan Grate x 1
- 4 Firepan x 1
- 5 Tripod Top x 1
- 6 Triple Turnbuckle Lid Hook x 1
- 7 Lid Handle x 1
- 8 Lid Handle Supports x 2
- 9 Hook Plate x 1
- 10 Handle Screws x 2

- **11** Lid x 1
- 12 Barrel x 1
- 13 Hanging Cable x 1
- 14 Pistol Grip Shackle x 1

15 Pistol Grip Trigger x 1

- 16 Pistol Grip Handle x 1
- 17 Barrel Turnbuckle x 1
- 18 Leg Shackle x 3
- $19_{\text{Leg Top x 3}}$
- $20~{\scriptstyle Leg~Bottom~x~3}$

STEP ONE



Connect the upper and lower halves of the legs. Screw the feet into the bottom of each leg.

Connect the shackles to each leg

В


Sleeve the pistol grip slider over the top of a leg. Then attach the cable and small shackle to the pistol grip lever.

Connect the leg with the pistol grip to the tripod top arm with an open top. Connect the remaining legs.

Feed the cable through the tripod top, over the pulley wheels, and down through the center of the tripod top.

STEP TWO


HANGING THE BARREL



 ${\sf A}$ Connect the turnbuckles to the sides of the barrel.

B Hang the barrel by the three hook-ended turnbuckles to the tripod's three shackles.

STEP THREE




A Place the fire pan and fire pan grate together on the spiral tracks. Spin the fire pan to adjust the height.

 \boldsymbol{B} Place the grill collar and grill grate on top of the barrel.

STEP FOUR

ASSEMBLING THE LID



A Screw on the lid handle and hook plate.


Note the handle supports have a curved end that seat against the round handle.

B Connect the triple turnbuckle hook assembly to the lid.

Twist the turnbuckles until they are all roughly and equal length.

STEP FIVE

HANGING THE LID



A Place the lid over the collar.

B Connect the loose end of the cable to the clip on top of the turnbuckle assembly.

Crack open a beer and get ready to grill.

WARNING

FOR OUTDOOR USE ONLY

DO NOT LEAVE FIREPIT UNATTENDED WHEN IN USE

ROUGH AND TUMBLE LIMITED WARRANTY

ROUGH AND TUMBLE LIMITED WARRANTY

BURCH BARREL designs and manufactures with functional excellence in mind. The BARREL and accessories are constructed with state-of-the-art materials and designed with meticulous attention to detail. Our Limited Warranty guarantees everything we build against manufacturing defects in materials and craftsmanship for the practical lifetime of the product.

Our Warranty does not cover damage due to normal wear and tear, neglect, or misuse but these can be repaired or replaced for a reasonable charge.

Warranties will be reviewed case by case and Burch Barrel will decide to either repair or replace manufacturing defects in material or craftsmanship. In a case of warranty repair, we may send replacement parts or source a local, quality handyman to repair the product for you at no cost. Shipping a barrel is expensive and inconvenient for you so working with a local professional is the best solution we have found.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Call or email us to start a Warranty claim - 406-924-2424; service@burchbarrel.com