


Rectangle LED Panel Lights Installation Instructions




Product Specifications						
Model No.	HCP-173400-R	HCP-173400-R-ND	HCP-173400-R-DALI	HCP-14340-R-REC	HCP-17340-R-SM	HCP-17341-R-SM
Material	Aluminium + Polycarbonate			Aluminium	Aluminium	Aluminium
Colour	White			White	White	White
IP Rating	IP20			IP20	IP20	IP20
Cut Out	N/A			1210mmx310mm	N/A	N/A
Input Voltage	240v			N/A		
Protection Class	2 (No Earth Required)			N/A		
Lamp Base	Built in LED			N/A		
Lamp Wattage	1x 40w			N/A		
Colour Temp	Tri-Colour - 3000k, 4000k, 5500k			N/A		
Lumens	2900lm, 3100lm, 3300lm			N/A		
CRI	> 90			N/A		
Dimmable	Yes - Triac Dimmable	No	Dali Dimmable	N/A		
Warranty	5 Years Replacement*			5 Years Replacement*		









Important Safety Issues:

- This product must be installed by a qualified electrician according to AS/NZS 3000.
- Ensure all electrical mains are disconnected before any installation.
- Modification of this product will void any warranty.
- Havit Commercial does not take responsibility for wrong installation, incorrect use, or use of installation material that does not belong to the system.
- · Aluminium and 304SS fittings must not be installed within 5km of any salt water environments.
- All o-rings and seals must be in place correctly to maintain warranty
- This form may be updated at any time due to product improvements, please check online installation form for most current version.

HCP-173400-R Steps for Installation in grid ceiling:

- 1. Make sure that the electrical circuit is free of voltage (master switch off)
- Remove ceiling tile where light is to be installed.
- 3. Connect LED Driver to plug base already in ceiling For DALI Model, Connect dali signal cable to driver.
- 4. Insert Panel into ceiling space and allow for fitting to sit back onto ceiling grid.
- 5. All connections must be carried out carefully, inspect all contacts before switching back on the electric circuit.

HCP-173400-R Steps for Installation using HCP-17340-R-REC Recesed kit:

- 1. Make sure that the electrical circuit is free of voltage (master switch off)
- Cut hole using dimension on line drawing and in table.
- 3. Connect LED Driver to plug base already in ceiling For DALI Model, Connect dali signal cable to driver.
- 4. Insert Panel into recessed panel and allow for fitting to sit back onto panel.
- 5. All connections must be carried out carefully, inspect all contacts before switching back on the electric circuit.

HCP-173400-R Steps for Installation using HCP-17340-R-SM + HCP-17341-R-SMSurface Mount kit:

- . Make sure that the electrical circuit is free of voltage (master switch off)
- 2. Assemble surface mount kit using screws provided making sure to leave 1 side off to allow for panel to slide in.
- 3. Attach surface mount kit in desired location using appropriate screws for application.
- 4. Connect LED Driver to plug and slide panel into place For DALI Model, Connect dali signal cable to driver.
- 5. Reattach side using screws provided.
- 6. All connections must be carried out carefully, inspect all contacts before switching back on the electric circuit.

Must be installed by a licensed electrician

Contact Details:

Australia

8/133 Beauchamp Road Tel: 02 9381 83 Matraville NSW 2036 Email: sales@ha

Email: sales@havitcommercial.com.au Web: www.havitcommercial.com.au

