# Sea-Legs
USER GUIDE

REMOTE PAIRING

1. Ensure the your Sea-Legs box is properly connected to a power source.

2. Hold the Front Up + Front Down button simultaneously for 2 seconds to enter discovery mode.

3. With the box now in discovery mode, press any button on your Sea-Legs remote to begin pairing.

4. Your remote will now be paired with the box. If the remote does not appear to be operating your system, press the power button on the remote and then try to operate the system again.

The system will automatically turn off after 2 minutes of inactivity to prevent accidental button presses.

5. If you ever need to unpair your remote, hold the Front Up + Front Down button for 12 seconds.

BOX OPERATION

FRONT UP   REAR UP

Wi-Fi

DISCOVERY MODE (HOLD 2 SEC)
FACTORY RESET (HOLD 12 SEC)

FRONT   *The pontoon lift that goes where you go.*   REAR

BLUETOOTH ENABLE (HOLD 2 SEC)
BLUETOOTH ERASE (HOLD 12 SEC)

www.sea-legs.com

FRONT DOWN   REAR DOWN

REMOTE OPERATION

Keyfob Remote

RAISE/LOWER ALL

LED INDICATOR

RAISE/LOWER FRONT   RAISE/LOWER REAR

FRONT BOAT REAR

FRONT BOAT REAR

TRIPLE TUBE REMOTE

LED INDICATOR
POWER ON / OFF   POWER
RAISE/LOWER ALL   BOAT
RAISE/LOWER FRONT   FRONT
RAISE/ LOWER REAR   REAR
RAISE/ LOWER PASSENGER   PASS
RAISE/ LOWER DRIVER   DRIVER

Sea-Legs

TWIN TUBE REMOTE

POWER   LED INDICATOR
POWER ON / OFF
BOAT   RAISE/LOWER ALL
FRONT   RAISE/LOWER FRONT
REAR   RAISE/ LOWER REAR

Sea-Legs

Application Guide

1 Download

Download the **Sea-Legs Bluetooth** app on the Apple App Store or Android Play Store.

2 Connect

Launch the app, then enable Bluetooth on the box by holding Rear Up + Rear Down simultaneously for 2 seconds.

The Sea-Legs system will automatically advertise a unique network name.

The app will show the system, click to connect to it.

Hold for 2 Sec

3 Set Password

After launching the app, you will be prompted to create a unique pin.
If you do not do this, Bluetooth will turn off when you close the app.

Enter the old pin, which is defaulted to: *654321* and then create your new one.

To unpair devices and reset your pin to default, hold Rear Up + Rear Down simultaneously for 12 seconds.

4 Update

The app will prompt you to install new firmware if available.

It is important to install the firmware updates when offered as the app is designed to operate with the firmware with which it is bundled.

interactive
TECHNOLOGIES, INC. | *www.ideasthatfloat.com*