

# colapz®

## FRESH MINI BASIC KIT

### USER INSTRUCTIONS

CONTENTS:

1 x FRESH MINI VESSEL • 1 x WATER CONTROL VALVE • 1 x ELBOW • 1 x 10.5CM TUBE • 1 x STORAGE BAG

**1** WATER CONTROL VALVE COVER AIR RELEASE BUNG (FOR USE WHEN FITTED WITH THE TAP)

FILL CAP

RETAINING STRAP

DISPENSING TAP

RELEASE THE RETAINING STRAP AND TWIST THE VESSEL INTO THE UPRIGHT POSITION.

**TOP TIP!** ADDING WATER AT THIS STAGE WILL SUPPORT THE VESSEL WHILE YOU ARE ASSEMBLING IT

**2** WATER INLET

LOCKING NUT (a)

WASHER (b)

WASHER (c)

WATER OUTLET

WATER CONTROL VALVE

TAKE THE WATER CONTROL VALVE AND REMOVE LOCKING NUT (a) AND WASHER (b) BY UNSCREWING THEM FROM THE MAIN BODY OF THE VALVE. LEAVE WASHER (c) ON THE THREADED TUBE.

**3** WATER OUTLET

90 DEGREE ELBOW

SCREW ON-TO WATER OUTLET

INSERT 10.5CM TUBE

TAKE THE 90 DEGREE ELBOW AND SCREW TO THE WATER OUTLET. THEN PUSH THE 10.5CM TUBE INTO THE BOTTOM OF THE ELBOW. THIS WILL PREVENT ANY VIBRATION WHEN THE VESSEL IS RE-FILLING.

**4**

LOCKING NUT (a)

WASHER (b)

UNDERSIDE OF VESSEL LID

REMOVE THE VESSEL LID AND THE WATER CONTROL VALVE COVER. INSERT THE WATER CONTROL VALVE INTO THE HOLE AND FIT THE SILICONE WASHER (b) AND SCREW LOCKING NUT (a) ONTO THE WATER INLET. TIGHTEN THE NUT UNTIL VALVE IS FITTED TIGHTLY ONTO THE LID.

**5**

AUTO STOP (HAS AN ARROW TO INDICATE AUTO STOP CONNECTOR) (NOT INCLUDED)

HOSE END FITTED CORRECTLY (NOT INCLUDED)

OPEN THE HOSE PIPE AND ATTACH THE 'AUTO STOP' CONNECTOR AT ONE END AND THE SECOND CONNECTOR TO THE OTHER END. (NOT INCLUDED)

**6** MAINS WATER IN

'AUTO STOP' HOSE CONNECTOR END (NOT INCLUDED)

TAP CONNECTOR (NOT INCLUDED)

VESSEL

REPLACE THE LID ONTO THE VESSEL ENSURING IT IS FITTED SECURELY. SCREW THE TAP CONNECTOR (NOT INCLUDED) TO THE WATER CONTROL VALVE. CONNECT THE 'AUTO STOP' HOSE CONNECTOR (NOT INCLUDED) TO THE TAP CONNECTOR.

**7**

MAINS WATER SUPPLY (NOT INCLUDED)

SECOND TAP CONNECTOR (NOT INCLUDED)

CONNECT THE OTHER END OF THE HOSE TO MAINS WATER SUPPLY USING THE SECOND TAP CONNECTOR. (NOT INCLUDED)

**8** WATER CONTROL VALVE

SUBMERSIBLE PUMP

DROP YOUR PUMP INTO THE LARGE CAP OPENING AND CONNECT THE PUMP TO YOUR CARAVAN. ONCE THE MAINS WATER IS TURNED ON THE VESSEL WILL FILL TO APPROXIMATELY 6-7 LITRES AND THE VALVE WILL AUTOMATICALLY SHUT OFF AND REFILL AS THE WATER IS USED.

**9**

WITH TAP FITTED (WATER CARRIER)

WITH CAP FITTED (BUCKET)

YOUR VESSEL CAN ALSO BE CONVERTED TO A WATER CARRIER OR BUCKET BY FITTING THE TAP OR CAP TO THE FRONT WATER EXIT.

### OPTIONAL EXTRA'S

**WATERING CAN PARTS**

SPOUT

FILLING TUBE

ELBOW

ROSE HEAD

**INSULATING JACKET**

PREVENTS WATER FREEZING

**FOLDING STAND**

FOR USE WITH 8L VESSEL

CLIPS TOGETHER FOR STORAGE

**7.5 METRE HOSE EXTENSION KIT**

INCLUDES HOSE END CONNECTORS

7.5M HOSE