



## SINGLE FLEXI WASTE PIPE


### USER INSTRUCTIONS



EXTEND THE WASTE PIPE TO THE DESIRED LENGTH. PIPES EXTEND UP TO 1 METRE.



THE WASTE PIPE CAN BE JOINED TO ANOTHER FLEXI-PIPE. INSERT THE RIGID END INTO THE FLEXIBLE END OF THE SECOND WASTE PIPE.



THE WASTE PIPES CAN BE SHAPED TO SUIT THE LOCATION OF THE WASTE MAINS.



BEFORE PACKING AWAY, FLUSH THROUGH WITH WATER.