

LINEAR RGB WALL WASH INTERNAL SETTINGS

USE UP / DOWN BUTTONS TO SELECT MODE

PRESS MENU BUTTON TO ACCESS MODE SETTING

USE UP / DOWN BUTTONS TO ADJUST MODE SETTING

PRESS MENU BUTTON TO RETURN TO MODE SELECTION

MODE	MODE SETTINGS
A-1	FUNCTION - PREPROGRAMMED 7 COLOR FADE-IN / FADE-OUT CYCLE *
	PRESS MENU. Use UP / DOWN buttons to set speed of Fade-In / Fade-Out Cycle
A-2	FUNCTION - PREPROGRAMMED 7 COLOR FLASH CYCLE (NO FADE-IN / FADE OUT)*
	Press MENU. Use UP / DOWN buttons to set speed of Flash Cycle
A-R	FUNCTION - ADJUST LEVEL OF RED SATURATION
	Press MENU. Use UP / DOWN buttons to set the level of RED light displayed
A-G	FUNCTION - ADJUST LEVEL OF GREEN SATURATION
	Press MENU, Use UP / DOWN buttons to set the level of GREEN light displayed
A-B	FUNCTION - ADJUST LEVEL OF BLUE SATURATION
	Press MENU, Use UP / DOWN buttons to set the level of BLUE light displayed
A-D	FUNCTION - ADJUST BRIGHTNESS
	Press MENU, Use UP / DOWN buttons to set the brightness level (001-Low / 255-High)
A-5	FUNCTION - STATIC COLOR FLASH-ON / FLASH-OFF
	Press MENU. Use UP / DOWN buttons to set speed of Static Color Flash Cycle (000-)
ADR	FUNCTION - DMX ADDRESS (SET FOR USE WITH DMX CONTROLLER)
	Press MENU, Use UP / DOWN buttons to set DMX ADDRESS (001-MASTER / SLAVE)

***PREPROGRAMMED COLORS - RED, GREEN, BLUE, YELLOW, CYAN, PURPLE, WHITE**