

SYMBOLS AND WARNINGS

- ▲ The **WARNING** symbol indicates a potentially hazardous condition/situation. The warnings throughout this document, and on your equipment, if any, are for the protection of people and property. Failure to abide by warnings will result in a waiver of all liabilities, loss of your warranty, and could result in equipment damage and or failure, property damage, risk of serious bodily injury, and or death to operators, riders, and those nearby. The symbol may appear in various colors and in conjunction with other symbols.

WARNINGS!

- ▲ Prior to assembly and use, read and follow all instructions and warnings. Following all instructions and obeying all warnings before and during use is necessary for safe operation. For additional information or to obtain replacement copies of instructions, call 1-800-451-1903.
- ▲ Do not use the mat if it is damaged or unstable.
- ▲ The mat surface may be slippery in wet conditions; use caution if the surface is wet as traction may be reduced.
- ▲ Do not use the mat if its surface is covered with ice, snow, dirt, leaves, or other debris. Remove accumulations and sweep the surface clean before use.
- ▲ Do not use the mat unless sufficient maneuvering room is available at both ends of the mat to assure safe travel when entering and exiting the mat.
- ▲ The mat is designed to minimize (but not eliminate all) trip hazards; therefore, use caution at all times.
- ▲ Do not use the mat unless it is flush against the door threshold or raised landing.

PLACING

1. If the door threshold is equal to the height of the mat, place the mat in the desired location.
 - a. If trimming is needed to decrease the height of the mat, see 'TRIMMING/NOTCHING' section.
2. Ensure that the mat is flush against the door threshold or raised landing.
 - a. If notching is needed to accommodate obstacles such as the door jamb, see 'TRIMMING/NOTCHING' section.

TRIMMING/NOTCHING

1. Trim or notch the mat as needed. See FIG. 1 as a reference when trimming.
 - ▲ Trimming can only be done to decrease the height of the mat, not the width.
 - ▲ Use caution when using hand tools as serious injury may result due to unexpected binding or pinching of the rubber mat material. Always follow hand tool manufacturer's safety guidelines.
2. Ensure that the mat is flush against the door threshold or raised landing.

ANCHORING

1. If the mat is unable to stay securely in place, anchor the mat to ensure it does not move from the intended position (anchoring hardware is not provided).
 - a. Anchor the mat using locations shown in FIG. 2.

SAFETY AND MAINTENANCE

1. Keep the mat surface clear of ice, snow, dirt, leaves, and other debris. For ice and or snow, remove accumulations and sweep surface clean. For dirt, leaves, and other debris, sweep surface or wash with a soft bristle brush and non-alkaline detergent. Rinse well and allow to dry before use.
2. Ensure that the mat is always flush against the door threshold or raised landing.

