

Standing Support Sling Washing Instructions

The sling should be hand washed because the metal rings and plasti belt buckle may damage the washing machine or vice versa. The sling should be hung to air dry. Warm wash with mild detergent is recommended.

- Use mild detergent
- Set washing machine to warm wash/cold rinse cycle
- Do not dry on steam pipes, conventional heaters, wood stoves or other similar devices
- Tumble dry on air/fluff cycle only or hang dry
- Do not use chlorine based bleach
- Do not dry clean