




OWNER’S FIELD GUIDE

CLASSIC JACK 140


With 140 sq. ft. of interior living space, a generous shade awning, and our premium 100% cotton duck canvas throughout, the Classic Jack 140 is built tough for everything from extended wilderness basecamps to styled out desert retreats. Stretch interior pockets, brass details, and canvas carry bags round out the kit.

S P E C S	SIZE 10’ x 14’ x 6.5’	MATERIAL 100% Cotton Duck Canvas, (8.5oz walls & 10oz roof) Treated for water resistance and anti-mold 14oz Laminated Vinyl Floor. Heavy-duty and fully waterproof No-See-Um Mesh window and door interiors	 springbar DURABLE IMPORTS BUILT TO WEATHER ANY WEATHER Designed in SLC, Utah. Made in China
	WEIGHT 90 lbs. (Tent body: 64 lbs.) (Poles: 26 lbs)		
	PACKED DIMENSIONS 48 inches x 12 inches x 12 inches	HARDWARE Galvanized steel 10 x 14 Springbar® pole set Plated steel 12” nail stakes	

* * C L A S S I C J A C K 1 4 0 I N C L U D E S * *


Classic Jack 140 x 1 	Carry Bag x 1  Pole Bag x 1 	Spring Bar x 4  Ridge Pole x 2  Steel Sleeve Pole x 1 	Adjustable Awning Poles x 2  Upright Poles x 2 	Plated steel 12” nail stakes x 18  Tension Rope with Tie Guy x 2 
---	---	--	--	---

SPRINGBAR TENT SET-UP GUIDE




1. Stake it Down.
Select and level site and keep the tent as ‘square’ as possible.

Springbar Tents **MUST BE SECURELY STAKED DOWN** to function.




2. Insert Ridge Poles and Spring Bars.
Use 2 ridge poles, 1 steel sleeve, and 4 spring bars.




3. Tension the Roof Panel.
Place the ridge poles end to end and press down to tension the roof. Slide the steel sleeve over the connection point to secure the ridge.


Tip: The tension screw may be adjusted to achieve more or less tension as needed.



4. Install One Upright Pole.
Tip: Assemble the upright pole on the shortest setting. After installing, lengthen the pole until the walls are taut—but not too tight.



5. Install Second Upright Pole.
Tip: Follow the same procedure outlined in Step 4.



6. Enjoy your Classic Jack 140.
Tip: The awning can be rolled up and secured, or extended using 2 included awning poles, tension ropes, & tie-guys



WOOD STOVE COMPATIBLE WHEN USED WITH REQUIRED ACCESSORIES AND SAFETY GUIDELINES

Requires:

- + Springbar Zip-In Stove Jack Accessory
- + Winnerwell Stainless Steel Wood Stove
- + Winnerwell Accessories:
 - 45 degree elbows (qty 2), double wall pipe section, flashing kit, fireproof mat
- + Adherence to All Safety Guidelines (included with Zip-In Stove Jack Accessory)



Winter Camping Tip
Springbar Tents are not intended to carry heavy snow loads.


If snow fall is expected during your camp, snow accumulation must be managed and brushed from roof as needed.



MAINTENANCE TIPS

STORE IT DRY, STORE IT CLEAN!
That goes for the poles too.

With proper care, a Springbar® Tent is built to last a lifetime.



REPAIRS

We work hard to keep tents in the great outdoors and out of landfills. Our Salt lake City Sew Shop can repair or replace just about anything. It’s how we do sustainability.



Contact us to schedule a repair.



SATISFACTION GUARANTEE

Love your tent or we’ll make it right.
We’ve got you covered.



SERVICE & SUPPORT

Springbar® representatives are standing by to assist you

By Email: service@springbar.com
By Phone: (801) 486-4161
By Post: 4026 S West Temple
Millcreek, Utah, 84107

“DISCOVER A NEW PLEASURE IN CAMPING”



Jack Kirkham Sr. circa 1962
Inventor of the Springbar® Tent