PR A | M Professional Speech Teleprompter (TP-SPH)

Assembly Manual



What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.

NOTE: If you have purchased Speech teleprompter (TP-SPH-01), you will receive the following:



All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

NOTE: If you have purchased Speech teleprompter (TP-SPH-02), you will also receive the following:



Teleprompter **Setup**

• To keep the Stand Platform in a static position (non-movable), lock down the wheels using the provided brakes.



 Attach the main rod with a telescopic rod and secure it by twisting them.





• Now insert the main rod onto the Base Platform and tighten bolts with the Allen key's help.





• If you want to extend the stand's height, you can raise the 3rd section using a speed crank knob. Tighten the knob after getting the desired size.





 If you further need to increase the height, then loosen the bolt from the bottom of the telescopic rod, adjust as per the required height and tighten the bolt to secure.





• Loosen both the knobs of the iPad tray clamp and adjust as per the required height.



 Loosen the knobs of the iPad clamp to insert both rods & tighten the knobs to secure them.





• Loosen the knob of iPad tray, Insert the iPad section & tighten the knob.





 Attach the iPad tray with clamp and tighten both side knobs to secure it.





• Centre align the glass and place in the glass holder and tighten the knob to secure.





NOTE: You can adjust the angle of the glass by using the provided knob, as shown.



Monitor **Setup**

• For installing LCD Monitor, first, remove the I-Pad Holder tray. Now, put the LCD monitor on the base platform.





• Now, loosen the knobs of the LCD monitor, as shown in the image.



• The LCD Monitor has different ports; now, connect the HDMI cable to the HDMI port.





• Now, connect the power adapter cable to the respective port.





• Lastly, insert the bolts into the Base Platform to secure the LCD monitor with it.





YOUR PROAIM SPEECH TELEPROMPTER ALL DRESSED UP AND READY TO GO!



Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.