

©CAPCOM

HOW TO UPDATE AREA ARE

PC ONLY
Firmware Update

WARNING:

THIS UPDATE IS FOR THE __MEGA MAN __ARCADE1UP ONLY. <u>DO NOT APPLY THIS UPDATE TO OTHER ARCADE1UPS.</u> THIS UPDATE WILL DAMANGE OTHER ARCADE1UPS.





YOU WILL REED



The Mega Man Console Updater Tool.

The file will come zipped(compressed) so you will need to use a tool to unzip the files. We strongly recommend using the native Windows extractor or 7-Zip/WinRAR to unzip(decompress) your files as some zip tools may lead to complications.




PC with a USB to Micro USB Cable -To connect the Arcade1Up to a PC.

Windows 8 or Above Operating System is required.


Step 1: Download and Unzip Files






Step 2: Install Drivers





Step 3: Load The Build Into Flash Tool






Step 3: Load The Build Into Flash Tool

(Continued)





NOW LETS MOVE ONTO MEGA MAN CONSOLE



Step 4: Plugging in your Kit



- Now that you have the build successfully loaded onto your Flash Tool, proceed to take your USB to Micro USB cable, and plug the USB end into your PC.
- Before plugging the Micro USB end into your Mega Man Console, Unplug the power cable from your Mega Man Console.



On your Mega Man Console, press the power button so that it is in the on position.



Locate the reset button on the front of the console. Once located you want to press and hold the reset button down.



Step 4: Plugging in your Kit (continued)



While holding the sync button down,
Plug the MicroUSB end of your cable into the
power port of your Mega Man Console.



Once you have both the USB plugged into your computer, and the Micro USB plugged into the Mea Man Console, go back to your Flash Tool. At the bottom of your Flash Tool, the status should have changed from "No Devices Found" to "Found One MASKROM Device."



Found One MASKROM Device

Once you see this message, click "Run" button to begin flashing the Mega Man Console.

The download process will begin.




Step 7: Last Steps

Once the flash is complete, you will receive a "Download image OK" message at the bottom-right corner of your Flash Tool.



Wait for the text on the right side of the Flash Tool to populate, and the download progress will appear near the bottom.



One MASKROM Device

Verify **Download Image OK**

Test Device Start Test Device Success Check Chip Start Check Chip Success Get FlashInfo Start Get FlashInfo Success Prepare IDB Start Prepare IDB Success Download IDB Start Download IDB Success Wait For Maskron Start Wait For Maskrom Success Test Device Start Test Device Success FIRMWARE Start to download Download FIRMWARE...(100%)

Now that you are done flashing, unplug the MicroUSB end of the cable from your Console.

Press the power button so that it is in the OFF position.

MOIL 28 TO SELVI

Unplug the micro USB Cable



Plug the Power cable back into your console and turn it on