

ReST Bed™ Set-up Instructions

2 People | 30 min

Tools Needed:

Box Cutter

Summary of Steps

Step 1: Place Box Spring (Optional)

Step 2: Place ReST Bed™ on Box Spring/Platform/Adjustable Base

Step 3: Connect Air Hoses to Pump Unit

Step 4: Connect Sensor to Pump Unit

Step 5: Connect Power Supply

Step 6: Position Pump Unit

What's in the Box

Box Spring (Optional)



Mattress



• Pump Unit and Power Adapter





Step 1: Place Box Spring (Optional)

Note: this step only applies if customer has purchased Box Spring from ReST

 Make sure to place Box Spring near a power source.



Step 2: Place ReST Bed™ on Box Spring/Platform/Adjustable Base


- Before beginning the set up, unzip the top cover of the mattress to expose the sensors. Make sure they are zippered in.
- Then, unzip the next layer to expose the air chambers.
 Make sure they are laying flat in the tub.
- The head of the mattress includes air hoses and USB sensor cords.
- Ensure that the air hoses and USB sensor cords are tucked behind the headboard and under the foundation.






Step 3: Connect Air Hoses to Pump Unit

- In the gray sleeve that come from the head of the mattress, identify the air hoses.
- Air hoses with an "L" are for the left side of the bed.
 Air hoses with an "R" are for the right side of the bed.
 - See picture on Step 2 / page 5 for "left" and "right" side orientation.
- Connect air hoses by matching Head/Legs to corresponding sticker on the pump unit. Repeat for Hips, Lumbar, and Shoulders.
- If you need to disconnect the air hoses, press the center spring release.



Step 4: Connect Sensor to Pump Unit

- In the gray sleeve that come from the head of the mattress, identify the black cord alongside the air hoses.
- Insert the right sensor cord into the pump unit's USB input.
- Confirm the USB is plugged in completely. Repeat for the left side.





Step 5: Connect Power Supply

Plug the 3-prong power cord into a power source.

Important: avoid the use of extension cords as this could negatively impact the performance of the pump. We also recommend using a surge protector.

- Plug power connector into pump unit.
- The bed will take approximately 20 minutes to fully inflate.
- While bed is inflating, press and hold the reset button on the pump unit for 10 seconds.





Step 6: Position Pump Unit

- Pump unit should be on a carpeted or soft surface.
- Gently push the pump unit under the bed.
- While moving pump unit, avoid disconnecting air hoses, USB cable, or power connector.
- We recommend completing Steps 3 6 for one side of the bed before repeating Steps 3 – 6 for the other side of the bed.

