



DSLR SHOULDER RIG

INSTRUCTION MANUAL



For Demonstration only

All rights reserved

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the publisher.

INTRODUCTION

Our Filmcity DSLR SHOULDER RIG meets and exceeds the requirement of DSLR users by providing professional look production value at an affordable price.

IN THE BOX

Please inspect the contents of your shipped package to ensure you have received all that is pictured and listed below.

Note: 1. If you have purchased (FC-10W), you will receive the following:



Camera Base with
Quick Release



1 x Handle Set



Straight & Z-Bracket



5x 300mm Female
threaded Rods



Front handle
bracket clamps



Clamps For Handle Set



Front Handle Bracket



Counter Weight



Shoulder Pad



Handle Bracket



Accessories

Note: 2. If you have purchased (FC-10), you will receive the following except of counter weight



MB-77 Matte box



French and Side Flags



SR-33A Adapter

ASSEMBLING YOUR DSLR SHOULDER RIG

- Attach the quick release plate of your tripod head with base plate and tighten it with the help of screw driver.



- Now mount the base plate on fluid head and secure it properly with the help of knob.



- Insert the rod into camera base & tighten the knob to secure.



- Attach the front handle bracket clamps with the bracket, attach it with the rods and secure it properly with the help of allen key.



Note: The front handle bracket clamps are the ones with allen bolts.



- Now insert front handle rod into the front bracket and secure it properly with the help of allen key.



- Screw the handle into the handle clamp and insert the handle into the rod.




Note: The front handle bracket clamps are the ones without allen bolts



- Attach the z-bracket to the end of the rods and secure it properly with the help of provided knob.



- Now insert the 300mm rods into the z-bracket and tighten the knob to secure properly.



Note: if you have purchased (FC-10W) then you have to attached counter weight instead of SR-33A adapter.

- Attach the shoulder pad and SR-33A adapter into the rods and secure it properly with the help of provided knob.



- Attach the camera with quick release plate and tighten the bolt to secure properly.



- Now mount the camera onto the base plate and tighten the knob to secure it.



Note: you can adjust the height of camera plate as shown in the image.



Note: 2. If you have purchased (FC-10), you will receive the following except of counter weight

ASSEMBLING YOUR MB-77 MATTE BOX

- Attach the french flag & side flags with matte box by simply pushing.



Note: Height can be adjusted 3cm as per your requirement.



ATTACHING THE MATTE BOX

- Now attach the matte box to the front of rods and align it with lens barrel properly.



YOUR FILMCITY CARBON FIBER CAMERA RIG

ALL DRESSED UP AND GOOD TO GO



(SHOWN WITH OPTIONAL ACCESSORIES)

WARRANTY

We offer a one year warranty for our products from the date of purchase.

We will repair or replace your product, free of charge, in the event of a defect in materials or craftsmanship obtained during normal use or handling based on the user manual. Please note that we will not cover any shipping costs for returning the product to us. If any VAT or import duties are applied to the return, we will also charge these costs to the customer.

The warranty does not include, by the way of example, damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

We are not liable for incidental or consequential damages resulting from the use of the unit or occurring due to any breach of this warranty.

Replacement parts of the product will be provided at nominal cost (covering the cost price of the replacement parts only) to the customers after the Warranty Period has expired. We will cover the complete cost of sending replacement parts within the warranty period. After that, Nominal cost of the product & Actual shipping cost will be charged.

Do not send the unit to us without first getting a response and getting the approval to send back the item.

In case of any kind of dissatisfaction, we urge you to **Contact us** immediately and we shall do our Best to help you out. For any other assistance you can reach us via email.

For any other assistance you can reach us via email.