
Assembly Manual



What's In The Box

Please inspect the contents of your shipped package to ensure you have received everything that is listed below.



All rights reserved.

No part of this document may be reproduced, stored in a retrieval system, or transmitted by any form or by any means, electronic, mechanical, photo-copying, recording, or otherwise, except as may be expressly permitted by the applicable copyright statutes or in writing by the Publisher.

Astra jib **Setup**

 Mount the camera jib crane (8ft) above the tripod stand, matching the center of the jib stand.





• Dual Mounting Provision as shown.



 After the jib is aligned, tighten the jib properly with the help of the tightening knob.





• Then loosen the rear section knob of the jib crane, as shown in the image.





 The rear section has an interior connecting bar extension out. This slides into the front section or extension.
Tighten the knobs to secure the sections together.





 After inserting the connecting bar, insert the knob into the coupler and tighten knob into the groove.





Camera Setup

• Remove the extension camera plate screw with the help of a 4mm Allen key.



 Match both the threads of the camera mounting head as well as the extension camera plate properly, and secure the screw with the help of a 4mm Allen Key.





• (1/4" bolt, converted into 3/8") Remove the conversion adapter from the 3/8" bolt, so that the size of the bolt is converted to a 1/4" bolt, as shown in the image.





 Now inserting the bolt (1/4") into the thread of the extension camera plate and the camera's (Not-Included) thread hole from the bottom & Properly secure it with the help of screwdriver (Not-Included)





Counterweight Bar

 Insert the counterweight bar into the weight closure present at the back end of the camera jib, and tighten the counterweight properly.





• Use the weights according to your camera weight setup requirements.

NOTE: When the proper amount of counterweight has been added, the crane will rest in a horizontal position. Motions will be smooth and effortless. Note, the type of camera and mounting position will affect the balance. If the mounted camera is front heavy then mount the vertical bar in the first hole.



BELOW IS THE MANUAL TILT FUNCTIONALITY OF THE CAMERA

WARNING: When tilted manually, always maintain a control on the camera. The front heavy camera might move forward abruptly without notice, You need to be very careful at this point.

For Upper Angle





For Straight Angle





For lower Angle





LCD Mounting Bracket Setup

 Remove the Female Knob and the bolt from the LCD Mounting Bracket.





 To attach the mounting bracket to the jib stand, insert the bolt matching to the provided hole of the Astra camera jib.





 By aligning the mounting bracket properly, tighten it properly with the help of a female knob.





 After aligning the mounting bracket with the jib, Tighten the LCD Monitor (Not-included) with the help of the plastic screwdriver in symmetry to the hole of the mounting bracket, as shown in the image.





• The LCD Monitor (Not Included) is now Properly Mounted on the Astra Jib.



Remove Astra Camera Jib

 Remove the Astra camera jib from the jib stand, to align it on the tripod head and remove both of its screw with the help of a 4mm Allen key.





• Remove the jib crane from the jib stand.



Using Tripod Head Setup

• Loosen the knob of the tripod head, then remove the quick release plate.





 Attach the quick release plate to the bottom part of the jib and secure it properly with the help of a Screwdriver (Not-included).





• Directly mount the jib crane on the mounting part of the tripod head.





• (3/8" bolt, converted into 1/4") Remove the conversion adapter from 3/8" bolt, which will convert the size of the bolt into 1/4".





 Insert 1/4" bolt into the provided thread of the bottom part of the extension camera plate, and from the top of the camera plate, insert it into the Conversion adapter bolt, by which the bolt size will be converted back from 1/4" to 3/8".





 Attach the upper fluid head of the extension camera plate and properly secure it with the help of a screwdriver (Not-Included). Then attach the quick release plate at the bottom part of the camera and attach it properly at the top mounting part of the fluid head.





• Camera (Not-Included) is properly attach with camera plate.



YOUR PROAIM ASTRA CAMERA JIB CRANE ALL DRESSED UP AND READY TO GO!



(SHOWN WITH OPTIONAL ACCESSORIES)

Warranty: We offer one year warranty for our products from date of purchase. Within this period of time, we will repair it without charge for labor or parts. Warranty doesn't cover transportation costs nor does it cover a product subjected to misuse or accidental damage. Warranty repairs are subjected to inspection and evaluation by us.

Liability: We are not liable for damage caused by products that we do not supply or from mishandling in transit, accident, misuse, neglect, lack of care of the product, or service by anyone other than our company.

Contact Us: In case of any kind of dissatisfaction, please Contact us immediately and we promise our utmost support and care until you use our product.